

Record of Revisions

Reference numbers are shown at the bottom left corner on the back cover of each manual.

Date	Reference No.	Revised Contents
May, 2014	1071NE0	First edition
March, 2017	1071NE1	Second edition <ul style="list-style-type: none">• Added printer related macro commands• Added video related macro commands• Added MES macro commands• Added the macro command for universal serial interruption [SYS (OUT_ENQ_EX)]• Other modifications
October, 2018	1071NE2	Third edition <ul style="list-style-type: none">• Added RGB related macro commands• Added the macro command for FL-net information acquisition [SYS (GET_STATUS_FL)]• Added TELLUS related macro commands• Other modifications

Preface

Congratulations on purchasing the MONITOUCH V9 series.

The "V9 Series Macro Reference" manual describes macro functions used on the drawing/editing software (V-SFT version 6) for the MONITOUCH V9 series. For a correct use of the product, read this manual thoroughly.

Notes:

1. The copyright of the software is possessed by Hakko Electronics Co., Ltd.
2. Reproduction of the contents of the software and this manual, in whole or in part, without permission of Hakko Electronics Co., Ltd. is prohibited.
3. The specifications of the software and the information in this manual are subject to change without prior notice.
4. If the specifications of the software do not correspond with the contents of this manual, the software specifications have priority.
5. No liability is assumed by Hakko Electronics Co., Ltd. with respect to the influence brought by the result of using the software or this manual.
6. You may use this software on a single central processing unit.

About Trademarks:

- Windows, Word and Excel are registered trademarks of Microsoft Corporation in the United States and other countries.
- All other company names or product names are trademarks or registered trademarks of their respective holders.
- The names of the products contained herein are trademarks or registered trademarks of their respective manufacturers.

About Manuals

The manuals shown below are related manuals for the V9 series. Refer to them as necessary.

Manual Name	Contents	Reference No.
V9 Series Reference Manual 1	Explains the functions and operations of the V9 series.	1065NE
V9 Series Reference Manual 2		1066NE
V9 Series Setup Manual	Explains the installation procedure of V-SFT version 6, the creation process of simple screen programs as well as how to transfer a created screen program using V-SFT version 6.	1067NE
V9 Series Troubleshooting/ Maintenance Manual	Provides an error list and explains the operating procedures for the V9 series.	1068NE
V9 Series Training Manual Beginner's Guide	Explains the screen creation process using V-SFT version 6 with examples in detail.	1069NE
V9 Series Training Manual Practical Guide		1070NE
V9 Series Macro Reference	Provides an overview of macros of V-SFT version 6 and explains macro editor operations and macro command descriptions in detail.	1071NE
V9 Series Operation Manual	Explains the configuration of V-SFT version 6, the editing process of each part and limitations regarding operation in detail.	1072NE
V9 Series Connection Manual 1	Explains the connection and communication parameters for the V9 series and controllers in detail.	2210NE
V9 Series Connection Manual 2		2211NE
V9 Series Connection Manual 3		2212NE
V9 Series Hardware Specifications	Explains hardware specifications and precautions when handling the V9 series.	2023NE

V9 Series Models

The following V9 series models are available:

Generic Name	Series	Model
V9 series	V9 Advanced	V910xiW
		V907xiW
	V9 Standard	V9150iX
		V9120iS
		V9100iS
		V9080iS
	V9 Lite	V9010iC
		V9080iC
		V9060iT
	TELLUS4	

Please note that the V9 series model names are used as listed above in the manuals.

Notes on Safe Usage of MONITOUCH

In this manual, you will find various notes categorized under the following levels with the signal words “DANGER” and “CAUTION”.



DANGER

Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.



CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury and could cause property damage.

Note that there is a possibility that items listed with  CAUTION may have serious ramifications.

DANGER

- Never use the output signal of the V9 series for operations that may threaten human life or damage the system, such as signals used in case of emergency. Please design the system so that it can cope with a touch switch malfunction. A touch switch malfunction may result in machine accidents or damage.
- Turn off the power supply when you set up the unit, connect new cables, or perform maintenance or inspections. Otherwise, electrical shock or damage may occur.
- Never touch any terminals while the power is on. Otherwise, electrical shock may occur.
- You must cover the terminals on the unit before turning the power on and operating the unit. Otherwise, electrical shock may occur.
- The liquid crystal in the LCD panel is a hazardous substance. If the LCD panel is damaged, do not ingest the leaked liquid crystal. If leaked liquid crystal makes contact with skin or clothing, wash it away with soap and water.
- Never disassemble, recharge, deform by pressure, short-circuit, reverse the polarity of the lithium battery, nor dispose of the lithium battery in fire. Failure to follow these conditions will lead to explosion or ignition.
- Never use a lithium battery that is deformed, leaking, or shows any other signs of abnormality. Failure to follow these conditions will lead to explosion or ignition.
- Switches on the screen are operable even when the screen has become dark due to a faulty backlight or when the backlight has reached the end of its service life. If the screen is dark and hard to see, do not touch the screen. Otherwise, unintended operations may occur resulting in machine accidents or damage.

CAUTION

- Check the appearance of the unit when it is unpacked. Do not use the unit if any damage or deformation is found. Failure to do so may lead to fire, damage, or malfunction.
- For use in a facility or as part of a system related to nuclear energy, aerospace, medical, traffic equipment, or mobile installations, please consult your local distributor.
- Operate (or store) the V9 series under the conditions indicated in this manual and related manuals. Failure to do so could cause fire, malfunction, physical damage, or deterioration.
- Observe the following environmental restrictions on use and storage of the unit. Otherwise, fire or damage to the unit may result.
 - Avoid locations where there is a possibility that water, corrosive gas, flammable gas, solvents, grinding fluids, or cutting oil can come into contact with the unit.
 - Avoid high temperatures, high humidity, and outside weather conditions, such as wind, rain, or direct sunlight.
 - Avoid locations where excessive dust, salt, and metallic particles are present.
 - Avoid installing the unit in a location where vibrations or physical shocks may be transmitted.

 **CAUTION**

- Equipment must be correctly mounted so that the main terminal of the V9 series will not be touched inadvertently. Otherwise, an accident or electric shock may occur.
- Tighten the mounting screw on the fixtures of the V9 series to an equal torque of 5.31 lbf-in (0.6 N·m). Excessive tightening may distort the panel surface. Loose mounting screws may cause the unit to fall down, malfunction, or short-circuit.
- Check periodically that terminal screws on the power supply terminal block and fixtures are firmly tightened. Loosened screws or nuts may result in fire or malfunction.
- Tighten the terminal screws on the power supply terminal block of the V9 series to an equal torque of 7.1 to 8.8 inch-lbf (0.8 to 1.0 N·m). Improper tightening of screws may result in fire, malfunction, or other serious trouble.
- The V9 series has a glass screen. Do not drop the unit or impart physical shocks to the unit. Otherwise, the screen may be damaged.
- Correctly connect cables to the terminals of the V9 series in accordance with the specified voltage and wattage. Overvoltage, overwattage, or incorrect cable connection could cause fire, malfunction, or damage to the unit.
- Always ground the V9 series. The FG terminal must be used exclusively for the V9 series with the level of grounding resistance less than 100 Ω. Otherwise, electric shock or a fire may occur.
- Prevent any conductive particles from entering the V9 series. Failure to do so may lead to fire, damage, or malfunction.
- After wiring is finished, remove the paper used as a dust cover before starting operation of the V9 series. Operation with the dust cover attached may result in accidents, fire, malfunction, or other trouble.
- Do not attempt to repair the V9 series yourself. Contact Hakko Electronics or the designated contractor for repairs.
- Do not repair, disassemble, or modify the V9 series. Hakko Electronics Co., Ltd. is not responsible for any damages resulting from repair, disassembly, or modification of the unit that was performed by an unauthorized person.
- Do not use sharp-pointed tools to press touch switches. Doing so may damage the display unit.
- Only experts are authorized to set up the unit, connect cables, and perform maintenance and inspection.
- Lithium batteries contain combustible material such as lithium and organic solvents. Mishandling may cause heat, explosion, or ignition resulting in fire or injury. Read the related manuals carefully and correctly handle the lithium battery as instructed.
- Take safety precautions during operations such as changing settings when the unit is running, forced output, and starting and stopping the unit. Any misoperations may cause unexpected machine movement, resulting in machine accidents or damage.
- In facilities where the failure of the V9 series could lead to accidents that threaten human life or other serious damage, be sure that such facilities are equipped with adequate safeguards.
- When disposing of the V9 series, it must be treated as industrial waste.
- Before touching the V9 series, discharge static electricity from your body by touching grounded metal. Excessive static electricity may cause malfunction or trouble.
- Insert an SD card into the unit in the same orientation as pictured on the unit. Failure to do so may damage the SD card or the slot on the unit.
- The SD card access LED flashes red when the SD card is being accessed. Never remove the SD card or turn off power to the unit while the LED is flashing. Doing so may destroy the data on the SD card. Check that the LED has turned off before removing the SD card or turning off the power to the unit.
- Be sure to remove the protective sheet that is attached to the touch panel surface at delivery before use. If used with the protective sheet attached, MONITOUCH may not correctly recognize touch operations.
- When using an analog resistive-film type V9 series unit, do not touch two positions on the screen at the same time. If two or more positions are pressed at the same time, the switch located between the pressed positions may be activated.
- When using a V9 series unit of the capacitive type, observe the following points.
 - Use a Class 2 power supply for the 24 VDC power unit. Using an unstable power supply may result in incorrect touch switch activation.
 - Capacitive touch panel types support two-point touch operations. If a third point is touched, the touch operation will be cancelled.
 - Capacitive touch panel types are prone to the influence of conductive material. Do not place conductive material such as metals near the touch panel surface and do not use the panel if it is wet. Otherwise, malfunctions may occur.

[General Notes]

- Never bundle control cables or input/output cables with high-voltage and large-current carrying cables such as power supply cables. Keep control cables and input/output cables at least 200 mm away from high-voltage and large-current carrying cables. Otherwise, malfunction may occur due to noise.
- When using the V9 series in an environment where a source of high-frequency noise is present, it is recommended that the FG shielded cable (communication cable) be grounded at each end. However, when communication is unstable, select between grounding one or both ends, as permitted by the usage environment.
- Be sure to plug connectors and sockets of the V9 series in the correct orientation. Failure to do so may lead to damage or malfunction.
- If a LAN cable is inserted into the MJ1 or MJ2 connector, the device on the other end may be damaged. Check the connector names on the unit and insert cables into the correct connectors.
- Do not use thinners for cleaning because it may discolor the V9 series surface. Use commercially available alcohol.
- If a data receive error occurs when the V9 series unit and a counterpart unit (PLC, temperature controller, etc.) are started at the same time, read the manual of the counterpart unit to correctly resolve the error.
- Avoid discharging static electricity on the mounting panel of the V9 series. Static charge can damage the unit and cause malfunctions. Discharging static electricity on the mounting panel may cause malfunction to occur due to noise.
- Avoid prolonged display of any fixed pattern. Due to the characteristic of liquid crystal displays, an afterimage may occur. If prolonged display of a fixed pattern is expected, use the backlight's auto OFF function.
- The V9 series is identified as a class-A product in industrial environments. In the case of use in a domestic environment, the unit is likely to cause electromagnetic interference. Preventive measures should thereby be taken appropriately.
- The signal ground (SG) and frame ground (FG) are connected inside the V9150 series unit. Take care when designing systems.

[Notes on the LCD]

Note that the following conditions may occur under normal circumstances.

- The response time, brightness, and colors of the V9 series may be affected by the ambient temperature.
- Tiny spots (dark or luminescent) may appear on the display due to the characteristics of liquid crystal.
- There are variations in brightness and color between units.

[Notes on Capacitive Touch Panels]

- Touch panel operability may not be optimal if used with dry fingers or skin. In such a case, use a capacitive stylus pen.
- Regularly clean the screen to maintain optimal performance of touch operations. Observe the following points when cleaning the screen.
<Notes on Cleaning>
 - The panel surface is made of glass. Be sure to clean the surface gently with a cloth or sponge. Otherwise, you may scratch or damage the glass.
 - Take care not to let cleaning detergent to seep into the touch panel unit. In particular, avoid spraying cleaning detergent directly onto the panel surface.

[Notes on Wireless LAN]

For details regarding supported wireless LAN standards, radio law certifications, and countries where wireless LAN can be used, refer to the "About Wireless LAN on V9 Advanced Model"/"About Wireless LAN on V9 Standard Model" manual or the "V9 Series Hardware Specifications" provided with the V9 series unit at delivery.

Contents

Chapter 1 Outline

1.1	Type of V Series Macros	1-1
1.2	Screen Macro	1-2
1.3	Multi-overlap Macro.	1-3
1.4	Switch Macro.	1-4
1.5	Function Switch Macro	1-5
1.6	Initial Macro.	1-6
	Macro Setting	1-6
	[General] tab window	1-6
1.7	Global Macro.	1-7
	Macro Setting	1-7
	[General] tab window	1-7
	Macro Execution Steps	1-7
	Supplemental Remarks	1-7
1.8	Event Timer Macro	1-8
	Macro Setting	1-8
	[Event Timer Macro] tab window	1-8
	Supplemental Remarks	1-8
1.9	Interval Timer	1-9
	Setting Dialog	1-10
	[Macro Edit] window	1-10
	[Detail] window.	1-12
	Setting Example	1-13
1.10	Macro Mode	1-15
	Setting	1-15
	[Macro Edit] window	1-15
	[Detail] window	1-16
1.11	Alarm Macro	1-17
1.12	Scheduler Macro.	1-18
1.13	Notes on Macros.	1-19

Chapter 2 Edit

2.1	7Macro Editor	2-1
2.1.1	Start and Quit	2-1
	Start	2-1
	Screen	2-1
	Overlap library	2-1
	Switch	2-2
	Function switch	2-2
	Macro block	2-3
	Macro mode	2-3
	Alarm macro	2-4
	Scheduler macro	2-4
	Quit	2-5
2.1.2	Screen Composition	2-6
	Menus	2-6
	[File] menu	2-6
	[Edit]/right-click menu	2-7
	[View] menu	2-8
	Toolbar	2-9
	Edit	2-9
	Comment List	2-9
	Macro Editing Support	2-9
2.1.3	Edit	2-10
	1: Command Entry	2-10
	New registration	2-10
	Device memory change	2-11
	Command change	2-11
	2: Direct Entry	2-12
	New registration	2-12
	Memory change	2-13
	Command change	2-13
	3: Macro Editing Support	2-14
	New registration	2-14
	Device memory change	2-15
	4: Text Entry	2-16
	Export	2-16
	Text editing	2-16
	Import	2-17
2.1.4	Error	2-18
2.2	Available Device Memory	2-19
2.2.1	Device Memory Types	2-19
2.2.2	Indirect Device Memory Designation	2-20
	Internal Device Memory, PLC (1 - 8) Device Memory	2-20
	Memory card	2-21
	Example	2-21

2.3	CSV Format Setting (with Recipe or Sampling Macro Used)	2-22
2.3.1	Applicable Macros	2-22
2.3.2	Recipe	2-23
	Setting procedure	2-23
	Setting details	2-24
	V8-compatible settings	2-27
	CSV File Name and Storage Target	2-28
	Total Number of CSV Files	2-29
	Data in CSV File	2-29
2.3.3	Sampling	2-30
	Alarm Server	2-30
	Setting procedure	2-30
	Setting details	2-30
	Logging Server	2-32
	Setting procedure	2-32
	Setting details	2-32
	CSV File Name and Storage Target	2-33
	For "SMPL_CSV"	2-33
	For "SMPLCSV_BAK/SMPLCSV_BAK2"	2-34

Chapter 3 Command

3.1	Macro Command List	3-1
-----	--------------------	-----

Chapter 4 Details of Macro Commands

4.1	Guide to Chapter 4	4-1
4.2	Arithmetical Operation	4-2
	ADD(+)	4-2
	SUB(-)	4-4
	MUL(X)	4-6
	DIV(/)	4-8
	MOD(%)	4-9
4.3	Logical Operation	4-10
	AND(&)	4-10
	OR()	4-11
	XOR(^)	4-12
	SHL(<<)	4-13
	SHR(>>)	4-14
4.4	Statistic	4-15
	MAX	4-15
	MIN	4-16
	AVG	4-17
	SUM	4-18
4.5	Mathematics/trigonometric	4-19
	EXP	4-19
	EXPT	4-20
	LN	4-21
	LOG	4-22
	SQRT	4-23
	ABS	4-24
	NEG	4-25

	SIN	4-26
	COS	4-27
	TAN	4-28
	ASIN	4-29
	ACOS	4-30
	ATAN	4-31
	DEG	4-32
	RAD	4-33
4.6	Bit Operation	4-34
	BSET	4-34
	BCLR	4-35
	BINV	4-36
4.7	Conversion	4-37
	BCD	4-37
	BIN	4-38
	CWD	4-39
	CVP	4-40
	CVPFMT	4-41
	CVB	4-42
	CVBFMT	4-43
	SWAP	4-44
	CHR	4-45
	STRING	4-46
	CVFD	4-47
	CVDF	4-49
	CLND_TO_GRE	4-51
	GRE_TO_CLND	4-53
	FORMAT_DATA	4-55
	FORMAT_STR	4-59
4.8	Transfer	4-63
	MOV	4-63
	BMOV	4-64
	CVMOV	4-66
	CVSMOV	4-69
	FILL	4-71
4.9	Comparison	4-72
	CMP	4-72
	TST	4-74
	IF	
	ELSE	
	ENDIF	4-75
4.10	Macro Operation Control	4-77
	CALL	4-77
	JMP	4-79
	LABEL	4-80
	FOR/NEXT	4-81
	RET	4-83
	SWRET	4-84
	EN_INT	4-85
4.11	FROM Backup	4-86
	FROM_WR	4-86
	FROM_RD	4-87

4.12	Printer	4-88
	MR_OUT	4-88
	MR_REG	4-89
	OUT_PR	4-91
4.13	Video	4-93
	VIDEO	4-93
	VIDEO2	4-107
4.14	PLC	4-149
	PLC_CLND	4-149
	PLC_CTL	4-151
	TBL_READ	4-153
	TBL_WRITE	4-154
4.15	Ethernet	4-155
	SEND	4-155
	EREAD	4-157
	EWRITE	4-158
4.16	MES	4-159
	MES	4-159
4.17	Storage (Recipe)	4-169
	LD_RECIPE	4-169
	LD_RECIPE2	4-172
	LD_RECIPESEL	4-174
	LD_RECIPESEL2	4-177
	SV_RECIPE	4-181
	SV_RECIPE2	4-183
	SV_RECIPESEL	4-185
	SV_RECIPESEL2	4-188
	SET_	
	RECIPEFOLDER	4-190
	RD_RECIPE_FILE	4-192
	RD_RECIPE_LINE	4-194
	RD_RECIPE_	
	COLUMN	4-197
	WR_RECIPE_FILE	4-200
	WR_RECIPE_LINE	4-202
	WR_RECIPE_	
	COLUMN	4-204
	GET_RECIPE_	
	FILEINFO	4-206
4.18	Storage (Sampling)	4-208
	SMPL_BAK	4-208
	SMPL_CSV	4-210
	SMPL_CSV2	4-213
	SMPL_SAVE	4-216
	SMPLCSV_BAK	4-218
	SMPLCSV_BAK2	4-221
4.19	Storage (Others)	4-223
	HDCOPY	4-223
	HDCOPY2	4-224
	HDCOPY3	4-226
	SET_DRIVE	4-228
	COPY_FILE	4-229
	MOVE_FILE	4-231

	READ_FILE	4-233
	WRITE_FILE	4-235
4.20	Real No. Arithmetical Operation	4-237
	F_ADD(+)	4-237
	F_SUB(-)	4-238
	F_MUL(X)	4-239
	F_DIV(/)	4-240
4.21	Real No. Statistics	4-241
	F_SUM	4-241
	F_AVG	4-242
	F_MAX	4-243
	F_MIN	4-244
4.22	Others	4-245
	;(Comment)	4-245
	BRIGHT	4-246
	GET_MSGBLK	4-247
	PLC_ULR	4-248
	RECONNECT	4-250
	RECONNECT_EX	4-251
	SAMPLE	4-252
	SEARCH_FILE	4-255
	ADJ_VOLUME	4-256
	SAVE_VOLUME	4-257
	TREND REFRESH	4-258
	SYS	4-259
	HMI-FUNC	4-305

1

Outline

- 1.1 Type of V Series Macros
- 1.2 Screen Macro
- 1.3 Multi-overlap Macro
- 1.4 Switch Macro
- 1.5 Function Switch Macro
- 1.6 Initial Macro
- 1.7 Global Macro
- 1.8 Event Timer Macro
- 1.9 Interval Timer
- 1.10 Macro Mode
- 1.11 Alarm Macro
- 1.12 Scheduler Macro
- 1.13 Notes on Macros

1.1 Type of V Series Macros

Macros, created with V-series-specific commands, are used to process user programs. Macro creation is made simple with easy-to-use commands.

Macros are executable for the following occasions:

- Screen
 - OPEN macro: Executes once when the screen is opened.
 - CLOSE macro: Executes once when the screen is switched.
 - CYCLE macro: Executes repeatedly while the screen is open.
- Multi-overlap
 - OPEN macro: Executes once when the multi-overlap is opened.
 - CLOSE macro: Executes once when the multi-overlap is closed.
 - * OPEN and CLOSE macros cannot be used for call-overlaps.
- Switch
 - ON macro: Executes once when the switch is pressed.
 - OFF macro: Executes once when the switch is released.
- Function switch
 - ON macro: Executes once when the function switch is pressed.
 - OFF macro: Executes once when the function switch is released.
- Initial macro

The specified macro block executes once before the V series starts communicating with the PLC. (Refer to page 1-6.)
- Global macro

The specified macro block is executed once when the control device memory is changed from 0 to 1 (leading edge). (Refer to page 1-7.)
- Event timer macro

The specified macro block executes at regular intervals, regardless of which screen is currently displayed. (Refer to page 1-8.)
- Interval timer

While a screen equipped with the interval timer is displayed, the timer starts as preset. Each time the preset time has elapsed, the specified macro block is executed. (Refer to page 1-9.)
- Macro mode

While a screen equipped with macro mode is displayed, macros are executed according to the status at the specified device memory addresses. (Refer to page 1-15.)

 - ON macro: Executes when the bit at the specified device memory address changes from 0 → 1 (leading edge).
 - OFF macro: Executes when the bit at the specified device memory address changes from 1 → 0 (falling edge).
- Alarm macro

When a macro is set in the [Alarm Server] window, it is executed according to a change in the status of the device memory for errors. (Refer to page 1-17.)

 - Occurrence macro: To be executed at the time of alarm occurrence
 - Resetting macro: To be executed at the time of alarm reset
- Scheduler macro

When a macro is set in the [Scheduler] window, it is executed at the timing specified for [Trigger]. (Refer to page 1-18.)

1.2 Screen Macro

This macro is registered for screens.

Registered commands are executed at the following timings:

- OPEN macro
This macro is executed once when a screen is opened.
Select [Screen Setting] → [Open Macro] and register the command to be executed.
- CLOSE macro
This macro is executed once when a screen is closed.
Select [Screen Setting] → [Close Macro] and register the command to be executed.
- CYCLE macro
This macro is executed repeatedly while the screen is open.
Select [Screen Setting] → [Close Macro] and register the command to be executed.




1.3 Multi-overlap Macro

This macro is registered for overlap displays.

Registered commands are executed at the following timings:


- OPEN macro
This macro is executed once when a multi-overlap display is opened.
Select [Screen Setting] → [Open Macro] in the overlap library window and register the command to be executed.
- CLOSE macro
This macro is executed once when a multi-overlap display is closed.
Select [Screen Setting] → [Close Macro] in the overlap library window and register the command to be executed.



1.4 Switch Macro

This macro is registered for switches.


- ON macro
This macro is executed once when a switch is pressed.
Set the command in the [Macro] window of the switch.
 - Editing with [Setting Method: Use switch macros] selected
Macro commands are registered for switches.
 - Editing with [Setting Method: Specify the macro block number] selected
Register macro commands in a macro block, and select a number of the macro block to execute.
- OFF macro
This macro is executed once when a switch is released.
Set the command in the [Macro] window of the switch.
 - Editing with [Setting Method: Use switch macros] selected
Macro commands are registered for switches.
 - Editing with [Setting Method: Specify the macro block number] selected
Register macro commands in a macro block, and select a number of the macro block to execute.



1.5 Function Switch Macro

This macro is registered for function switches.

- ON macro
This macro is executed once when a switch is pressed.
Set the command in the [Local Function Switch Setting] window.
- OFF macro
This macro is executed once when a switch is released.
Set the command in the [Local Function Switch Setting] window.



1.6 Initial Macro

An initial macro is executed once before the V series starts communicating with an external device.

Select [System Setting] → [Macro Setting] to make settings.


Register the command in [Macro Block].

Select [Home] → [Registration Item] → [Macro Block] to register a macro block.

For more information, refer to page 2-3.

Macro Setting

[General] tab window



Initial Macro	Check this box to use an initial macro. Specify the macro block number to be executed before the V series starts communicating with the PLC. 0 - 1023: Macro block number
---------------	---

1.7 Global Macro

A global macro is executed when the bit is set (ON), regardless of the screen being displayed. Select [System Setting] → [Macro Setting] to make settings.


Register the command in [Macro Block].

Select [Home] → [Registration Item] → [Macro Block] to register a macro block.

For more information, refer to page 2-3.

Macro Setting

[General] tab window



Global Macro	Check this box to use a global macro.
Macro Block	Specify the macro block number to be executed. It can also be specified by specifying a device memory address.
Control Device	Specify a macro start bit. The macro is executed when the specified bit changes from 0 → 1 (leading edge).
Information Output Device	This reflects the status of the control device memory.

Macro Execution Steps

1. Specify the number of the macro block for which commands to be executed are registered.
2. The control device memory is set ([0 → 1] leading edge).
↓
Macro execution
↓
The information output device memory is automatically set ([0 → 1]).
3. The control device memory is reset ([1 → 0] falling edge).

Supplemental Remarks

- By using the information output device memory, you can check the timing to reset (OFF) the control device memory.

1.8 Event Timer Macro

An event timer macro is executed at regular intervals, regardless of the screen being displayed.

Select [System Setting] → [Macro Setting] → [Event Timer Macro] to make settings.


Register the command in [Macro Block].

Select [Home] → [Registration Item] → [Macro Block] to register a macro block.

For more information, refer to page 2-3.

Macro Setting


[Event Timer Macro] tab window



Event Timer	0 - 7 A maximum of eight event timer macro blocks can be set.
Cycle Time	0 - 3600 (sec) Specify a cycle time for the timer. The specified macro block is executed each time the specified time has elapsed.
Macro No.	0 - 1023 Specify the macro block number to be executed.

Supplemental Remarks

- When the timers for multiple event timer macros are up at the same time:
Event timer macro blocks are executed in ascending numeric order of [Event Timer]. After a macro block has been processed, execution proceeds to the next macro block.



- When accessing the same external device memory address in some event timer macros:
The processing ability will be improved if you set the event timer macro No. 0 that reads the external device memory into the internal device memory and make other event timer macros refer to this internal device memory.
In order to improve the overall processing ability, reduce the number of times that the external device memory is accessed.

1.9 Interval Timer


The interval timer can be set for screens and multi-overlap displays.

Select [Screen Setting] → [Interval Timer] to make settings.


The interval timer has the following three functions.

Register the command in [Macro Block] for all cases.


- The specified macro is executed at intervals specified for [Repeat Interval] from when the screen is opened.



- The specified macro is executed at intervals specified for [Repeat Interval] from when an arbitrary bit is set (ON). (This function is valid only while the bit is ON.)




- The specified macro is executed once after the time specified for [Repeat Interval] has elapsed since the screen was opened or an arbitrary bit was set (ON).






Setting Dialog

[Macro Edit] window




Repeat Interval *1	<p>0 - 65535 (× 100 msec)</p> <p>Specify a repetition interval to execute the macro. The macro is executed at the specified intervals. When "0" is specified, the macro is executed every cycle.</p> <p>The timing to start the timer depends on the setting for [Use the start device].</p>
Stop after macro execution	<p>Check this box to execute the macro only once.</p> <p>When the specified time has elapsed and the macro has been executed, the timer stops.</p>
Use the start device	<p>Check this box when specifying the start device memory address.</p> <ul style="list-style-type: none"> • Unchecked <p>The timer starts when the screen is opened.</p> • Checked <p>While the bit is "1" (ON): The macro is executed at intervals specified for [Repeat Interval].</p> <p>While the bit is "0" (OFF): The macro is not executed.</p>
Execution Macro	<p>Specify the macro block number to be executed at intervals specified for [Repeat Interval].</p>

ON Macro	<p>Specify the macro block number to be executed once when the timer starts.</p> <ul style="list-style-type: none"> • [Use the start device] unchecked: When the screen is opened, the timer starts and the ON macro is executed once. <p>The timer starts when the screen is opened.</p>  <ul style="list-style-type: none"> • [Use the start device] checked: The ON macro block is executed once when the start device memory bit is set to "1". 
OFF Macro	<p>This option is enabled, provided that [Use the start device] is checked. Specify the macro block number to be executed once when the start device memory bit is reset (1 → 0).</p>  <p>This option is useful for clearing the internal device memory that is used for a macro.</p>
Edit	This button is used to open a macro block.
Preview	This area displays the contents of macros registered in the selected macro block number.

*1 The actual repetition interval may fluctuate according to the contents of the screen.

[Detail] window




Process Cycle	Specify the cycle for the V series to read the PLC when they are communicating. For more information, refer to the V9 Series Reference Manual.
ID	Specify an ID.

Setting Example

Graphic movement on the screen

When the switch is pressed, a graphic from the graphic library is displayed. At the same time, the graphic placed on the left of the screen starts to move to the right.

Pressing the switch next clears the graphic. Pressing the switch again displays the graphic in the same position where it was displayed last. The graphic starts to move to the right.



Screen Edit

(1) Graphic ([Method: Device (Bit Designation)])

Number of Bits to Monitor: 1
Device Designation: $\$u100-00$
Type: 1-Graphic
Mode: XOR
Start Graphic: GNo. 0 No. 0
Valid parameters No.: 1

(2) Interval timer

Repeat Interval: 0
 Stop after macro execution
 Use the start device: $\$u100-00$
 Execution Macro: Macro block No.: 1
 ON Macro: Macro block No.
 OFF Macro: Macro block No.


(3) Switch

Device to Output: $\$u100-00$
Output Action: Alternate
Lamp Device: $\$u100-00$

Graphic Library Edit (4)

Example: GNo. 0 & No. 0

Place the following graphic on the screen, and specify the X parameter.



Macro Block Edit (5)

Example: Macro block No. 1

```
0 $u00101 = $u00101 + 1 (W)
1 IF ($u00101 = 640) LB00 (W)
2 RET
3 LB00:
4 $u00101 = 0 (W)
```

Macro to change the X parameter of the graphic start point

While the count on the X axis is increasing up to 640 (0 → 1 → ... → 640 → 0 → 1 → ... → 640), the graphic moves from the left to the right.

Transfer the above screen program to the V series for checking.

1.10 Macro Mode

Select [Screen Setting] → [Macro] to make settings.

The interval timer can be set for screens and multi-overlap displays.

Macro mode is used to execute an ON macro when the corresponding bit changes from 0 → 1 (leading edge) and an OFF macro when the corresponding bit changes from 1 → 0 (falling edge).

However, when the screen (multi-overlap) is opened, they are executed upon level recognition.


(Refer to [Execute an OFF macro at startup].)

Set the command in the [Macro Edit] window of the macro mode.

A maximum of 32 ON/OFF macros each can be set using the consecutive bits.

Setting


[Macro Edit] window



Device Designation	Specify the device memory address that triggers the macro.
Number of Relays	1 - 32 Specify the number of bits for triggering macros. The number specified here is common to both the ON macro and OFF macro. Example: "10" specified for [Number of Relays] - ON Macro: 10 maximum - OFF Macro: 10 maximum In this case, 10 bits must be allocated for [Device Designation].
Execute an OFF macro at startup	Set the operation to be performed when a screen or multi-overlap for which a macro mode is set is opened. <ul style="list-style-type: none"> • Checked While the bit specified for [Device Designation] is ON, the ON macro is executed; while it is OFF, the OFF macro is executed. • Unchecked The ON macro is executed while the bit specified for [Device Designation] is ON. While the bit is OFF, nothing is executed.
Macro to Edit	As many ON/OFF macros as the number for [Number of Relays] can be set.

Edit	The macro editor window corresponding to the selected relay number is opened.
Delete	The macro of the selected relay number is deleted.
Cut	The macro of the selected relay number is cut (copied and deleted).
Copy	The macro of the selected relay number is copied.
Paste	The copied macro is pasted to the selected relay number.
Preview	The macro of the selected relay number is shown.

[Detail] window



Process Cycle	Specify the cycle for the V series to read data in the PLC when they are communicating. For more information, refer to the V9 Series Reference Manual.
ID	Specify an ID.

1.11 Alarm Macro


An alarm macro can be set when the alarm server is used.

Select [Alarm Device] → [Operation Setting] to set macro commands.

When an alarm occurs, the occurrence macro is executed once. When it is reset, the resetting macro is executed once.

Select [Alarm Server] → [Alarm Device] → [Operation Setting] → [Macro], and set commands to be executed.

- Editing with [Setting: Use Alarm macros] selected
Register macro commands directly in the [Operation Setting] window.
- Editing with [Setting: Specify the macro block number] selected
Register macro commands in a macro block, and select a number of the macro block to execute.



1.12 Scheduler Macro


A scheduler macro is executed by using the scheduler function.

Select [System Setting] → [Scheduler] to set macro commands.

The registered macro is executed once at the timing specified for [Trigger] in the [Scheduler] window.

Select [Action] → [Macro], and set commands to be executed.

- Editing with [Setting: Use Scheduler macros] selected
Register macro commands directly in the [Action] tab window.
- Editing with [Setting: Specify the macro block number] selected
Register macro commands in a macro block, and select a number of the macro block to execute.



1.13 Notes on Macros

- A maximum of 1,024 lines (instructions) can be set for one macro.
- The maximum of executable lines in macros is 160,000.
If the maximum permissible number is exceeded by, for instance the repetition of the same macro with the use of a loop macro, macro execution is forcibly terminated.
With the V9 series, if the maximum number of executions is exceeded “-1 (DEC)” is stored at \$s1059.
- A maximum of 4096 words of data can be transferred per command. When creating macros, be careful not to exceed the maximum.
- When an external device memory is used with multiple MOV commands, the external memory is accessed each time so the processing speed is slowed down.

Example:

```
Line No. 0 PLC1 [D00200] = $u00200 (W)
Line No. 1 PLC1 [D00201] = $u00201 (W)
Line No. 2 PLC1 [D00202] = $u00202 (W)
Line No. 3 PLC1 [D00203] = $u00203 (W)
Line No. 4 PLC1 [D00204] = $u00204 (W)
```

In the above example, the V series goes and writes data to D200 as commanded in line No. 0, then goes and writes data to D201 as commanded in line No. 1, and so on. Communications that frequently occur will result in a prolonged processing time.


To shorten the communications time, give a BMOV command as shown below. The contents of the macro using BMOV are the same as the above macro consisting of five lines, but the data writing takes place only once.

```
Line No. 0 PLC1 [D00200] = $u00200 C:5 (BMOV) (W)
```

The processing speed is increased and the number of macro commands is reduced. As described above, macros can be simplified when you plan to make their commands more efficient to use.

MEMO

Please use this page freely.



2 Edit

- 2.1 Macro Editor
 - 2.1.1 Start and Quit
 - 2.1.2 Screen Composition
 - 2.1.3 Edit
 - 2.1.4 Error
- 2.2 Available Device Memory
 - 2.2.1 Device Memory Types
 - 2.2.2 Indirect Device Memory Designation
- 2.3 CSV Format Setting
(with Recipe or Sampling Macro Used)
 - 2.3.1 Applicable Macros
 - 2.3.2 Recipe
 - 2.3.3 Sampling

2.1 7Macro Editor

This section describes the usage of the macro editor.

2.1.1 Start and Quit

Start

How to start the macro editor varies depending on the location where a macro command is registered.

Screen


- OPEN macro
[Screen Setting] → [Open Macro]
- CLOSE macro
[Screen Setting] → [Close Macro]
- CYCLE macro
[Screen Setting] → [Cycle Macro]



Overlap library


Select [Home] → [Registration Item] → [Overlap Library] to show the overlap display where a macro is to be registered.

- OPEN macro
[Screen Setting] → [Open Macro]
- CLOSE macro
[Screen Setting] → [Close Macro]




Switch

- ON macro
[Macro] → [Macro to Edit: ON Macro] → [Edit]
- OFF macro
[Macro] → [Macro to Edit: OFF Macro] → [Edit]



Function switch

- ON macro
[Function Switch Setting] → [ON Macro] → [Edit]
- OFF macro
[Function Switch Setting] → [OFF Macro] → [Edit]



Macro block

[Home] → [Registration Item] → [Macro Block]


Specify the number of the macro block where macro commands are to be registered, and click [OK].



Macro mode

[Screen Setting] → [Macro]


- ON macro
[Macro Edit] → [ON Macro] → [Edit]
- OFF macro
[Macro Edit] → [OFF Macro] → [Edit]



Alarm macro

[Alarm Server] → [Alarm Device] → [Operation Setting] → [Macro]


- Occurrence macro
[Macro to Edit: Occurrence operation] → [Setting: Use Alarm macros] → [Edit]
- Resetting macro:
[Macro to Edit: Cancellation operation] → [Setting: Specify the macro block number] → [Edit]



Scheduler macro


[Scheduler] → [Action] → [Macro]

[Setting: Use Scheduler macros] → [Edit]



Quit


1. Select [File] → [Close], or click the close button in the upper right corner of the window.



2. When no error is detected, the macro editor ends normally. If detected, the following message appears. Select a countermeasure for the error, and quit the macro editor.




Example: When quitting by commenting out the error line



When the macro editor is opened again, the error line is changed to a comment in red with "(ERR)" appended to the beginning of the line.

2.1.2 Screen Composition


The macro editor window is configured as follows:



Menus


[File] menu

Close	Quits the macro editor.
Import	Reads text files.
Export	Saves the macro currently being edited to a text file.
Print Preview	Displays the printout image of the macro being edited.
Print Current Window	Prints the macro currently being edited.

[Edit]/right-click menu


Undo	Returns you to the previous state by canceling the effect of the most recently executed command.
Redo	Returns you to the state before [Undo] is executed.
Cut	Cuts the selected area and saves it to the clipboard.
Copy	Copies the selected area and saves it to the clipboard.
Paste	Pastes the data from the clipboard.
Delete	Deletes the selected area.
Select All	Selects all macros currently being edited.
Delete All	Deletes all macros currently being edited.
Find	Searches for characters in the macro currently being edited.
Replace	Searches for characters in the macro currently being edited and replaces them.
Jump to Next Line	Jumps to the specified line.
Set Comment	Converts the line selected in the macro editor window to a comment (with ";" as the first character).
Reset Comment	Resets the comment conversion selected in the macro editor window (deletes the first character ";" from the comment).
Edit Comment	Allows you to edit comments on macro blocks during macro block editing.

[View] menu



Tool Bar	Selects whether to show/hide the toolbar.
Support Dialog	Selects whether to show/hide the [Macro Editing Support] dialog. For more information on the dialog, refer to page 2-9.
Jump	Opens the macro editor window for the number specified in [Macro Block].
Previous Page	Opens the previous page.
Next Page	Opens the next page.
Skip to Non-registered Screen	Skips the non-registered screens at the time of screen change.
Character Size	Allows you to select the size of characters to be displayed in the macro editor.
Display Language	Allows you to select the language to be displayed in the macro editor.

Memory Setting Menu (Upside Display, Downside Display, Hide)	<p>Allows you to select the position where the memory setting pull-down menu appears in the macro editor.</p> <p>Example: [Downside Display] selected</p>
---	---

Placing the cursor at a memory address brings up this underneath the address.

Toolbar

Edit


Refer to “Menus” (page 2-6).

Comment List

	
Comment List	Jumps to the selected comment line.

Macro Editing Support

To go to this dialog, select [Support Dialog] from the [View] menu.



Category	Macro category list
Command	The list of commands contained in the selected category
Setting items	Setting items required for the selected command
Inserted Comment	Comments can be registered together with commands.
UP/DW	Moves the selected line.
Overwrite	Overwrites the selected line with the contents of [Preview].
Insert	Inserts the contents of [Preview] into the position above the selected line.
Explanation	Explains the command selected from the list.
Preview	Displays the preview of macro editing.

2.1.3 Edit

You can utilize the macro editor in several editing manners. Choose a desired one.

1: Command Entry

Editing is performed with the command list. This method is useful when you know the names of particular commands. (Refer to page 2-10.)

2: Direct Entry

Editing is performed by entering text through the keyboard of your computer. (Refer to page 2-12.)


3: Macro Editing Support

Editing is performed in the dialog that provides the explanation of individual commands. This method is best suited to beginners. (Refer to page 2-14.)

4: Text Entry

Editing is performed with a text editor (commercially available). Macro programming is enabled even in an environment without the editor. (Refer to page 2-16.)


For mnemonic codes, you can indent commands by using a tab key or a space key.



1: Command Entry

New registration


1. Select a line using the [UP] / [DW] button.
2. Enter a command. The command list appears.




3. Choose the desired command from the list and double-click it. Alternatively, choose the desired command using the [↑] / [↓] key on the keyboard and press the Enter key.



- The [Device Setting] dialog appears. Make necessary settings, such as the address and data length, in the dialog, and click the [Finish] or [x] button.




- The line has been registered. To proceed with the next line registration, go back to step 1.



Device memory change

Device memory addresses (corresponding to [F0] / [F1] / [F2] / [F3]) are colored green. Follow the steps below when you wish to change any addresses:

- Select the desired memory address in green with the cursor. The device memory setting menu is displayed. Change the address as necessary.



- Select the desired device memory address in green with the cursor, and type an address change through your computer keyboard.


Command change

Choose the line you wish to change. Delete the line and register a new line.


2: Direct Entry

New registration

1. Select a line using the [UP] / [DW] button.
2. Enter mnemonic codes through the keyboard.
Example: MOV command
PLC1 [D200] = \$u100 (W)
* For designating memory, refer to page 2-19.




3. Press the Enter key to go to the next line. To proceed with the next line registration, go back to step 1.



Memory change

Memory addresses (corresponding to [F0] / [F1] / [F2] / [F3]) are colored green. Follow the steps below when you wish to change any memory addresses:

- Select the desired memory address in green with the cursor. The memory setting menu is displayed. Change the address as necessary.



- Select the desired memory address in green with the cursor, and type an address change through the keyboard.


Command change

Choose the line you wish to change. Delete the line and register a new line.


3: Macro Editing Support

New registration

1. Select a line using the [UP] / [DW] button.
2. Select the desired command from the pull-down menu and the macro list.



3. The setting items required for the selected command are displayed. Specify the address, data length, etc.




4. The settings made are displayed under [Preview].



5. If you wish to make a comment, enter it in the comment entry box.
6. To overwrite the selected line, press the [Overwrite] button. To insert a line into the position above the selected line, press the [Insert] button.
7. The line has been registered. To proceed with the next line registration, go back to step 1.

Device memory change

1. Select the line to be modified. The command and the values specified for the line are displayed in the [Macro Editing Support] dialog.




2. Change the device memory addresses as desired and click the [Overwrite] button. Clicking the [Insert] button inserts the changed setting into the position above the selected line.

4: Text Entry

The macro editor is capable of importing and exporting text files. Even if the editor is not installed on your computer, macros can be created with commercially available software.

Export

1. From the [File] menu, select [Export]. The [Save As] dialog is displayed.




2. Enter a file name and click [Save]. A text file is created under the name.


Text editing

Editing on Notepad

1. Open the text file on Notepad.




2. Select a line using the [UP] / [DW] button.
3. Enter mnemonic codes through the keyboard.
Example: Addition command
\$u1000 = \$u200 + \$u300 (W)
* For designating memory, refer to page 2-19.




4. Save the file.

Import

1. Open the edit sheet, to which a text file will be imported.
2. From the [File] menu, select [Import]. The [Open] dialog is displayed.




3. Select the desired file and click [Open]. The text file is imported.




2.1.4 Error


1. If the registered lines of a macro have any errors, error messages are displayed.



2. Double-clicking an error message selects the corresponding line.



3. Correct the error as needed in the message. Once finished, the message disappears.



2.2 Available Device Memory

2.2.1 Device Memory Types

The following device memory types can be used with macros:

Device Memory		Setting Range	Remarks	
Internal device memory	\$u	\$u00000 - \$u65535		
	\$s	\$s0000 - \$s2047		
	\$L	Depends on the setting *1		
	\$LD	Depends on the setting *1		
	\$T	\$T0000 - \$T1023		
	\$P n : *2	\$Pn:000 - \$Pn:511		
	\$M	\$M0000 - \$M2047		
	\$MC	\$MC0000 - \$MC2047		
	\$C	\$C0000 - \$C4095		
	\$R *3	\$R00000 - \$R65535		
	Indirect device memory designation	For more information, refer to page 2-20.	\$u/\$T/\$M only usable	
Memory card	[File No.: Record No.] #address	[0:0] #0000 - [15:4094] #4095		
PLCn device memory	PLC n [xxxx] *2*4	(Example) PLC1 [D100]	1:1 communication	
	PLCn [Port number: xxxx] *2*4	(Example) PLC1 [1:D100]	1:n communication	
Constant	DEC	WORD	0U - 65535U	Add "U" to the extreme right position.
		DWORD	0U - 4294967295U	
	DEC-	WORD	-32768 - 32767	
		DWORD	-2147483648 - 2147483647	
	OCT	WORD	0o - 177777o	Add "o" to the extreme right position. (lower-case "o")
		DWORD	0o - 3777777777o	
	HEX	WORD	0000H - FFFFH	Add "H" to the extreme right position.
		DWORD	00000000H - FFFFFFFFH	
FLOAT	DWORD	-3.402823E+38 - -1.401298E-45 0 1.401298E-45 - 3.402823E+38		

*1 The available range varies depending on the settings set on the [SRAM/Clock Setting] dialog.

*2 For "n", set the number of the connected device (1 to 8).

*3 [Allow use of recipe temporary device memory \$R] under [System Setting] → [Unit Setting] → [General Setting] must be checked. \$R is used in the recipe function.

*4 The designation of [xxxx] varies depending on the type of the connected device. For more information, refer to the available device memory list in the V9 Series Connection Manual.

2.2.2 Indirect Device Memory Designation

Each device memory address can be indirectly designated.
 The designation procedure varies depending on the device memory type and addresses.

Internal Device Memory, PLC (1 - 8) Device Memory

- Addresses 0 - 65535:

	15 MSB	8 7	LSB	0
n+0	Model		Device memory type	
n+1	Device memory No. (address)			
n+2	Expansion code		Bit designation	
n+3	00		Station number	

- Addresses 65536 and above:

	15 MSB	8 7	LSB	0
n+0	Model		Device memory type	
n+1	Device memory No. (address) lower-order			
n+2	Device memory No. (address) higher-order			
n+3	Expansion code		Bit designation	
n+4	00		Station number	

- Model, device memory type (hexadecimal)

Device memory		Model	Device memory type	
Internal device memory	\$u	00	00	
	\$s		01	
	\$L	0 - 65535	00	02
		65536 -		
	\$LD	0 - 65535	00	03
		65536 -		
	\$T	00	04	
	\$Pn ^{*1}	00	05	
	\$M	00	06	
	\$MC	00	07	
\$C	00	08		
\$R	00	09		
PLC1 device memory	0 - 65535	01/11 ^{*2}	The device memory type depends on the device memory used. Refer to the V9 Series Connection Manual or the PLC Connection Manual and set the type number of the device memory.	
	65536 -	81/91 ^{*2}		
PLC2 device memory	0 - 65535	03/12 ^{*2}		
	65536 -	83/92 ^{*2}		
PLC3 device memory	0 - 65535	13		
	65536 -	93		
PLC4 device memory	0 - 65535	14		
	65536 -	94		
PLC5 device memory	0 - 65535	15		
	65536 -	95		
PLC6 device memory	0 - 65535	16		
	65536 -	96		
PLC7 device memory	0 - 65535	17		
	65536 -	97		
PLC8 device memory	0 - 65535	18		
	65536 -	98		

*1 "n" treated as an expansion code

*2 The memory will work when specified with either model.

- Expansion code
An expansion code should be designated, depending on the type of memory in use. For more information, refer to the description of indirect device memory designation relevant to the target device memory type in the V9 Series Connection Manual.

Ex.: Mitsubishi Electric SPU device memory

Unit No. 0: 00

Unit No. 1: 01

- Station number
 - 1 : 1 or multi-link: Not used
 - 1 : n (multi-drop): Set the station number of the connected device.

Memory card

	15	MSB	8	7	LSB	0
n+0	02H		File No.			
n+1	Word address in the record					
n+2	Record No.					

- File number, word address in the record, record number
Refer to the memory card map in the V9 Series Memory Card Mode Conversion Manual.

Example

- When accessing a word in the PLCn memory, "0" is specified for the "n + 2" word even in the case of device memory that does not use an expansion code.

Ex.: Accessing D165 in a Mitsubishi PLC (PLC1)

(Macro)

\$u100 = 0100H (W) Model: 01 (PLC1 memory) Memory type: 00

\$u101 = 0165 (W) Device memory No.: 165

\$u102 = 0000 (W) Expansion code: None

\$u200 = *\$u100 (W)

(Result of execution)

Data at D165 is transferred to \$u200.

- When accessing the bit-writable device memory, such as the Mitsubishi M Relay, the following setting is necessary.

Device memory number = M (address)/16

Ex.: Accessing M20

(Macro)

\$u100 = 0106H (W) Model: 01 (PLC1 device memory) Device memory type: 06

\$u101 = 0001H (W) Device memory No. = 20 ÷ 16 = 1...4

\$u102 = 0004H (W) Expansion code: None Bit designation: 4

*\$u100 (ON)

(Result of execution)

The bit of M20 is set (ON).

2.3 CSV Format Setting (with Recipe or Sampling Macro Used)

Format settings are required for handling CSV files. Register data formats of CSV files in [Format Setting]. MONITOUCH will read/write the CSV files in accordance with these format settings.


2.3.1 Applicable Macros

Function	Macro	CSV File Name	Setting Location	Refer to:
Recipe	LD_RECIPE	RECxxxx.CSV 0000 - 9999 (Designation of a number)	[Recipe] → [File Format]	page 4-169
	LD_RECIPE2			page 4-172
	LD_RECIPESSEL			page 4-174
	LD_RECIPESSEL2			page 4-177
	SV_RECIPE			page 4-181
	SV_RECIPE2			page 4-183
	SV_RECIPESSEL			page 4-185
	SV_RECIPESSEL2			page 4-188
	RD_RECIPE_FILE	xxxxxxx.CSV 8 one-byte upper-case alphanumeric characters or less (Designation of a name)		page 4-192
	RD_RECIPE_LINE			page 4-194
	RD_RECIPE_COLUMN			page 4-197
	WR_RECIPE_FILE			page 4-200
	WR_RECIPE_LINE			page 4-202
	WR_RECIPE_COLUMN			page 4-204
Sampling	SMPL_CSV	xxxxxxx.CSV Designation of a file name by the editor	<ul style="list-style-type: none"> Alarm server [Alarm Block] → [Format Setting] Logging Server [Logging Block] → [Format Setting] 	page 4-210
	SMPL_CSV2	xxxxxxx.CSV Designation of a file name by the device memory		page 4-213
	SMPLCSV_BAK	xxxxxxx_YYYYMMDDHHMMSS.CSV Designation of a file name by the editor After _: Output time in year, month, day, hour, minute, and second		page 4-218
	SMPLCSV_BAK2	xxxxxxx_YYYYMMDDHHMMSS.CSV Designation of a file name by the device memory After _: Output time in year, month, day, hour, minute, and second		page 4-221


2.3.2 Recipe

Setting procedure


1. Select [System Setting] → [Recipe], and specify a recipe number. The [Recipe Edit] window is displayed.



2. In the [File Format] tab window, set and change settings of the selected recipe number.



Setting details



Format Setting	Line/Column Contents	<p>Select an option according to the CSV file.</p> <ul style="list-style-type: none"> [Line: Record, Column: Data] <p>CSV file</p> <table style="margin-left: auto; margin-right: auto;"> <tr> <td></td> <td></td> <td style="text-align: center;">DEC</td> <td style="text-align: center;">CHAR</td> <td style="text-align: center;">DEC</td> </tr> <tr> <td></td> <td></td> <td style="text-align: center;">↓</td> <td style="text-align: center;">↓</td> <td style="text-align: center;">↓</td> </tr> <tr> <td style="text-align: right;">Record</td> <td style="border: 1px solid blue; padding: 2px;">Line A</td> <td style="border: 1px solid orange; padding: 2px;">1</td> <td style="border: 1px solid orange; padding: 2px;">A</td> <td style="border: 1px solid orange; padding: 2px;">100</td> </tr> <tr> <td></td> <td style="border: 1px solid blue; padding: 2px;">Line B</td> <td style="border: 1px solid orange; padding: 2px;">2</td> <td style="border: 1px solid orange; padding: 2px;">B</td> <td style="border: 1px solid orange; padding: 2px;">200</td> </tr> <tr> <td></td> <td style="border: 1px solid blue; padding: 2px;">Line C</td> <td style="border: 1px solid orange; padding: 2px;">3</td> <td style="border: 1px solid orange; padding: 2px;">C</td> <td style="border: 1px solid orange; padding: 2px;">300</td> </tr> <tr> <td></td> <td style="border: 1px solid blue; padding: 2px;">Line D</td> <td style="border: 1px solid orange; padding: 2px;">4</td> <td style="border: 1px solid orange; padding: 2px;">D</td> <td style="border: 1px solid orange; padding: 2px;">400</td> </tr> <tr> <td></td> <td></td> <td style="text-align: center;">Data</td> <td></td> <td></td> </tr> </table> <ul style="list-style-type: none"> [Line: Data, Column: Record] <p>CSV file</p> <table style="margin-left: auto; margin-right: auto;"> <tr> <td></td> <td style="text-align: center;">Record</td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td style="border: 1px solid blue; padding: 2px;">Line A</td> <td style="border: 1px solid orange; padding: 2px;">Line B</td> <td style="border: 1px solid orange; padding: 2px;">Line C</td> <td style="border: 1px solid orange; padding: 2px;">Line D</td> <td></td> </tr> <tr> <td style="text-align: right;">DEC →</td> <td style="border: 1px solid blue; padding: 2px;">1</td> <td style="border: 1px solid orange; padding: 2px;">2</td> <td style="border: 1px solid orange; padding: 2px;">3</td> <td style="border: 1px solid orange; padding: 2px;">4</td> <td style="text-align: left;">Data</td> </tr> <tr> <td style="text-align: right;">CHAR →</td> <td style="border: 1px solid blue; padding: 2px;">A</td> <td style="border: 1px solid orange; padding: 2px;">B</td> <td style="border: 1px solid orange; padding: 2px;">C</td> <td style="border: 1px solid orange; padding: 2px;">D</td> <td></td> </tr> <tr> <td style="text-align: right;">DEC →</td> <td style="border: 1px solid blue; padding: 2px;">100</td> <td style="border: 1px solid orange; padding: 2px;">200</td> <td style="border: 1px solid orange; padding: 2px;">300</td> <td style="border: 1px solid orange; padding: 2px;">400</td> <td></td> </tr> </table> <p>Lines are in the same format.</p>			DEC	CHAR	DEC			↓	↓	↓	Record	Line A	1	A	100		Line B	2	B	200		Line C	3	C	300		Line D	4	D	400			Data				Record						Line A	Line B	Line C	Line D		DEC →	1	2	3	4	Data	CHAR →	A	B	C	D		DEC →	100	200	300	400	
		DEC	CHAR	DEC																																																															
		↓	↓	↓																																																															
Record	Line A	1	A	100																																																															
	Line B	2	B	200																																																															
	Line C	3	C	300																																																															
	Line D	4	D	400																																																															
		Data																																																																	
	Record																																																																		
	Line A	Line B	Line C	Line D																																																															
DEC →	1	2	3	4	Data																																																														
CHAR →	A	B	C	D																																																															
DEC →	100	200	300	400																																																															

Format Setting	Add record name *1	<p>Set how to treat the first column in the CSV file.</p> <ul style="list-style-type: none"> • Unchecked The first column in the CSV file is treated as data. <p>CSV file</p> <table border="1"> <tr><td>6000</td><td>15</td><td>200</td><td></td></tr> <tr><td>6100</td><td>15</td><td>201</td><td></td></tr> <tr><td>6200</td><td>20</td><td>202</td><td></td></tr> <tr><td>6300</td><td>20</td><td>203</td><td></td></tr> <tr><td></td><td></td><td></td><td></td></tr> </table> <p>Display on MONITOUCH</p> <table border="1"> <tr><td>..\</td><td>#1</td><td>#2</td><td>#3</td></tr> <tr><td>#1</td><td>6000</td><td>15</td><td>200</td></tr> <tr><td>#2</td><td>6100</td><td>15</td><td>201</td></tr> <tr><td>#3</td><td>6200</td><td>20</td><td>202</td></tr> <tr><td>#4</td><td>6300</td><td>20</td><td>203</td></tr> </table> <ul style="list-style-type: none"> • Checked The first column in the CSV file is treated as a record name. <p>CSV file</p> <table border="1"> <tr><td>ITEM1</td><td>6000</td><td>15</td><td>200</td></tr> <tr><td>ITEM2</td><td>6100</td><td>15</td><td>201</td></tr> <tr><td>ITEM3</td><td>6200</td><td>20</td><td>202</td></tr> <tr><td>ITEM4</td><td>6300</td><td>20</td><td>203</td></tr> <tr><td></td><td></td><td></td><td></td></tr> </table> <p>Display on MONITOUCH</p> <table border="1"> <tr><td>..\</td><td>#1</td><td>#2</td><td>#3</td></tr> <tr><td>ITEM1</td><td>6000</td><td>15</td><td>200</td></tr> <tr><td>ITEM2</td><td>6100</td><td>15</td><td>201</td></tr> <tr><td>ITEM3</td><td>6200</td><td>20</td><td>202</td></tr> <tr><td>ITEM4</td><td>6300</td><td>20</td><td>203</td></tr> </table>	6000	15	200		6100	15	201		6200	20	202		6300	20	203						..\	#1	#2	#3	#1	6000	15	200	#2	6100	15	201	#3	6200	20	202	#4	6300	20	203	ITEM1	6000	15	200	ITEM2	6100	15	201	ITEM3	6200	20	202	ITEM4	6300	20	203					..\	#1	#2	#3	ITEM1	6000	15	200	ITEM2	6100	15	201	ITEM3	6200	20	202	ITEM4	6300	20	203
	6000	15	200																																																																															
	6100	15	201																																																																															
	6200	20	202																																																																															
6300	20	203																																																																																
..\	#1	#2	#3																																																																															
#1	6000	15	200																																																																															
#2	6100	15	201																																																																															
#3	6200	20	202																																																																															
#4	6300	20	203																																																																															
ITEM1	6000	15	200																																																																															
ITEM2	6100	15	201																																																																															
ITEM3	6200	20	202																																																																															
ITEM4	6300	20	203																																																																															
..\	#1	#2	#3																																																																															
ITEM1	6000	15	200																																																																															
ITEM2	6100	15	201																																																																															
ITEM3	6200	20	202																																																																															
ITEM4	6300	20	203																																																																															
Add title to data *1	<p>Set how to treat the first line in the CSV file.</p> <ul style="list-style-type: none"> • Unchecked The first line in the CSV file is treated as data. <p>CSV file</p> <table border="1"> <tr><td>6000</td><td>15</td><td>200</td><td></td></tr> <tr><td>6100</td><td>15</td><td>201</td><td></td></tr> <tr><td>6200</td><td>20</td><td>202</td><td></td></tr> <tr><td>6300</td><td>20</td><td>203</td><td></td></tr> <tr><td></td><td></td><td></td><td></td></tr> </table> <p>Display on MONITOUCH</p> <table border="1"> <tr><td>..\</td><td>#1</td><td>#2</td><td>#3</td></tr> <tr><td>#1</td><td>6000</td><td>15</td><td>200</td></tr> <tr><td>#2</td><td>6100</td><td>15</td><td>201</td></tr> <tr><td>#3</td><td>6200</td><td>20</td><td>202</td></tr> <tr><td>#4</td><td>6300</td><td>20</td><td>203</td></tr> </table> <ul style="list-style-type: none"> • Checked The first line in the CSV file is treated as title. <p>CSV file</p> <table border="1"> <tr><td>Title1</td><td>Title2</td><td>Title3</td><td></td></tr> <tr><td>6000</td><td>15</td><td>200</td><td></td></tr> <tr><td>6100</td><td>15</td><td>201</td><td></td></tr> <tr><td>6200</td><td>20</td><td>202</td><td></td></tr> <tr><td>6300</td><td>20</td><td>203</td><td></td></tr> </table> <p>Display on MONITOUCH</p> <table border="1"> <tr><td>..\</td><td>Title1</td><td>Title2</td><td>Title3</td></tr> <tr><td>#1</td><td>6000</td><td>15</td><td>200</td></tr> <tr><td>#2</td><td>6100</td><td>15</td><td>201</td></tr> <tr><td>#3</td><td>6200</td><td>20</td><td>202</td></tr> <tr><td>#4</td><td>6300</td><td>20</td><td>203</td></tr> </table>	6000	15	200		6100	15	201		6200	20	202		6300	20	203						..\	#1	#2	#3	#1	6000	15	200	#2	6100	15	201	#3	6200	20	202	#4	6300	20	203	Title1	Title2	Title3		6000	15	200		6100	15	201		6200	20	202		6300	20	203		..\	Title1	Title2	Title3	#1	6000	15	200	#2	6100	15	201	#3	6200	20	202	#4	6300	20	203	
6000	15	200																																																																																
6100	15	201																																																																																
6200	20	202																																																																																
6300	20	203																																																																																
..\	#1	#2	#3																																																																															
#1	6000	15	200																																																																															
#2	6100	15	201																																																																															
#3	6200	20	202																																																																															
#4	6300	20	203																																																																															
Title1	Title2	Title3																																																																																
6000	15	200																																																																																
6100	15	201																																																																																
6200	20	202																																																																																
6300	20	203																																																																																
..\	Title1	Title2	Title3																																																																															
#1	6000	15	200																																																																															
#2	6100	15	201																																																																															
#3	6200	20	202																																																																															
#4	6300	20	203																																																																															
Delimiter	<p>Select a delimiter used in the CSV file. , (comma) / <tab> (tab) / . (period) * When "." (period) is selected, a comma is used for a decimal point.</p>																																																																																	
Number of Records	<p>Set this option when transferring data on a file-by-file basis. Specify the number of records to contain in one file.</p>																																																																																	
Number of Data (1 - 4096)	<p>Specify the number of data to contain in one record. * The column of record names is not counted.</p>																																																																																	
Occupied Words (1 - 65535)	<p>The number of words used is automatically calculated.</p> <ul style="list-style-type: none"> • When transferring data on a record-by-record basis: Total number of words in one record • When transferring data on a file-by-file basis: Total number of words in one file 																																																																																	

Format Setting	Data Type	<p>Specify the data format in the CSV file.</p> <ul style="list-style-type: none"> Record Name This option is enabled when [Add record name] is checked. Specify the number of characters and the order of text processing for a record name. 1 - Specify the data format. <ul style="list-style-type: none"> Data Type: DEC, DEC-, HEX, OCT, BIN, CHAR, BCD, FLOAT Data Length: 1-Word, 2-Word Decimal Point: 0 - 32 Characters: 2 - 255 Text Process: LSB → MSB, MSB → LSB
Transfer Device Setting	Transfer Target	<p>This option is enabled when [Add record name] is checked.</p> <ul style="list-style-type: none"> [Data] Only data is transferred. [Record Name + Data] Both record name and data are transferred.

*1 When both title and record name are used:

CSV file


-	Title1	Title2	Title3
ITEM1	6000	15	200
ITEM2	6100	15	201
ITEM3	6200	20	202
ITEM4	6300	20	203

Display on MONITOUCH

..\	Title1	Title2	Title3
ITEM1	6000	15	200
ITEM2	6100	15	201
ITEM3	6200	20	202
ITEM4	6300	20	203

V8-compatible settings

When using a recipe macro, the following settings are necessary:



Individual Setting	Recipe File No.	Specify a number when using a LD_RECIPE, LD_RECIPESL, SV_RECIPE, or SV_RECIPESL macro. Set the CSV file number (REC0000.CSV to REC9999.CSV) that corresponds to the format of the recipe setting. Location of the CSV file Storage \ (access folder) \ RECIPE folder
	Group Folder Name (8 one-byte upper-case alphanumeric characters or less)	Set a group folder name when executing a recipe macro by randomly specifying CSV file names. <ul style="list-style-type: none"> [Add] Creates a group folder in which CSV files are to be stored. The folder name can be changed as desired. [Delete] Deletes a group folder. * All CSV files contained in the group folder use the same format settings.
Common Setting	Default Recipe No.	This is common to all recipe settings. Format settings of the default recipe number take effect in the following cases: <ul style="list-style-type: none"> There is no recipe setting that corresponds to the file named "RECxxx.csv". A group folder that does not exist in the recipe setting is added to the storage via Explore. [System Setting] → [Unit Setting] → [General Setting] → [Allow max. 8 characters for naming files used in V8 recipe mode (V8 compatible)] is not checked.


- Relationship between the recipe setting and the CSV file

- Recipe setting

Recipe No.	Group Folders
Recipe [0]	NORMAL TARGET TEST
Recipe [1]	

Default Recipe No. 1 = Recipe [1]


- Storage



CSV File Name and Storage Target

Depending on the name of a CSV file, its location and file designation vary. Create a file according to your purpose.

File name	Store target
RECxxx.CSV 0000 - 9999	Access folder\RECIPE\ See the following:
xxxxxxx.CSV 8 one-byte upper-case alphanumeric characters or less	Access folder\RECIPE\ <u>(group folder)</u> 8 one-byte upper-case alphanumeric characters or less See the following:



* Group folders are defined in [Format Setting] → [V8 Compatible Setting]. They are automatically created when MONITOUCH recognizes the storage.

Total Number of CSV Files


There is a limitation on the number of group folders and CSV files that can be handled in the recipe mode.

- The total of group folders and CSV files in the RECIPE folder: 1,024 maximum
- The number of CSV files in a group folder: 1,024 maximum

Any more folders and files than 1,024 are not recognized in the recipe mode.

- * When access to CSV files is made by a macro command, this limitation is not imposed.

The time for accessing increases proportionately with the number of files.



Data in CSV File

- The number of words to be transferred
A maximum of 65536 words can be read and written at one time in recipe mode or a macro. If you attempt to transfer data exceeding capacity, 65536 words are transferred, but extra words will not be transferred.
- Lines and columns
The number of lines/columns to be handled varies, depending on the format setting.

	Line: Record, Column: Data	Line: Data, Column: Record
Number of lines	1 - 32767	1 - 4096 ^{*3}
Number of columns ^{*1}	1 - 4096 ^{*2}	1 - 4096

*1 Excel is capable of handling a maximum of 256 columns.
 *2 The maximum number of words per column: 4,096 words
 *3 The maximum number of words per line: 4,096 words
 *4 File size: 1 MB or less


- Number of bytes for record
64 bytes maximum per record
* This setting can be made in [Format Setting].
- Number of bytes for a title name
64 bytes maximum per title

2.3.3 Sampling

Alarm Server


Setting procedure

1. Select [Alarm Server] → [Alarm Block].
The [Alarm Block] window is displayed.
2. In the [Form Setting] tab window, double-click on the block number to be output in CSV format. The [Format] dialog appears.



Setting details

- [Alarm]



Specify a title	Specify a title to be added to the header in the CSV file.
History Display	Set the display order of alarm history.
Calendar Condition	Select a format of date display to be output in the CSV file.
Display the primary cause only	Only error messages of primary causes are output in the CSV file.
Add a (*) mark to the primary cause	Primary cause messages are output with (*) marks appended in the CSV file.

- [Event]

The screenshot shows a dialog box titled 'Format[0]'. It has the following fields and controls:


- Type: Event (dropdown)
- File Name: ALAFM_00_00 (text input)
- Output Language: No Designation (dropdown)
- Display: (V8 Format)
- Specify a title: GN. 127 /127 No. 0 /255 (with Edit... button)
- Calendar Condition: Data and Time (dropdown) with Date/Time Display Format Setting... button
- Output Information: ON-OFF (dropdown)
- Activate Status Display
- Buttons: Complete, Cancel

Specify a title	Specify a title to be added to the header in the CSV file.
Calendar Condition	Check this box to output the date in the CSV file.
Output Information	Select a status to output.
Activate Status Display	Select a format of status display to be output in the CSV file.


Logging Server

Setting procedure

1. Select [Logging Server] → [Logging Block].
The [Logging Block] window is displayed.
2. In the [Form Setting] tab window, double-click on the block number to be output in CSV format. The [Format] dialog appears.



Setting details




Specify a title	Specify a title to be added to the header in the CSV file.
Calendar Condition	Select a format of date display to be output in the CSV file.
Display in msec	Check this box to output the time data in the unit of msec in the CSV file.

CSV File Name and Storage Target

For “SMPL_CSV”

File Name	Storage Target
(User-specified name).CSV * A maximum of 64 one-byte characters can be used as a user-specified name.	<ul style="list-style-type: none"> Alarm server (access folder)\ALARM\ Logging Server (access folder)\LOGGING\


Example: Alarm server



For "SMPLCSV_BAK/SMPLCSV_BAK2"

File Name	Storage Target
<p>(User-specified name)_YYYYMMDDHHMMSS.CSV</p> <p style="text-align: center;"> Output time in year, month, day, hour, minute, and second </p> <p>* A maximum of 64 one-byte characters can be used as a user-specified name.</p>	<ul style="list-style-type: none"> Alarm server (access folder)\ALARM\year/month folder)\(year/month/day folder) Logging Server (access folder)\LOGGING\year/month folder)\(year/month/day folder)

Example: Alarm server



3 Command

3.1 Macro Command List

3.1 Macro Command List

Category	Command Name	Mnemonic	Contents	Refer to
Arithmetical Operation	ADD(+)	F0 = F1 + F2 (W) F0 = F1 + F2 (D)	Addition	page 4-2
	SUB(-)	F0 = F1 - F2 (W) F0 = F1 - F2 (D)	Subtraction	page 4-4
	MUL(X)	F0 = F1 F2 (W) F0 = F1 F2 (D)	Multiplication	page 4-6
	DIV(/)	F0 = F1 / F2 (W) F0 = F1 / F2 (D)	Division	page 4-8
	MOD(%)	F0 = F1 % F2 (W) F0 = F1 % F2 (D)	Remainder of division	page 4-9
Logical Operation	AND(&)	F0 = F1 & F2 (W) F0 = F1 & F2 (D)	Logical product	page 4-10
	OR()	F0 = F1 F2 (W) F0 = F1 F2 (D)	Logical add	page 4-11
	XOR(^)	F0 = F1 ^ F2 (W) F0 = F1 ^ F2 (D)	Exclusive OR	page 4-12
	SHL(<<)	F0 = F1 << F2 (W) F0 = F1 << F2 (D)	Left shift	page 4-13
	SHR(>>)	F0 = F1 >> F2 (W) F0 = F1 >> F2 (D)	Right shift	page 4-14
Statistic	MAX	F0 = MAX (F1 C:F2) (W) F0 = MAX (F1 C:F2) (D)	Maximum	page 4-15
	MIN	F0 = MIN (F1 C:F2) (W) F0 = MIN (F1 C:F2) (D)	Minimum	page 4-16
	AVG	F0 = AVG (F1 C:F2) (W) F0 = AVG (F1 C:F2) (D)	Average	page 4-17
	SUM	F0 = SUM (F1 C:F2) (W) F0 = SUM (F1 C:F2) (D)	Sum	page 4-18
Mathematics/ trigonometric	EXP	F0 = EXP (F1) (F)	Exponent	page 4-19
	EXPT	F0 = EXPT (F1,F2) (F)	Powers	page 4-20
	LN	F0 = LN (F1) (F)	Natural logarithms	page 4-21
	LOG	F0 = LOG (F1) (F)	Common logarithms	page 4-22
	SQRT	F0 = SQRT (F1) (F)	Square roots	page 4-23
	ABS	F0 = ABS (F1) (W) F0 = ABS (F1) (D) F0 = ABS (F1) (F)	Absolute value	page 4-24
	NEG	F0 = NEG (F1) (W) F0 = NEG (F1) (D) F0 = NEG (F1) (F)	Sign inversion	page 4-25
	SIN	F0 = SIN (F1) (F)	Sine	page 4-26
	COS	F0 = COS (F1) (F)	Cosine	page 4-27
	TAN	F0 = TAN (F1) (F)	Tangent	page 4-28
	ASIN	F0 = ASIN (F1) (F)	Arcsine	page 4-29
	ACOS	F0 = ACOS (F1) (F)	Arccosine	page 4-30
	ATAN	F0 = ATAN (F1) (F)	Arctangent	page 4-31
	DEG	F0 = DEG (F1) (F)	Convert radians → degrees	page 4-32
RAD	F0 = RAD (F1) (F)	Convert degrees → radians	page 4-33	

Category	Command Name	Mnemonic	Contents	Refer to
Bit Operation	BSET	F0 (ON)	Bit set (ON)	page 4-34
	BCLR	F0 (OFF)	Bit reset (OFF)	page 4-35
	BINV	F0 (INV)	Bit inversion	page 4-36
Conversion	BCD	F0 = F1 BCD (W) F0 = F1 BCD (D)	Conversion to BCD	page 4-37
	BIN	F0 = F1 BIN (W) F0 = F1 BIN (D)	Conversion to BIN	page 4-38
	CWD	F0 = F1 D <- W	Convert one-word → double-word	page 4-39
	CVP	F0 = F1 PLC <- (W) F0 = F1 PLC <- (D)	Convert DEC → PLC1	page 4-40
	CVPFMT	F0 = F1 (W) PLC F2 <- F0 = F1 (D) PLC F2 <-	Convert DEC → PLCn	page 4-41
	CVB	F0 = F1 (W) <- PLC F0 = F1 (D) <- PLC	Convert PLC1 → DEC	page 4-42
	CVBFMT	F0 = F1 (W) <- PLC F2 F0 = F1 (D) <- PLC F2	Convert PLCn → DEC	page 4-43
	SWAP	F0 C:F1	Swap MSB with LSB	page 4-44
	CHR	F0 = ''	Convert text → code (PLC1 code fixed)	page 4-45
	STRING	F0 = '' (STRING)	Convert text → code	page 4-46
	CVFD	F0 (D) <- F1 (F) F2 (D)	Convert real number → BIN	page 4-47
	CVDF	F0 (F) <- F1 (D) F2 (D)	Convert BIN → real number	Page 4-49
	CLND_TO_GRE	CLND_TO_GRE F0 F1 F2	Convert calendar data → GMT-based UNIX time	page 4-51
	GRE_TO_CLND	GRE_TO_CLND F0 F1 F2	Convert GMT-based UNIX time → calendar data	page 4-53
	FORMAT_DATA	FORMAT_DATA F0 F1 F2	Convert string → numerical data	page 4-55
FORMAT_STR	FORMAT_STR F0 F1 F2	Convert numerical data → string	page 4-59	
Transfer	MOV	F0 = F1 (W) F0 = F1 (D)	Transfer	page 4-63
	BMOV	F0 = F1 C:F2 (BMOV) (W) F0 = F1 C:F2 (BMOV) (D)	Block transfer	page 4-64
	CVMOV	F0 = F1 C:F2 (CVMOV) (W) F0 = F1 C:F2 (CVMOV) (D)	(With data conversion) Block transfer	page 4-66
	CVSMOV	F0 = F1 C:F2 (CVSMOV) (W) F0 = F1 C:F2 (CVSMOV) (D)	(With text conversion) Block transfer	page 4-69
	FILL	F0 = F1 C:F2 (FILL)	Transfer all	page 4-71

Category	Command Name	Mnemonic	Contents	Refer to
Comparison	CMP	IF (F0 = F1)F2 (W) IF (F0 = F1)F2 (D)	Comparison	page 4-72
	TST	IFZ (F0 & F1) F2 (W) IFZ (F0 & F1) F2 (D)	Logical product comparison	page 4-74
	IF ELSE ENDIF	IF (F0 (condition) F1) (W) IF (F0 (condition) F1) (D) IF ((condition) F0) (B) ELSE ENDIF	Conditional branch	page 4-75
Macro Operation Control	CALL	CALL F0	Macro block call	page 4-77
	JMP	JMP F0	Jump	page 4-79
	LABEL	LB F0:	Label	page 4-80
	FOR/NEXT	FOR F0 / NEXT	Loop between FOR and NEXT	page 4-81
	RET	RET	Finish macro processing	page 4-83
	SWRET	SWRET	Execute switch function	page 4-84
	EN_INT	EN_INT	Interruption enabled	page 4-85
FROM Backup	FROM_WR	FROM_WR F0 F1	Write to FROM	page 4-86
	FROM_RD	FROM_RD F0 F1	Read from FROM	page 4-87
Printer	MR_OUT	MR_OUT F0	Execute MR400 call setting	page 4-88
	MR_REG	MR_REG F0	Execute MR400 registration setting	page 4-89
	OUT_PR	OUT_PR F0 F1	Execute printer command	page 4-91
Video	VIDEO	Video MEMORY F1	Memory use	page 4-93
		Video SIZE F1	Size	page 4-100
		Video SIZE F1 F2	Size (dot)	page 4-101
		Video SEL_CH F1	Channel	page 4-102
		Video BRIGHT F1	Brightness	page 4-103
		Video CONTRAST F1	Contrast	page 4-104
		Video COLOR F1	Color intensity	page 4-105
		Video INF F1	Save settings/reset to default	page 4-106

Category	Command Name	Mnemonic	Contents	Refer to
Video	VIDEO2	Video2 MEMORY F1	Memory use	page 4-107
		Video2 SNAP F1 F2	Snapshot	page 4-129
		Video2 SNAP F1 F2 (SIZE)	Snapshot (SIZE)	page 4-131
		Video2 STROBE F1 F2	Strobe snapshot	page 4-133
		Video2 RE_SIZE	Resize	page 4-135
		Video2 ZOOM F1 F2	Zoom	page 4-136
		Video2 BRIGHT F1 F2	Brightness	page 4-137
		Video2 CONTRAST F1 F2	Contrast	page 4-138
		Video2 COLOR F1 F2	Color intensity	page 4-139
		Video2 VIDEOINF F1 F2	Save settings/reset to default	page 4-140
		Video2 PAUSE F1	Pause playback	page 4-141
		Video2 RESTART F1	Pause cancel	page 4-142
		Video2 DELETE F1	Delete	page 4-143
		Video2 SNAP_SEQ F1 F2	Change continuous single snapshot	page 4-144
		Video2 CLIP_POS F1 F2 F3	Change the clip start position	page 4-146
Video2 CLIP_SIZE F1 F2 F3	Change the image clip size	page 4-147		
Video2 MODE F1 F2 F3	Change the operation mode	page 4-148		
PLC	PLC_CLND	PLC_CLND F0 PLC F1 F2 F3	Calendar control for PLCn	page 4-149
	PLC_CTL	PLC_CTRL PLC F0 F1 F2	PLCn control	page 4-151
	TBL_READ	TBL_READ F0 <- TABLE : PLC F1 : F2	Read from device memory map	page 4-153
	TBL_WRITE	TBL_WRITE TABLE : PLC F1 : F0 <- F2	Write to device memory map	page 4-154
Ethernet	SEND	SEND F0 C:F1 TO F2	Transfer on the network	page 4-155
	EREAD	EREAD F0 = F1 C:F2 F3	Read on the network	page 4-157
	EWRITE	EWRITE F0 F1 = F2 C:F3	Write on the network	page 4-158
MES	MES	MES CHECK F1 F2 F3	V-server start check	page 4-159
		MES WRITE F1 F2 F3	Add data to the database	page 4-169
		MES READ F1 F2 F3	Search the database	page 4-163
		MES DEL F1 F2 F3	Delete database records	page 4-165
		MES UPDATE F1 F2 F3	Update the database	page 4-167


Category	Command Name	Mnemonic	Contents	Refer to
Storage (Recipe)	LD_RECIPe	LD_RECIPe F0 F1	Read CSV file	page 4-169
	LD_RECIPe2	LD_RECIPe2 F0 F1 F2		page 4-172
	LD_RECIPeSEL	LD_RECIPeSEL F0 F1		page 4-174
	LD_RECIPeSEL2	LD_RECIPeSEL2 F0 F1 F2		page 4-177
	SV_RECIPe	SV_RECIPe F0 F1 F2	Save to CSV file	page 4-181
	SV_RECIPe2	SV_RECIPe2 F0 F1 F2 F3		page 4-183
	SV_RECIPeSEL	SV_RECIPeSEL F0 F1		page 4-185
	SV_RECIPeSEL2	SV_RECIPeSEL2 F0 F1 F2		page 4-188
	SET_RECIPeFOLDER	SET_RECIPeFOLDER F0	Folder designation	page 4-190
	RD_RECIPe_FILE	RD_RECIPe_FILE F0 F1	Read CSV file	page 4-192
	RD_RECIPe_LINE	RD_RECIPe_LINE F0 F1 F2 F3		page 4-194
	RD_RECIPe_COLUMN	RD_RECIPe_COLUMN F0 F1 F2 F3		page 4-197
	WR_RECIPe_FILE	WR_RECIPe_FILE F0 F1	Save to CSV file	page 4-200
	WR_RECIPe_LINE	WR_RECIPe_LINE F0 F1 F2 F3		page 4-202
WR_RECIPe_COLUMN	WR_RECIPe_COLUMN F0 F1 F2 F3	page 4-204		
GET_RECIPe_FILEINFO	GET_RECIPe_FILEINFO F0 F1 F2	CSV file information	page 4-206	
Storage (Sampling)	SMPL_BAK	SMPL_BAK F0	Save backup	page 4-208
	SMPL_CSV	SMPL_CSV F0	Create CSV file	page 4-210
	SMPL_CSV2	SMPL_CSV2 F0 F1	Create CSV file (file name designation)	page 4-213
	SMPL_SAVE	SMPL_SAVE	Save logging/alarm data stored in SRAM	page 4-216
	SMPLCSV_BAK	SMPLCSV_BAK F0	Save backup (CSV file)	page 4-218
	SMPLCSV_BAK2	SMPLCSV_BAK2 F0 F1	Save backup (CSV file, file name designation)	page 4-221
Storage (Others)	HDCOPY	HDCOPY	Hardcopy	page 4-223
	HDCOPY2	HDCOPY2 F0	Hardcopy	page 4-224
	HDCOPY3	HDCOPY3 F0	Hardcopy (file name designation)	page 4-226
	SET_DRIVE	SET_DRIVE F0	Select drive	page 4-228
	COPY_FILE	COPY_FILE F0 F1	Copy file	page 4-229
	MOVE_FILE	MOVE_FILE F0 F1 F2	Move file	page 4-231
	READ_FILE	READ_FILE F0 F1 F2 F3	Read universal file	page 4-233
	WRITE_FILE	WRITE_FILE F0 F1 F2	Write to universal file	page 4-235
Real No. Arithmetical Operation	F_ADD(+)	$F0 = F1 + F2 (F)$	Real number addition	page 4-237
	F_SUB(-)	$F0 = F1 - F2 (F)$	Real number subtraction	page 4-238
	F_MUL(X)	$F0 = F1 \times F2 (F)$	Real number multiplication	page 4-239
	F_DIV(/)	$F0 = F1 / F2 (F)$	Real number division	page 4-240

Category	Command Name	Mnemonic	Contents	Refer to	
Real No. Statistics	F_SUM	F0 = F_SUM (F1 C:F2) (F)	Sum of real number data	page 4-241	
	F_AVG	F0 = F_AVG (F1 C:F2) (F)	Average of real number data	page 4-242	
	F_MAX	F0 = F_MAX (F1 C:F2) (F)	Maximum of real number data	page 4-243	
	F_MIN	F0 = F_MIN (F1 C:F2) (F)	Minimum of real number data	page 4-244	
Others	;(Comment)	;	Comment	page 4-245	
	BRIGHT	BRIGHT F0	Brightness adjustment	page 4-246	
	GET_MSGBLK	GET_MSGBLK F0 F1	Message acquisition	page 4-247	
	PLC_ULR	PLC_ULR F0 F1	Read user log	page 4-248	
	RECONNECT	RECONNECT F0	Multi-drop reconnection (PLC1)	page 4-250	
	RECONNECT_EX	RECONNECT_EX PLC F0 F1	Restart	page 4-251	
	SAMPLE	SAMPLE F0 F1 F2	Acquire logging/alarm data	page 4-252	
	SEARCH_FILE	SEARCH_FILE F0 F1	Search for JPEG files	page 4-255	
	ADJ_VOLUME	ADJ_VOLUME F0 F1 F2	Adjust volume	page 4-256	
	SAVE_VOLUME	SAVE_VOLUME	Save volume adjustment value	page 4-257	
	TREND REFRESH	TREND REFRESH F0 F1	Refresh trend data display	page 4-258	
	SYS	SYS (SET_SCRN) F1	SYS (SET_SCRN) F1	Screen number designation	page 4-259
		SYS (SET_MOVLP) F1	SYS (SET_MOVLP) F1	Multi-overlap/global overlap setting	page 4-260
		SYS (OVLP_SHOW) F1	SYS (OVLP_SHOW) F1	Overlap ON/OFF	page 4-262
		SYS (OVLP_POS) F1	SYS (OVLP_POS) F1	Overlap relocation	page 4-263
		SYS (GET_MSG) F1	SYS (GET_MSG) F1	Message acquisition	page 4-264
		SYS (GET_XY) F1	SYS (GET_XY) F1	Acquisition of X and Y coordinates on circumference	page 4-266
		SYS (SET_BZ) F1	SYS (SET_BZ) F1	Buzzer control	page 4-268
		SYS (GET_TIME) F1	SYS (GET_TIME) F1	System time acquisition	page 4-269
		SYS (STA_TIME) F1	SYS (STA_TIME) F1	Timer setting	page 4-270
		SYS (GET_CLND) F1	SYS (GET_CLND) F1	Calendar acquisition	page 4-272
		SYS (SET_CLND) F1	SYS (SET_CLND) F1	Calendar setting	page 4-273
		SYS (SET_BUFNO) F1	SYS (SET_BUFNO) F1	Logging information	page 4-274
			SYS (SET_BUFNO) F1	Alarm log information	page 4-276
		SYS (GET_SMPL) F1	SYS (GET_SMPL) F1	Acquire logging/alarm data	page 4-277
		SYS (GET_SCUR) F1	SYS (GET_SCUR) F1	Cursor point acquisition	page 4-280
		SYS (DSP_DATA) F1	SYS (DSP_DATA) F1	Show/hide numerical data display	page 4-282
		SYS (CHG_DATA) F1	SYS (CHG_DATA) F1	Change numerical data display property	page 4-283
		SYS (STA_LIST) F1	SYS (STA_LIST) F1	Data sheet print	page 4-285

Category	Command Name	Mnemonic	Contents	Refer to
Others	SYS	SYS (RGB_CHG) F1	Change RGB input parameter	page 4-287
		SYS (SET_RGB) F1	Switch from/to RGB input screen	page 4-288
			Snap/delete RGB input screen	page 4-289
			RGB input channel selection	page 4-291
			SYS (SET_BKLT) F1	Backlight control
		SYS (RESTART) F1	Restart	page 4-293
		SYS (CHG_LANG) F1	Language change	page 4-294
		SYS (RESET_SCRN) F1	Redisplay screen	page 4-296
		SYS (GET_STATUS_FL) F1	FL-net information acquisition	page 4-297
			SYS (OUT_ENQ) F1	Universal serial (interrupt)
		A-link + Net10		page 4-299
		SYS (OUT_ENQ_EX) F1	Universal serial (interrupt)	page 4-302
		SYS (SET_SYS_CLND) F1	System calendar setting	page 4-304
	HMI-FUNC	HMI-USERFUNC (F1 , " ")	DLL function execution	page 4-305
		HMI-LOADDLL (F1 , " ")	Load DLL	page 4-306
		HMI-SHUTDOWN	Computer shutdown	page 4-307
		HMI-USEREEXE (" ")	Application file execution	page 4-308
		HMI-CLOSE	TELLUS termination	page 4-309

MEMO

Please use this page freely.



4 Details of Macro Commands

- 4.1 Guide to Chapter 4
- 4.2 Arithmetical Operation
- 4.3 Logical Operation
- 4.4 Statistic
- 4.5 Mathematics/trigonometric
- 4.6 Bit Operation
- 4.7 Conversion
- 4.8 Transfer
- 4.9 Comparison
- 4.10 Macro Operation Control
- 4.11 FROM Backup
- 4.12 Printer
- 4.13 Video
- 4.14 PLC
- 4.15 Ethernet
- 4.16 MES
- 4.17 Storage (Recipe)
- 4.18 Storage (Sampling)
- 4.19 Storage (Others)
- 4.20 Real No. Arithmetical Operation
- 4.21 Real No. Statistics
- 4.22 Others

4.1 Guide to Chapter 4

Bit Operation

Command Name
Mnemonic

BCLR
F0 (OFF)

Applicable model *1

All models

Function: Bit reset
This macro command is used to reset (OFF) the memory bit specified in [F0].

F0 1 $\xrightarrow{\text{BCLR}}$ 0

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙	⊙	⊙	

○ : Setting enabled (indirect designation disabled)
⊙ : Setting enabled (indirect designation enabled)

Example

- \$u100 - 08 (OFF)

15	08	0
\$u100	0 0 0 0 0 0 0 0 0 0 1 0 0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
	BCLR ↓	
	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0

Types of device memory usable for the command and how to designate them
For more information on the types of device memory, refer to page 2-19.
For more information on the indirect memory designation, refer to page 2-20.

Example of command execution

Notes on the command

Supplemental remarks

- If you use PLC memory or temperature controller memory that is disabled for bit-by-bit read and write, the macro operation as the following takes place.
Ex.) Mitsubishi PLC D100-05 (OFF)

1. One word that specifies the bit is read.
2. The bit specified by the above one word is reset (OFF).
3. The data is written to the PLC.

* If the bit is changed in a sequence program during processing of step 2, step 3 for data writing is performed.

- The result of macro execution is stored in \$S72.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

*1 Refer to "V9 Series Models" in this manual.

Supplemental remarks

- Operation is performed in the decimal system with signs. Be sure that the result [F0] falls within the permissible range.

$$\text{\$u100} = \text{\$u200} + \text{\$u300} \text{ (W)}$$

\u200
+
\u300

\u100

DEC-
30000
+ 5000

-30536

HEX

7530
+ 1388

88B8

8000 - FFFF are negative in the decimal system with signs.

NG

* The execution result in the example above is an overflow.

If an operation results in "65535" in the decimal system (WORD) or less, it matches the result in the decimal system without signs.

\u200
+
\u300

\u100

DEC
30000
+ 5000

35000

HEX

7530
+ 1388

88B8

8000 - FFFF are positive in the decimal system without signs.

OK

* The execution result in the example above is an overflow.

- In a case where [F1] and [F2] are specified in the following ranges, they are treated as negative values -1 to -32768.
32768 - 65535 (DEC)
100000 - 17777 (OCT)
8000 - FFFF (HEX)
- The result of macro execution is stored in \$s1056.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
1	Overflow
2	Underflow
-1	Execution error

SUB(-)

All models	<input type="radio"/>
------------	-----------------------

F0 = F1 - F2 (W) WORD
F0 = F1 - F2 (D) DWORD

Function: Subtraction

This macro command is used to write the result of [F1] minus [F2] to [F0].



Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙	⊙		
F1	⊙	⊙		○
F2	⊙	⊙		○


○ : Setting enabled (indirect designation disabled)
 ⊙ : Setting enabled (indirect designation enabled)

Setting range


	WORD	DWORD
F0	-32768 - +32767 (Decimal system with signs)	-2147483648 - +2147483647 (Decimal system with signs)
F1		
F2		

Example

- \$u100 = \$u200 - \$u300 (W)




- \$u100 = \$u200 - \$u300 (D)



Supplemental remarks

- Operation is performed in the decimal system with signs. Be sure that the result [F0] falls within the permissible range.



* The execution result in the example above is an underflow.

- In a case where [F1] and [F2] are specified in the following ranges, they are treated as negative values -1 to -32768.
32768 - 65535 (DEC)
100000 - 177777 (OCT)
8000 - FFFF (HEX)
- The result of macro execution is stored in \$s1056.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
1	Overflow
2	Underflow
-1	Execution error

MUL(X)


All models	<input type="radio"/>
------------	-----------------------

F0 = F1 x F2 (W)..... WORD

F0 = F1 x F2 (D) DWORD

Function: Multiplication

This macro command is used to write the result of [F1] multiplied by [F2] to [F0].



Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙	⊙		
F1	⊙	⊙		○
F2	⊙	⊙		○

○ : Setting enabled (indirect designation disabled)
 ⊙ : Setting enabled (indirect designation enabled)

Setting range


	WORD	DWORD
F0	-32768 - +32767 (Decimal system with signs)	-2147483648 - +2147483647 (Decimal system with signs)
F1		
F2		

Example

- \$u100 = \$u200 × \$u300 (W)



- \$u100 = \$u200 × \$u300 (D)



Supplemental remarks

- Operation is performed in the decimal system with signs. Be sure that the result [F0] falls within the permissible range.

\$u200	×	\$u300	\$u100

DEC-

30000	
×	2
-5536	

NG

HEX

7530	
×	0002
EA60	

8000 - FFFF are negative in the decimal system with signs.

* The execution result in the example above is an overflow.

If an operation results in "65535" (WORD) or less, it matches the result in the decimal system without signs.

\$u200	×	\$u300	\$u100

DEC

30000	
×	2
60000	

OK

HEX

7530	
×	0002
EA60	

8000 - FFFF are positive in the decimal system without signs.

* The execution result in the example above is an overflow.

- If the result [F0] is outside the permissible range, the extra portion is truncated.

\$u200	×	\$u300	\$u100

DEC-

30000	
×	3
24464	

NG

HEX

7530	
×	0003
15F90	
↓	
Portion outside the range truncated	
5F90	

* The execution result in the example above is

In this case, operation is performed in DWORD.

\$u201	\$u200	×	\$u301	\$u300	\$u101	\$u100

DEC-

30000	
×	3
90000	

- In a case where [F1] and [F2] are specified in the following ranges, they are treated as negative values -1 to -32768.
32768 - 65535 (DEC)
100000 - 17777 (OCT)
8000 - FFFF (HEX)
- The result of macro execution is stored in \$s1056.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
1	Overflow
2	Underflow
-1	Execution error


DIV(/)

All models	<input type="radio"/>
------------	-----------------------

F0 = F1 / F2 (W) WORD
F0 = F1 / F2 (D) DWORD

Function: Division

This macro command is used to write the result of [F1] divided by [F2] to [F0].



Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙	⊙		
F1	⊙	⊙		○
F2	⊙	⊙		○

○ : Setting enabled (indirect designation disabled)
 ⊙ : Setting enabled (indirect designation enabled)

Setting range

	WORD	DWORD
F0	-32768 - +32767 (Decimal system with signs)	-2147483648 - +2147483647 (Decimal system with signs)
F1		
F2		

Example

- \$u100 = \$u200 / \$u300 (W)



- \$u100 = \$u200 / \$u300 (D)



Supplemental remarks

- Operation is performed in the decimal system with signs. Be sure that the [F1] value falls within the permissible range.
- In a case where [F1] and [F2] are specified in the following ranges, they are treated as negative values -1 to -32768.
 32768 - 65535 (DEC)
 100000 - 17777 (OCT)
 8000 - FFFF (HEX)
- The result of macro execution is stored in \$s1056.
 When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
1	Overflow
2	Underflow
3	Calculation operation execution error
-1	Execution error


MOD(%)

All models	<input type="radio"/>
------------	-----------------------

F0 = F1 % F2 (W).....WORD
F0 = F1 % F2 (D).....DWORD

Function: Remainder of division

This macro command is used to write the remainder of [F1] divided by [F2] to [F0].



Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙	⊙		
F1	⊙	⊙		○
F2	⊙	⊙		○


○ : Setting enabled (indirect designation disabled)
 ⊙ : Setting enabled (indirect designation enabled)

Setting range


	WORD	DWORD
F0	-32768 - +32767 (Decimal system with signs)	-2147483648 - +2147483647 (Decimal system with signs)
F1		
F2		

Example

- \$u100 = \$u200 % \$u300 (W)



- \$u100 = \$u200 % \$u300 (D)



Supplemental remarks

- Operation is performed in the decimal system with signs. Be sure that the [F1] value falls within the permissible range.
- In a case where [F1] and [F2] are specified in the following ranges, they are treated as negative values -1 to -32768.
 32768 - 65535 (DEC)
 100000 - 17777 (OCT)
 8000 - FFFF (HEX)
- The result of macro execution is stored in \$s1056.
 When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
1	Overflow
2	Underflow
3	Calculation operation execution error
-1	Execution error



4.3 Logical Operation

AND(&)


All models	<input type="radio"/>
------------	-----------------------

F0 = F1 & F2 (W) WORD

F0 = F1 & F2 (D) DWORD

Function: Logical product

This macro command is used to write the result of [F1] ANDed with [F2] bit by bit to [F0].



Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙			
F1	⊙			○
F2	⊙			○


○ : Setting enabled (indirect designation disabled)
 ⊙ : Setting enabled (indirect designation enabled)

Setting range


	WORD	DWORD
F0	0000 - FFFF (HEX)	00000000 - FFFFFFFF (HEX)
F1		
F2		

Example

- \$u100 = \$u200 & \$u300 (W)



- \$u100 = \$u200 & \$u300 (D)



Supplemental remarks

- The result of macro execution is stored in \$s1056. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error


OR()

All models	<input type="radio"/>
------------	-----------------------

F0 = F1 | F2 (W).....WORD
F0 = F1 | F2 (D).....DWORD

Function: Logical add

This macro command is used to write the result of [F1] ORed with [F2] bit by bit to [F0].



Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙			
F1	⊙			○
F2	⊙			○


○ : Setting enabled (indirect designation disabled)
 ⊙ : Setting enabled (indirect designation enabled)

Setting range


	WORD	DWORD
F0	0000 - FFFF (HEX)	00000000 - FFFFFFFF (HEX)
F1		
F2		

Example

- \$u100 = \$u200 | \$u300 (W)



- \$u100 = \$u200 | \$u300 (D)



Supplemental remarks

- The result of macro execution is stored in \$s1056. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

XOR(^)


All models	<input type="radio"/>
------------	-----------------------

F0 = F1 ^ F2 (W)..... WORD

F0 = F1 ^ F2 (D)..... DWORD

Function: Exclusive OR

This macro command is used to write the result of [F1] XORed with [F2] bit by bit to [F0].



Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙			
F1	⊙			○
F2	⊙			○


○ : Setting enabled (indirect designation disabled)
 ⊙ : Setting enabled (indirect designation enabled)

Setting range


	WORD	DWORD
F0	0000 - FFFF (HEX)	00000000 - FFFFFFFF (HEX)
F1		
F2		

Example

- \$u100 = \$u200 ^ \$u300 (W)



- \$u100 = \$u200 ^ \$u300 (D)



Supplemental remarks

- The result of macro execution is stored in \$s1056.
 When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error


SHL(<<)

All models	<input type="radio"/>
------------	-----------------------

F0 = F1 << F2 (W) WORD
F0 = F1 << F2 (D) DWORD

Function: Left shift

This macro command is used to perform logical shift of [F1] to the left by the number of bits specified in [F2] and write the result to [F0]. The higher-order bits (by the number in [F2]) are truncated. "0" is assigned to the lower-order bits (by the number in [F2]).



Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙			
F1	⊙			○
F2	○			○


○ : Setting enabled (indirect designation disabled)
 ⊙ : Setting enabled (indirect designation enabled)

Setting range


	WORD	DWORD
F0	0000 - FFFF (HEX)	00000000 - FFFFFFFF (HEX)
F1		
F2	0 - 15	0 - 31

Example

- \$u100 = \$u200 << 3 (W)



- \$u100 = \$u200 << 2 (D)



Supplemental remarks

- The result of macro execution is stored in \$s1056. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error


SHR(>>)

All models	<input type="radio"/>
------------	-----------------------

F0 = F1 >> F2 (W)..... WORD
F0 = F1 >> F2 (D)..... DWORD

Function: Right shift

This macro command is used to perform logical shift of [F1] to the right by the number of bits specified in [F2] and write the result to [F0]. The lower-order bits (by the number in [F2]) are truncated. "0" is assigned to the higher-order bits (by the number in [F2]).



Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙			
F1	⊙			○
F2	○			○


○ : Setting enabled (indirect designation disabled)
 ⊙ : Setting enabled (indirect designation enabled)

Setting range


	WORD	DWORD
F0	0000 - FFFF (HEX)	00000000 - FFFFFFFF (HEX)
F1		
F2	0 - 15	0 - 31

Example

- \$u100 = \$u200 >> 3 (W)



- \$u100 = \$u200 >> 2 (D)



Supplemental remarks

- The result of macro execution is stored in \$s1056.
 When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

4.4 Statistic

MAX


All models	<input type="radio"/>
------------	-----------------------

F0 = MAX (F1 C : F2) (W) WORD

F0 = MAX (F1 C : F2) (D) DWORD

Function: Maximum

This macro command is used to find the maximum data at the location starting from the address specified in [F1] and write the result to [F0]. The data count is specified in [F2].



Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙			
F1	⊙			
F2	○			○

○ : Setting enabled (indirect designation disabled)


⊙ : Setting enabled (indirect designation enabled)

Setting range


	WORD	DWORD
F0	-32768 - +32767	-2147483648 - +2147483647
F1	(Decimal system with signs)	(Decimal system with signs)
F2	0 - 512	0 - 512

Example

- \$u100 = MAX (\$u200 C : 5) (W)



- \$u100 = MAX (\$u200 C : 5) (D)



Supplemental remarks

- The result of macro execution is stored in \$s1056.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

MIN


All models	<input type="radio"/>
------------	-----------------------

F0 = MIN (F1 C : F2) (W).....WORD

F0 = MIN (F1 C : F2) (D)DWORD

Function: Minimum

This macro command is used to find the minimum data at the location starting from the address specified in [F1] and write the result to [F0]. The data count is specified in [F2].



Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙			
F1	⊙			
F2	○			○

○ : Setting enabled (indirect designation disabled)


⊙ : Setting enabled (indirect designation enabled)

Setting range


	WORD	DWORD
F0	-32768 - +32767	-2147483648 - +2147483647
F1	(Decimal system with signs)	(Decimal system with signs)
F2	0 - 512	0 - 512

Example

- \$u100 = MIN (\$u200 C : 5) (W)



- \$u100 = MIN (\$u200 C : 5) (D)



Supplemental remarks

- The result of macro execution is stored in \$s1056.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

AVG


All models	<input type="radio"/>
------------	-----------------------

F0 = AVG (F1 C : F2) (W) WORD

F0 = AVG (F1 C : F2) (D)..... DWORD

Function: Average

This macro command is used to average the data at the location starting from the address specified in [F1] and write the result to [F0]. The data count is specified in [F2].



Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙			
F1	⊙			
F2	○			○


○ : Setting enabled (indirect designation disabled)
 ⊙ : Setting enabled (indirect designation enabled)

Setting range


	WORD	DWORD
F0	-32768 - +32767	-2147483648 - +2147483647
F1	(Decimal system with signs)	(Decimal system with signs)
F2	0 - 512	0 - 512

Example

- \$u100 = AVG (\$u200 C : 5) (W)



- \$u100 = AVG (\$u200 C : 5) (D)



Supplemental remarks

- The result of macro execution is stored in \$s1056.
 When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
3	Calculation operation execution error
-1	Execution error

SUM


All models	<input type="radio"/>
------------	-----------------------

F0 = SUM (F1 C : F2) (W)..... WORD

F0 = SUM (F1 C : F2) (D)..... DWORD

Function: Sum

This macro command is used to determine the sum of the data at the location starting from the address specified in [F1] and write the result to [F0]. The data count is specified in [F2].



Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙			
F1	⊙			
F2	○			○

○ : Setting enabled (indirect designation disabled)


⊙ : Setting enabled (indirect designation enabled)

Setting range


	WORD	DWORD
F0	-32768 - +32767	-2147483648 - +2147483647
F1	(Decimal system with signs)	(Decimal system with signs)
F2	0 - 512	0 - 512

Example

- \$u100 = SUM (\$u200 C : 5) (W)



- \$u101 = SUM (\$u200 C : 5) (D)



Supplemental remarks

- The result of macro execution is stored in \$s1056.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
1	Overflow
2	Underflow
-1	Execution error

4.5 Mathematics/trigonometric

EXP

F0 = EXP(F1) (F)

All models	<input type="radio"/>
------------	-----------------------

Function: Calculation of the exponent

This macro command is used to store the exponent of [F1] in [F0]. Specify [F0] and [F1] as floating decimal point (FLOAT) type values.



Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙			
F1	⊙			○

○ : Setting enabled (indirect designation disabled)

⊙ : Setting enabled (indirect designation enabled)

Setting range

	Value
F0	IEEE 32-bit single precision real number
F1	

Example

- \$u100 = EXP (\$u200) (F)

$$2.71828 = e^{1.0}$$

When \$u200 = "1.0", on command execution "2.71828" is stored in \$u100.

Supplemental remarks

- For more information on the IEEE 32-bit single precision real number, refer to the V9 Series Reference Manual.
- The result of macro execution is stored in \$s1056. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
1	Overflow*
2	Underflow*

* An indefinite value is stored in [F0].


EXPT

F0 = EXPT(F1,F2) (F)

All models	<input type="radio"/>
------------	-----------------------

Function: Calculation of powers

This macro command is used to store [F1] to the power of [F2] in [F0]. Specify [F0], [F1], and [F2] as floating decimal point (FLOAT) type values.



Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙			
F1	⊙			○
F2	⊙			○

○ : Setting enabled (indirect designation disabled)

⊙ : Setting enabled (indirect designation enabled)

Setting range

	Value
F0	
F1	IEEE 32-bit single precision real number
F2	

Example

- \$u100 = EXPT (\$u200,\$u300) (F)

$$8 = 2^3$$

When \$u200 = "2" and \$u300 = "3", on command execution "8" is stored in \$u100.

Supplemental remarks

- For more information on the IEEE 32-bit single precision real numbers, refer to the V9 Series Reference Manual.
- The result of macro execution is stored in \$s1056. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
1	Overflow*
2	Underflow*

* An indefinite value is stored in [F0].

LN

F0 = LN(F1) (F)

All models	<input type="radio"/>
------------	-----------------------

Function: Calculation of natural logarithms

This macro command is used to store the value of the natural logarithm of [F1] in [F0].

Specify [F0] and [F1] as floating decimal point (FLOAT) type values.

$$\log_e \left(\begin{matrix} \text{FLOAT} \\ \boxed{F1+1} \end{matrix} \begin{matrix} \text{FLOAT} \\ \boxed{F1} \end{matrix} \right) \rightarrow \begin{matrix} \text{FLOAT} \\ \boxed{F0+1} \end{matrix} \begin{matrix} \text{FLOAT} \\ \boxed{F0} \end{matrix}$$

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙			
F1	⊙			○

○ : Setting enabled (indirect designation disabled)

⊙ : Setting enabled (indirect designation enabled)

Setting range

	Value
F0	IEEE 32-bit single precision real number
F1	

Example

- \$u100 = LN (\$u200) (F)

$$2.302585 = \log_e (10.0)$$

When \$u200 = "10.0", on command execution "2.302585" is stored in \$u100.

Supplemental remarks

- For more information on the IEEE 32-bit single precision real number, refer to the V9 Series Reference Manual.
- The result of macro execution is stored in \$s1056. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
1	Overflow*
2	Underflow*

* An indefinite value is stored in [F0].



LOG

F0 = LOG(F1) (F)

All models	<input type="radio"/>
------------	-----------------------

Function: Calculation of common logarithms

This macro command is used to store the value of the common logarithm of [F1] in [F0].

Specify [F0] and [F1] as floating decimal point (FLOAT) type values.

$$\log_{10} \left(\overset{\text{FLOAT}}{\boxed{F1+1}} \overset{\text{FLOAT}}{\boxed{F1}} \right) \rightarrow \overset{\text{FLOAT}}{\boxed{F0+1}} \overset{\text{FLOAT}}{\boxed{F0}}$$

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙			
F1	⊙			○

○ : Setting enabled (indirect designation disabled)

⊙ : Setting enabled (indirect designation enabled)

Setting range

	Value
F0	IEEE 32-bit single precision real number
F1	

Example

- \$u100 = LOG (\$u200) (F)

$$1.0 = \log_{10} (10.0)$$

When \$u200 = "10.0", on command execution "1.0" is stored in \$u100.

Supplemental remarks

- For more information on the IEEE 32-bit single precision real number, refer to the V9 Series Reference Manual.
- The result of macro execution is stored in \$s1056.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
1	Overflow*
2	Underflow*

* An indefinite value is stored in [F0].

SQRT

F0 = SQRT(F1) (F)

All models	○
------------	---

Function: Calculation of square roots

This macro command is used to store the value of the square root of [F1] in [F0]. Specify [F0] and [F1] as floating decimal point (FLOAT) type values.

$$\sqrt{\text{ (FLOAT F1+1 F1) }} \rightarrow \text{ (FLOAT F0+1 F0)}$$

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙			
F1	⊙			○

○ : Setting enabled (indirect designation disabled)

⊙ : Setting enabled (indirect designation enabled)

Setting range

	Value
F0	IEEE 32-bit single precision real number
F1	

Example

- \$u100 = SQRT (\$u200) (F)

$$1.41421 = \sqrt{2.0}$$

When \$u200 = "2.0", on command execution "1.41421" is stored in \$u100.

Supplemental remarks

- For more information on the IEEE 32-bit single precision real number, refer to the V9 Series Reference Manual.
- The result of macro execution is stored in \$s1056. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
1	Overflow*
2	Underflow*

* An indefinite value is stored in [F0].

ABS

All models	<input type="radio"/>
------------	-----------------------


F0 = ABS (F1) (W) WORD

F0 = ABS (F1) (D)..... DWORD

F0 = ABS (F1) (F) FLOAT

Function: Absolute value

This macro command is used to store an absolute value of [F1] in [F0].



Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙			
F1	⊙			○


○ : Setting enabled (indirect designation disabled)
 ⊙ : Setting enabled (indirect designation enabled)

Setting range

	WORD	DWORD	FLOAT
F0	-32767 to +32767 (Decimal system with signs)	-2147483647 to +2147483647 (Decimal system with signs)	IEEE 32-bit single precision real number
F1			

Example

- \$u100 = ABS (\$u200) (W)
 When \$u200 = "-1", on command execution "1" is stored in \$u100.



Supplemental remarks

- For more information on the IEEE 32-bit single precision real numbers, refer to the V9 Series Reference Manual.
- The result of macro execution is stored in \$s1056.
 When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
1	Overflow*
2	Underflow*

* An indefinite value is stored in [F0].


NEG

All models	<input type="radio"/>
------------	-----------------------

F0 = NEG (F1) (W)..... WORD
F0 = NEG (F1) (D)..... DWORD
F0 = NEG (F1) (F)..... FLOAT

Function: Sign inversion

This macro command is used to store a value with its sign inverted from [F1] in [F0].



Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙			
F1	⊙			○


○ : Setting enabled (indirect designation disabled)
 ⊙ : Setting enabled (indirect designation enabled)

Setting range

	WORD	DWORD	FLOAT
F0	-32767 to +32767 (Decimal system with signs)	-2147483647to +2147483647 (Decimal system with signs)	IEEE 32-bit single precision real number
F1			

Example

- \$u100 = NEG (\$u200) (W)
 When \$u200 = “-1”, on command execution “1” is stored in \$u100.



Supplemental remarks

- For more information on the IEEE 32-bit single precision real numbers, refer to the V9 Series Reference Manual.
- The result of macro execution is stored in \$\$s1056.
 When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
1	Overflow*
2	Underflow*

* An indefinite value is stored in [F0].


ASIN

F0 = ASIN (F1) (F) FLOAT

All models	<input type="radio"/>
------------	-----------------------

Function: Arcsine

This macro command is used to store an arcsine of the angle (in radians) specified for [F1] in [F0].
Specify [F0] and [F1] as floating decimal point (FLOAT) type values.



Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙			
F1	⊙			○

○ : Setting enabled (indirect designation disabled)
⊙ : Setting enabled (indirect designation enabled)


Setting range

	Value
F0	IEEE 32-bit single precision real number
F1	

Example

- To obtain the value for $\sin^{-1} 1$;
\$u100 = ASIN (1) (F)
The operation result of “1.570796” (= $\pi/2$) is stored in \$u100.

* The \sin^{-1} of the trigonometric functions is expressed in the graph shown on the right.



Supplemental remarks

- For more information on the IEEE 32-bit single precision real numbers, refer to the V9 Series Reference Manual.
- The result of macro execution is stored in \$s1056.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
1	Overflow*1
2	Underflow*1
3	Calculation operation execution error*2

*1 An indefinite value is stored in [F0].
*2 When the value specified for [F1] is outside the range from “-1” to “1”, “-1” is stored in [F0].

- To convert the unit of an angle, use the macro command of DEG (page 4-32) or RAD (page 4-33).

ACOS

F0 = ACOS (F1) (F)..... FLOAT

All models	<input type="radio"/>
------------	-----------------------

Function: Arccosine

This macro command is used to store an arccosine of the angle (in radians) specified for [F1] in [F0].

Specify [F0] and [F1] as floating decimal point (FLOAT) type values.



Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙			
F1	⊙			○

○ : Setting enabled (indirect designation disabled)

⊙ : Setting enabled (indirect designation enabled)


Setting range

	Value
F0	IEEE 32-bit single precision real number
F1	

Example

- To obtain the value for $\cos^{-1} 0$;
 $\$u100 = \text{ACOS}(0)$ (F)
 The operation result of "1.570796" ($= \pi/2$) is stored in \$u100.

* The \cos^{-1} of the trigonometric functions is expressed in the graph shown on the right.



Supplemental remarks

- For more information on the IEEE 32-bit single precision real numbers, refer to the V9 Series Reference Manual.
- The result of macro execution is stored in \$s1056. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
1	Overflow ^{*1}
2	Underflow ^{*1}
3	Calculation operation execution error ^{*2}

*1 An indefinite value is stored in [F0].

*2 When the value specified for [F1] is outside the range from "-1" to "1", "-1" is stored in [F0].

- To convert the unit of an angle, use the macro command of DEG (page 4-32) or RAD (page 4-33).

4.6 Bit Operation

BSET

All models

F0 (ON)

Function: Bit set

This macro command is used to set (ON) the memory bit specified in [F0].




Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙	⊙	⊙	

○ : Setting enabled (indirect designation disabled)
 ⊙ : Setting enabled (indirect designation enabled)


Example

- \$u100 - 08 (ON)



Supplemental remarks

- If you use PLC memory or temperature controller memory that is disabled for bit-by-bit read and write, the macro operation as the following takes place.
 Ex.) Mitsubishi PLC D100-05 (ON)
 1. One word that specifies the bit is read.
 2. The bit specified by the above one word is set (ON).
 3. The data is written to the PLC.



* If the bit is changed in a sequence program during processing of step 2, step 3 for data writing is performed.

- The result of macro execution is stored in \$s72.
 When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

BCLR

F0 (OFF)

All models	○
------------	---

Function: Bit reset

This macro command is used to reset (OFF) the memory bit specified in [F0].




Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙	⊙	⊙	

○ : Setting enabled (indirect designation disabled)
 ⊙ : Setting enabled (indirect designation enabled)


Example

- \$u100 - 08 (OFF)



Supplemental remarks

- If you use PLC memory or temperature controller memory that is disabled for bit-by-bit read and write, the macro operation as the following takes place.
 Ex.) Mitsubishi PLC D100-05 (OFF)
 1. One word that specifies the bit is read.
 2. The bit specified by the above one word is reset (OFF).
 3. The data is written to the PLC.



* If the bit is changed in a sequence program during processing of step 2, step 3 for data writing is performed.

- The result of macro execution is stored in \$s72.
 When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error


BINV

F0 (INV)

All models	<input type="radio"/>
------------	-----------------------

Function: Bit inversion

This macro command is used to invert the memory bit specified in [F0].




Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙	⊙	⊙	

○ : Setting enabled (indirect designation disabled)
 ⊙ : Setting enabled (indirect designation enabled)


Example

- \$u100 - 08 (INV)



Supplemental remarks

- If you use PLC memory or temperature controller memory that is disabled for bit-by-bit read and write, the macro operation as the following takes place.
 Ex.) Mitsubishi PLC D100-05 (INV)
 1. One word that specifies the bit is read.
 2. The bit specified by the above one word is inverted.
 3. The data is written to the PLC.



* If the bit is changed in a sequence program during processing of step 2, step 3 for data writing is performed.

- The result of macro execution is stored in \$s72.
 When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

4.7 Conversion

BCD

All models	<input type="radio"/>
------------	-----------------------

F0 = F1 (W) BCD **WORD**

F0 = F1 (D) BCD **DWORD**

Function: Conversion to BCD

This macro command is used to convert the binary data specified in [F1] to BCD and write the result to [F0].



Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙			
F1	⊙			


○ : Setting enabled (indirect designation disabled)
 ⊙ : Setting enabled (indirect designation enabled)

Setting range

	WORD	DWORD
F0	0 - 9999 (BCD)	0 - 99999999 (BCD)
F1	0 - 9999 (Decimal system without signs)	0 - 99999999 (Decimal system without signs)

Example

- \$u100 = \$u200 (W) BCD



Supplemental remarks

- If the value in [F1] is outside the permissible range, [F0] becomes "0".
- The result of macro execution is stored in \$s1057.
 When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error



BIN

All models	<input type="radio"/>
------------	-----------------------

F0 = F1 (W) BIN WORD
F0 = F1 (D) BIN DWORD

Function: Conversion to BIN

This macro command is used to convert the BCD data specified in [F1] to binary data and write the result to [F0].



Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙			
F1	⊙			


○ : Setting enabled (indirect designation disabled)
 ⊙ : Setting enabled (indirect designation enabled)

Setting range

	WORD	DWORD
F0	0 - 9999 (Decimal system without signs)	0 - 99999999 (Decimal system without signs)
F1	0 - 9999 (BCD)	0 - 99999999 (BCD)

Example

- \$u100 = \$u200 (W)BIN



Supplemental remarks

- If the value in [F1] is outside the permissible range, [F0] becomes "0".
 - The result of macro execution is stored in \$s1057.
- When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error


CWD

F0 = F1 D <-W

All models	<input type="radio"/>
------------	-----------------------

Function: Convert one-word → double-word

This macro command is used to convert the one-word data with sign specified in [F1] to double-word data with sign and write the result to [F0].



Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙			
F1	⊙			

○ : Setting enabled (indirect designation disabled)
 ⊙ : Setting enabled (indirect designation enabled)




Setting range

	Value
F0	-32768 - +32767 (Decimal system with signs)
F0+1	
F1	

Example

- \$u100 = \$u200 D <- W



Supplemental remarks

- The result of macro execution is stored in \$s1057. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

CVP

All models	<input type="radio"/>
------------	-----------------------

F0 = F1 (W) PLC <-..... WORD
F0 = F1 (D) PLC <-..... DWORD

Function: Convert binary data to PLC1-format data

This macro command is used to convert the binary data specified in [F1] to the PLC1-format data and write the result to [F0].

The following PLCs manipulate PLC-format data.

- Fuji Electric: MICREX-F all types
- Yaskawa: Memobus [Transmission Mode: Type 1]
- OMRON: All [Transmission Mode: Transmission Mode 2]

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙			
F1	⊙			

○ : Setting enabled (indirect designation disabled)

⊙ : Setting enabled (indirect designation enabled)

Setting range

- The available memory address range and the type of data vary, depending on the PLCs. Refer to the PLC manual for details.

Example

- Fuji MICREX-F F70S BCD with signs (-7999 to +7999)

The most significant bit

OFF: Positive

ON: Negative

\$u100 = \$u200 (W) PLC<-

\$u200	1	1	1	1	1	1	1	1	1	0	0	1	1	1	0	0	BIN
	F				F				9				C				HEX
	-100																V series (DEC)

CVP ↓

\$u100	1	0	0	0	0	0	0	1	0	0	0	0	0	0	0	0	BIN
	8				1				0				0				HEX
	-100																F70S (BCD with signs)

Supplemental remarks

- The macro command is used in combination with MOV or BMOV.
- To convert to characteristic data other than for PLC1, use " CVPFMT" (page 4-41).
- The result of macro execution is stored in \$s1057.
 When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

CVPFMT

All models	<input type="radio"/>
------------	-----------------------

F0 = F1 (W) PLC F2 <- WORD
F0 = F1 (D) PLC F2 <- DWORD

Function: Convert binary data to PLC-format data specified at [F2]

This macro command is used to convert the binary data specified in [F1] to the PLC-format data specified at [F2] and write the result to [F0].

The following PLCs manipulate PLC-format data.

- Fuji Electric: MICREX-F all types
- Yaskawa: Memobus [Transmission Mode: Type 1]
- OMRON: All [Transmission Mode: Transmission Mode 2]

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙			
F1	⊙			
F2	○			○

○ : Setting enabled (indirect designation disabled)
 ⊙ : Setting enabled (indirect designation enabled)

Setting range

	Value
F0	The available memory address range and the type of data vary, depending on the PLCs.
F1	Refer to the PLC manual for details.
F2	1 - 8

Example

- Fuji's MICREX-F series is connected as PLC2.
- Fuji MICREX-F F70S BCD with signs (-7999 to +7999)

The most significant bit

OFF: Positive

ON: Negative

\$u100 = \$u200 (W) PLC2 <-

\$u200	1 1 1 1 1 1 1 1 1 0 0 1 1 1 0 0	BIN
	F F 9 C	HEX
	-100	V series (DEC)
CVPFMT ↓		
\$u100	1 0 0 0 0 0 0 1 0 0 0 0 0 0 0	BIN
	8 1 0 0	HEX
	-100	F70S (BCD with signs)

Supplemental remarks

- The macro command is used in combination with MOV or BMOV.
 - The result of macro execution is stored in \$s1057.
- When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

CVB

All models	<input type="radio"/>
------------	-----------------------

F0 = F1 (W) <- PLC..... WORD
F0 = F1 (D) <- PLC..... DWORD

Function: Convert PLC1-format data to binary data

This macro command is used to convert the PLC1-format data specified in [F1] to binary data and write the result to [F0].

The following PLCs manipulate PLC-format data.

- Fuji Electric: MICREX-F all types
- Yaskawa: Memobus [Transmission Mode: Type 1]
- OMRON: All [Transmission Mode: Transmission Mode 2]

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙			
F1	⊙			○

○ : Setting enabled (indirect designation disabled)

⊙ : Setting enabled (indirect designation enabled)

Setting range

- The available memory address range and the type of data vary, depending on the PLCs. Refer to the PLC manual for details.

Example


- Fuji MICREX-F F70S BCD with signs (-7999 to +7999)

The most significant bit

OFF: Positive

ON: Negative

\$u100 = \$u200 (W) <-PLC



Supplemental remarks

- The macro command is used in combination with MOV or BMOV.
- To convert to characteristic data other than for PLC1, use " CVBFMT" (page 4-43).
- The result of macro execution is stored in \$s1057.
 When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

CVBFMT

All models	<input type="radio"/>
------------	-----------------------

F0 = F1 (W) <- PLC F2 WORD
F0 = F1 (D) <- PLC F2 DWORD

Function: Convert PLC-format data specified at [F2] to binary data

This macro command is used to convert the PLC-format data specified at [F2] in [F1] to the binary data and write the result to [F0].

The following PLCs manipulate PLC-format data.

- Fuji Electric: MICREX-F all types
- Yaskawa: Memobus [Transmission Mode: Type 1]
- OMRON: All [Transmission Mode: Transmission Mode 2]

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙			
F1	⊙			
F2	○			○

○ : Setting enabled (indirect designation disabled)
 ⊙ : Setting enabled (indirect designation enabled)

Setting range

	Value
F0	The available memory address range and the type of data vary, depending on the PLCs.
F1	Refer to the PLC manual for details.
F2	1 - 8

Example

- Fuji's MICREX-F series is connected as PLC2.
- Fuji MICREX-F F70S BCD with signs (-7999 to +7999)

The most significant bit

OFF: Positive

ON: Negative

\$u100 = \$u200 (W) <- PLC2

\$u200	1 0 0 0 0 0 0 0 0 0 0 0 0 0 0 1	BIN
	8 0 0 1	HEX
	-1	
CVBFMT ↓		
\$u100	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	BIN
	F F F F	HEX
	-1	

Supplemental remarks

- The macro command is used in combination with MOV or BMOV.
 - The result of macro execution is stored in \$s1057.
- When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error


SWAP

F0 = C : F1 (SWAP)

All models	<input type="radio"/>
------------	-----------------------

Function: Swap MSB with LSB

This macro command is used to perform a swap between the higher-order byte and the lower-order byte of the data at the location starting from the address specified in [F0]. The data count is specified in [F1].



Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙			
F1	○			○

○ : Setting enabled (indirect designation disabled)


⊙ : Setting enabled (indirect designation enabled)

Setting range

	Value
F0	0000 - FFFF (HEX)
F1	0 - 1024

Example

- \$u100 C : 2 (SWAP)



Supplemental remarks

- The result of macro execution is stored in \$s1057. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error


CHR

F0 = ''

All models	<input type="radio"/>
------------	-----------------------

Function: Convert text → code

This macro command is used to convert the text placed in quotation marks '' to the shifted JIS/ASCII codes and write the result to [F0].

**Available device memory**

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙			

○ : Setting enabled (indirect designation disabled)

⊙ : Setting enabled (indirect designation enabled)

Setting range

	Value	Remarks
F0	Shifted JIS/ASCII	82 bytes maximum Variable depending on the bytes of the text
F0+1		
:		
''	Text	80 bytes maximum

Example

- When [MSB → LSB] is selected for [Text Process] on the [Communication Setting] tab window.

\$u100 = 'string'

Text	string					
	CHR↓					
\$u100	7	3	7	4	HEX	ts
\$u101	7	2	6	9	HEX	ir
\$u102	6	E	6	7	HEX	gn
\$u103	0	0	0	0	HEX	Null code

Supplemental remarks

- Swap between the higher-order byte and the lower-order byte can be set by selecting an option for [Text Process] under [Communication Setting].
- Regardless of the setting above, use a "STRING" command (page 4-46) for [LSB → MSB] conversions.
- A null code is added to the end. Even-number-byte text thereby uses one extra word.
- The result of macro execution is stored in \$s1057.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error


STRING

F0 = '(STRING)

All models	<input type="radio"/>
------------	-----------------------

Function: Convert text → code

This macro command is used to convert the text placed in quotation marks '' to the shifted JIS/ASCII codes and write the result to [F0].



Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙			

○ : Setting enabled (indirect designation disabled)
 ⊙ : Setting enabled (indirect designation enabled)

Setting range

	Value	Remarks
F0	Shifted JIS/ASCII	128 bytes maximum Variable depending on the bytes of the text
F0+1		
:		
' '	Text	128 bytes maximum

Example

\$u100 = 'string' (STRING)

Text	string					
	STRING↓					
\$u100	7	4	7	3	HEX	ts
\$u101	6	9	7	2	HEX	ir
\$u102	6	7	6	E	HEX	gn
\$u103	0	0	0	0	HEX	Null code

Supplemental remarks

- Regardless of the [Text Process] setting under [Communication Setting] for PLC1, the data is stored in memory in the [LSB → MSB] sequence.
- A null code is added to the end. Even-number-byte text thereby uses one extra word.
- The result of macro execution is stored in \$s1057.

When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

CVFD

F0(D) <- F1 (F) F2 (D)

All models	<input type="radio"/>
------------	-----------------------

Function: Convert floating decimal point → 32-bit binary

This macro command is used to convert the 32-bit single precision real number specified in [F1] to 32-bit binary data and store the result in [F0].

[F2] specifies the exponent of "10" at the time of conversion.

If [F2] = 0, rounding to the nearest whole number* is performed. If [F2] = 1, rounding to the nearest tenth* is performed. The result is stored in [F0].

* Rounding down and rounding up are also possible. Refer to page 4-48.

F1	31	30	29	-	24	23	22	21					5	4	3	2	1	0	Real number
	Sign		Exponent				Mantissa												
	$0 < \text{Exponent} < 255$: $(-1)^{\text{Sign}} \times (1 + \text{Mantissa} \times 2^{-23}) \times 2^{(\text{Exponent} - 127)}$																		
	$\text{Exponent} = 0, \text{Mantissa} \neq 0$: $(-1)^{\text{Sign}} \times (\text{Mantissa} \times 2^{-23}) \times 2^{-126}$																		
	$\text{Exponent} = 0, \text{Mantissa} = 0$: 0																		
	$\text{Sign} = 0, \text{Exponent} = 255, \text{Mantissa} = 0$: ∞																		
	$\text{Sign} = 1, \text{Exponent} = 255, \text{Mantissa} = 0$: $-\infty$																		
	$\text{Exponent} = 255, \text{Mantissa} \neq 0$: NaN																		
	CVFD ↓																		
F0	31	30	29									5	4	3	2	1	0	BIN	
	2^{31}		2^{30}	2^{29}									2^5	2^4	2^3	2^2	2^1		2^0



Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙			
F1	⊙			
F2				○

○ : Setting enabled (indirect designation disabled)

⊙ : Setting enabled (indirect designation enabled)

Setting range

	Value
F0	-2147483648 - 2147483647 (BIN)
F1	IEEE 32-bit single precision real number
F2	-32 - +32

Example

- \$u100 (D) <- \$u200 (F) 0 (D)

\$u201,\$u200	31	30	29	-	24	23	22	21					2	1	0				
	0		127				4194304												
	Sign		Exponent				Mantissa												
	$(-1)^0 \times (1 + 4194304 \times 2^{-23}) \times 2^{(127-127)} = 1.5$																		
	CVFD ↓																		
\$u101,\$u100	31	30	29									2	1	0					
	0		0									0	1	0					
	2_{DEC}																		

- \$u100 (D) <- \$u200 (F) 1 (D)

\$u201,\$u200	31	30	29	-	24	23	22	21		-	2	1	0
	0	127						4194304					
	Sign	Exponent						Mantissa					
	$(-1)^0 \times (1 + 4194304 \times 2^{-23}) \times 2^{(127 - 127)} = 1.5$												
	CVFD ↓												
\$u101,\$u100	31	30	29							-	2	1	0
	0	0	0							-			
	15 _{DEC}												

Supplemental remarks

- You can select whether to round to the nearest whole number, round down or round up by specifying the appropriate value for \$s99.*

Setting	Operation	
Other than 1 or 2	Round to the nearest whole number	0 - 4 : Round down 5 - 9 : Round up
1	Round down	
2	Round up	0: Round down Other than 0: Round up

* If [Retain compatibility with negative value handling of CVFD macro command] is checked in the [General Settings] tab window ([System Setting] → [Unit Setting] → [General Settings]), the action to round down is performed, irrespective of the value in memory at \$s99.

- The result of macro execution is stored in \$s1057.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

CVDF

F0(F) <- F1 (D) F2 (D)

All models	<input type="radio"/>
------------	-----------------------

Function: Convert 32-bit binary → floating decimal point

This macro command is used to convert the 32-bit binary data specified in [F1] to 32-bit single precision real number and store the result in [F0].
[F2] specifies the exponent of "10" at the time of conversion.

F1	31	30	29									5	4	3	2	1	0	BIN	
	2^{31}	2^{30}	2^{29}									2^5	2^4	2^3	2^2	2^1	2^0		
CVDF ↓																			
F0	31	30	29	-	24	23	22	21					5	4	3	2	1	0	Real number
	Sign	Exponent						Mantissa											
$0 < \text{Exponent} < 255$: $(-1)^{\text{Sign}} \times (1 + \text{Mantissa} \times 2^{-23}) \times 2^{(\text{Exponent} - 127)}$																			
$\text{Exponent} = 0, \text{Mantissa} \neq 0$: $(-1)^{\text{Sign}} \times (\text{Mantissa} \times 2^{-23}) \times 2^{-126}$																			
$\text{Exponent} = 0, \text{Mantissa} = 0$: 0																			
$\text{Sign} = 0, \text{Exponent} = 255, \text{Mantissa} = 0$: ∞																			
$\text{Sign} = 1, \text{Exponent} = 255, \text{Mantissa} = 0$: $-\infty$																			
$\text{Exponent} = 255, \text{Mantissa} \neq 0$: NaN																			



Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙			
F1	⊙			
F2				○

○ : Setting enabled (indirect designation disabled)
⊙ : Setting enabled (indirect designation enabled)

Setting range


	Value
F0	IEEE 32-bit single precision real number
F1	-2147483648 - 2147483647 (BIN)
F2	-32 - +32

Example

- \$u100 (F) <- \$u200 (D) 0 (D)


\$u201,\$u200	31	30	29									2	1	0	BIN							
	00000001 _{BIN}																					
CVDF ↓																						
\$u101,\$u100	31	30	29	-	24	23	22	21					2	1	0	Real number						
	0	127						0														
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 5%;">Sign</td> <td style="width: 20%;">Exponent</td> <td style="width: 75%;">Mantissa</td> </tr> <tr> <td></td> <td></td> <td>$(-1)^0 \times (1 + 0 \times 2^{-23}) \times 2^{(127 - 127)} = 1$</td> </tr> </table>																	Sign	Exponent	Mantissa			$(-1)^0 \times (1 + 0 \times 2^{-23}) \times 2^{(127 - 127)} = 1$
Sign	Exponent	Mantissa																				
		$(-1)^0 \times (1 + 0 \times 2^{-23}) \times 2^{(127 - 127)} = 1$																				

- \$u100 (F) <- \$u200 (D) 1 (D)



Supplemental remarks

The V series manipulates 32-bit single precision real numbers. Therefore, in the case of 24-bit binary data that exceeds the significant digit (-16777216 to 16777215 in the decimal system), the figure at the 25th bit from the leftmost digit of the converted binary data is rounded up and the figures at the 26th bit and after are truncated. Since the value obtained in the above manner is used for conversion to real number, an error is introduced.



- The result of macro execution is stored in \$s1057. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

Supplemental remarks

- The result of macro execution is stored in \$s1057. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

Restrictions

- When setting a numerical data display to show the converted result of calendar data, 3 (hour):14 (minutes):7 (seconds) on January 19, 2038 or after, enable the display to show 2-word long data without sign.
- This macro handles any year divisible by 4 as a leap year. For example, the year 2100 is recognized as a leap year though it is not so. Therefore, an error of one day will result.
- The calendar data displayable on the V9 unit ranges from January 1, 2012 to January 19, 2038. Any data outside this range cannot be converted with this macro correctly.

GRE_TO_CLND

GRE_TO_CLND F0 F1 F2

All models	<input type="radio"/>
------------	-----------------------

Function: Convert GMT-based UNIX time → calendar data

This macro is used to convert the UNIX time based on GMT in [F1] to the calendar data in format [F2], and to store the converted result in [F0].



Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙			
F1	⊙			
F2	○			○

○ : Setting enabled (indirect designation disabled)
 ⊙ : Setting enabled (indirect designation enabled)

Setting range

	Value			
F0	4 digits: Year			
F0+1	1 - 12: Month			
F0+2	1 - 31: Day			
F0+3	0 - 23: Hour			
F0+4	0 - 59: Minute			
F0+5	0 - 59: Second			
F0+6	0: Sunday 1: Monday 2: Tuesday 3: Wednesday 4: Thursday 5: Friday 6: Saturday			
F1	Time data 0	DEC only		
F1+1	Time data 1	<table border="1"> <tr> <td>Time data 1</td> <td>Time data 0</td> </tr> </table> GMT-based UNIX time from January 1, 1970	Time data 1	Time data 0
Time data 1	Time data 0			
F2	Data format for [F0] 0: DEC 1: BCD			

 : ← V series (return data)

Example

The GMT-based UNIX time, 1278663500 seconds, in \$u200 is converted to the calendar data in DEC format, and the converted result is stored in \$u100 and after.

```
GRE_TO_CLND $u100 $u200 0
```

The calendar data, "8 (hour):18 (minutes):20 (seconds) on Friday on July 9, 2010," is obtained.

- Year → \$u100 = 2010 DEC
- Month → \$u101 = 7 DEC
- Day → \$u102 = 9 DEC
- Hour → \$u103 = 8 DEC
- Minutes → \$u104 = 18 DEC
- Seconds → \$u105 = 20 DEC
- Day of the week → \$u106 = 5 DEC

Supplemental remarks

- The result of macro execution is stored in \$s1057. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

Restrictions

- This macro handles any year divisible by 4 as a leap year. For example, the year 2100 is recognized as a leap year though it is not so. Therefore, an error of one day will result.
- The calendar data displayable on the V9 unit ranges from January 1, 2012 to January 19, 2038. Any data outside this range cannot be converted with this macro correctly.

FORMAT_DATA

FORMAT_DATA F0 F1 F2

All models	<input type="radio"/>
------------	-----------------------

Function: Convert string → numerical data

This macro is used to convert the string [F1] according to the attributes [F2], and to store the converted result in [F0].

F1 → F0
FORMAT_DATA

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙	⊙		
F1	⊙			
F2	○			

○ : Setting enabled (indirect designation disabled)

⊙ : Setting enabled (indirect designation enabled)

Setting range

	Value	Remarks
F0	Target memory: BIN data	The number of words depends on [F2+1] (data length).
F1	Source memory: String (ASCII code)	The number of bytes depends on [F2+3] (character count). 32 bytes maximum (16 words) Character processing LSB → MSB fixed
F2	0: DEC without sign (decimal) 1: DEC with a negative sign (decimal) 2: DEC with a positive/negative sign (decimal) 3: HEX (hexadecimal) 4: OCT (octal) 5: BIN (binary) 6: FLOAT (real number)	Format for [F1] If "DEC with a negative sign" or "FLOAT" is selected for [F2] for the conversion of a positive value, add a space code (20H) to the leftmost position of the positive value. Otherwise, an error will result. A space code is not included in the number of digits. Example: For a string "123" to be converted, add a space to make it as " 123".
F2+1	0: 1 word 1: 2 words	Data length for [F0] If "FLOAT" is selected for [F2], specify "0".
F2+2	0: DEC 1: BCD	Data format for [F0] If "HEX," "OCT," "BIN," or "FLOAT" is selected for [F2], specify "0".
F2+3	1 - 32: [F2] = 0, 1, 2, 5, or 6 1 - 8: [F2] = 3 1 - 11: [F2] = 4	Number of digits for [F1] A positive/negative sign and a decimal point are not included in the number of digits. Example: For a string "-12.3" to be converted, the number of digits is three.
F2+4	0 - 10: [F2] = 0, 1, or 2 0 - 31: [F2] = 6	Decimal place for [F1] Example: For a string "12.34" to be converted, specify two decimal places.
F2+5	0: With zero suppress 1: Without zero suppress	Format for [F1]

	Value	Remarks
F2+6	Valid only when F2+5 = 0 0: Leading spaces removed 1: Trailing spaces removed	Format for [F1] When a value in [F1] includes leading spaces, specify "0". When a value in [F1] includes trailing spaces, specify "1". Example: 0: <code> 12</code> → 12 1: <code>12 </code> → 12
F2+7	0 fixed	

Example

The string in \$u100 is converted to the numerical data, and the converted result is stored in \$u300.

- String "1234": DEC without sign

	3	2	3	1	HEX	Display
\$u100	3 2 3 1					"12"
\$u101	3 4 3 3				HEX	"34"
↓ FORMAT_DATA						
\$u300	1234					"1234"

```

$u00100 = '1234' (STRING)
$u00200 = 0 (W) [DEC without sign]
$u00201 = 0 (W) [1 word]
$u00202 = 0 (W) [DEC]
$u00203 = 4 (W) [4 digits]
$u00204 = 0 (W) [Without decimal point]
$u00205 = 0 (W) [With zero suppress]
$u00206 = 0 (W) [Leading spaces removed]
$u00207 = 0 (W) [0 fixed]
FORMAT_DATA $u00300 $u00100 $u00200
The result "1234" is stored in $u300.
    
```

- String "12.34": A positive value in DEC with a negative sign format and with two decimal places

```

$u00100 = ' _12.34' (STRING)
; (For a positive value, add a space code 20H to the leftmost position.)
$u00200 = 1 (W) [DEC with a negative sign]
$u00201 = 0 (W) [1 word]
$u00202 = 0 (W) [DEC]
$u00203 = 4 (W) [4 digits]
$u00204 = 2 (W) [Two decimal places]
$u00205 = 0 (W) [With zero suppress]
$u00206 = 0 (W) [Leading spaces removed]
$u00207 = 0 (W) [0 fixed]
FORMAT_DATA $u00300 $u00100 $u00200
The result "1234" is stored in $u300.
    
```

- String “-12.34”: A negative value in DEC with a negative sign format and with two decimal places

```
$u00100 = '-12.34' (STRING)
$u00200 = 1 (W) [DEC with a negative sign]
$u00201 = 0 (W) [1 word]
$u00202 = 0 (W) [DEC]
$u00203 = 4 (W) [4 digits]
$u00204 = 2 (W) [Two decimal places]
$u00205 = 0 (W) [With zero suppress]
$u00206 = 0 (W) [Leading spaces removed]
$u00207 = 0 (W) [0 fixed]
FORMAT_DATA $u00300 $u00100 $u00200
```

The result “-1234” is stored in \$u300.
- String “1234”: FLOAT

```
$u00100 = ' 1234' (STRING)
;(For a positive value, add a space code 20H to the leftmost position.)
$u00200 = 6 (W) [FLOAT]
$u00201 = 0 (W) [0 fixed]
$u00202 = 0 (W) [0 fixed]
$u00203 = 4 (W) [4 digits]
$u00204 = 0 (W) [Without decimal point]
$u00205 = 0 (W) [With zero suppress]
$u00206 = 0 (W) [Leading spaces removed]
$u00207 = 0 (W) [0 fixed]
FORMAT_DATA $u00300 $u00100 $u00200
```

The result “1234” is stored in \$u300 and \$u301.
- String “001234”: DEC without sign format and without zero suppress

```
$u00100 = '001234' (STRING)
$u00200 = 0 (W) [DEC without sign]
$u00201 = 0 (W) [1 word]
$u00202 = 0 (W) [DEC]
$u00203 = 6 (W) [6 digits]
$u00204 = 0 (W) [Without decimal point]
$u00205 = 1 (W) [Without zero suppress]
$u00206 = 0 (W) [Leading spaces removed]
$u00207 = 0 (W) [0 fixed]
FORMAT_DATA $u00300 $u00100 $u00200
```

The result “1234” is stored in \$u300.
- String “ 1234”: DEC without sign format and with two leading spaces

```
$u00100 = ' 1234' (STRING)
$u00200 = 0 (W) [DEC without sign]
$u00201 = 0 (W) [1 word]
$u00202 = 0 (W) [DEC]
$u00203 = 6 (W) [6 digits]
$u00204 = 0 (W) [Without decimal point]
$u00205 = 0 (W) [With zero suppress]
$u00206 = 0 (W) [Leading spaces removed]
$u00207 = 0 (W) [0 fixed]
FORMAT_DATA $u00300 $u00100 $u00200
```

The result “1234” is stored in \$u300.

- String "1234": DEC without sign format and with two trailing spaces
 \$u00100 = '1234' (STRING)
 \$u00200 = 0 (W) [DEC without sign]
 \$u00201 = 0 (W) [1 word]
 \$u00202 = 0 (W) [DEC]
 \$u00203 = 6 (W) [6 digits]
 \$u00204 = 0 (W) [Without decimal point]
 \$u00205 = 0 (W) [With zero suppress]
 \$u00206 = 1 (W) [Trailing spaces removed]
 \$u00207 = 0 (W) [0 fixed]
 FORMAT_DATA \$u00300 \$u00100 \$u00200
 The result "1234" is stored in \$u300.

Supplemental remarks

- If "HEX" is specified as an attribute for conversion, characters "A" - "F" of the source data is not case-sensitive.
- If this macro, with "FLOAT" specified as an attribute, results in underflow, "0" is obtained as the converted result.
- Conversion with this macro is in the order of LSB → MSB.
- The following PLCs provided with PLC-specific data format are capable of handling negative values in BCD with a sign format. When you run this macro using such a value with any of these PLCs, the internal memory is not valid for [F0]. Therefore, be sure to assign the PLC memory (specific to the PLC model) to [F0].
 - Fuji Electric: All of the MICREX-F series
 - Yaskawa: Memobus [Trans. Mode: Type 1]
 - Omron: All [Transmission Mode 2]
- The result of macro execution is stored in \$s1057.
 When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

FORMAT_STR

FORMAT_STR F0 F1 F2

All models	<input type="radio"/>
------------	-----------------------

Function: Convert numerical data → string

This macro is used to convert the numerical data [F1] according to the attributes [F2], and to store the converted result in [F0].

**Available device memory**

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙			
F1	⊙	⊙		
F2	○			

○ : Setting enabled (indirect designation disabled)

⊙ : Setting enabled (indirect designation enabled)

Setting range


	Value	Remarks
F0	Target device memory: String (ASCII code)	The number of bytes depends on [F2+3] (character count). 32 bytes maximum (16 words) Character processing LSB → MSB fixed
F1	Source device memory: BIN data	The number of words depends on [F2+1] (data length).
F2	0: DEC without sign (decimal) 1: DEC with a negative sign (decimal) 2: DEC with a positive/negative sign (decimal) 3: HEX (hexadecimal) 4: OCT (octal) 5: BIN (binary) 6: FLOAT (real number)	Format for [F1] If “DEC with a negative sign” or “FLOAT” is selected for [F2] and the converted result is a positive value, a space code (20H) is added to the leftmost position of the positive value. Example: For numerical data “123” to be converted, a space is added to provide a converted result as “_123”.
F2+1	0: 1 word 1: 2 words	Data length for [F1] If “FLOAT” is selected for [F2], specify “0”.
F2+2	0: DEC 1: BCD	Data format for [F1] If “HEX,” “OCT,” “BIN,” or “FLOAT” is selected for [F2], specify “0”.
F2+3	1 - 32: [F2] = 0, 1, 2, 5, or 6 1 - 8: [F2] = 3 1 - 11: [F2] = 4	Number of digits for [F0] A positive/negative sign and a decimal point are not included in the number of digits. If the number of digits specified for [F2+3] is smaller than that of the converted string, the result is given as a hyphen “-”. Example: For a string “-12.3” as the converted result, the number of digits is three.
F2+4	0 - 10: [F2] = 0, 1, or 2 0 - 31: [F2] = 6	Decimal place for [F0] Example: For a string “12.34” as the converted result, the number of digits is four and two decimal places are given.

	Value	Remarks
F2+5	0: With zero suppress 1: Without zero suppress	Format for [F0] Select whether to execute zero suppress. Example: For a string "00012" as the converted result, specify "1".
F2+6	Valid only when F2+5 = 0 0: Leading spaces added 1: Trailing spaces added	Format for [F0] When a value in [F0] includes leading spaces, specify "0". When a value in [F1] includes trailing spaces, specify "1". Example: 0: 12 → <u> </u> 12 1: 12 → 12 <u> </u>
F2+7	0 fixed	

Example

The numerical data in \$u100 is converted to a string according to the specified attributes, and the converted result is stored in \$u300.

- Numerical data "1234": DEC without sign



```

$u00100 = 1234 (W)
$u00200 = 0 (W) [DEC without sign]
$u00201 = 0 (W) [1 word]
$u00202 = 0 (W) [DEC]
$u00203 = 4 (W) [4 digits]
$u00204 = 0 (W) [Without decimal point]
$u00205 = 0 (W) [With zero suppress]
$u00206 = 0 (W) [Leading spaces added]
$u00207 = 0 (W) [0 fixed]
FORMAT_STR $u00300 $u00100 $u00200
The result "1234" is stored in $u300 and $u301.
    
```

- Numerical data "1234": DEC without sign format and with zero suppress and leading spaces

```

$u00100 = 1234 (W)
$u00200 = 0 (W) [DEC without sign]
$u00201 = 0 (W) [1 word]
$u00202 = 0 (W) [DEC]
$u00203 = 6 (W) [6 digits]
$u00204 = 0 (W) [Without decimal point]
$u00205 = 0 (W) [With zero suppress]
$u00206 = 0 (W) [Leading spaces added]
$u00207 = 0 (W) [0 fixed]
FORMAT_STR $u00300 $u00100 $u00200
The result "  1234" is stored in $u300 to $u302.
    
```

- Numerical data "1234": DEC without sign format and with zero suppress and trailing spaces

```

$u00100 = 1234 (W)
$u00200 = 0 (W) [DEC without sign]
$u00201 = 0 (W) [1 word]
$u00202 = 0 (W) [DEC]
$u00203 = 6 (W) [6 digits]
$u00204 = 0 (W) [Without decimal point]
$u00205 = 0 (W) [With zero suppress]
$u00206 = 1 (W) [Trailing spaces added]
$u00207 = 0 (W) [0 fixed]
FORMAT_STR $u00300 $u00100 $u00200

```

The result "1234_ _" is stored in \$u300 to \$u302.
- Numerical data "1234": DEC without sign format and without zero suppress

```

$u00100 = 1234 (W)
$u00200 = 0 (W) [DEC without sign]
$u00201 = 0 (W) [1 word]
$u00202 = 0 (W) [DEC]
$u00203 = 6 (W) [6 digits]
$u00204 = 0 (W) [Without decimal point]
$u00205 = 1 (W) [Without zero suppress]
$u00206 = 0 (W) [Leading spaces added]
$u00207 = 0 (W) [0 fixed]
FORMAT_STR $u00300 $u00100 $u00200

```

The result "001234" is stored in \$u300 to \$u302.
- Numerical data "12.34": DEC with a negative sign format and with two decimal places

```

$u00100 = 1234 (W)
$u00200 = 1 (W) [DEC with a negative sign]
$u00201 = 0 (W) [1 word]
$u00202 = 0 (W) [DEC]
$u00203 = 4 (W) [4 digits]
$u00204 = 2 (W) [Two decimal places]
$u00205 = 0 (W) [With zero suppress]
$u00206 = 0 (W) [Leading spaces added]
$u00207 = 0 (W) [0 fixed]
FORMAT_STR $u00300 $u00100 $u00200

```

The result "_12.34" is stored in \$u300 to \$u302.
(For a positive value, a space code 20H is added to the leftmost position.)
- Numerical data "1234.00": FLOAT

```

$u00100 = 1234 (D)
$u00100(F) <- $u00100(D) 0 (D)
$u00200 = 6 (W) [FLOAT]
$u00201 = 0 (W) [0 fixed]
$u00202 = 0 (W) [0 fixed]
$u00203 = 6 (W) [6 digits]
$u00204 = 2 (W) [Two decimal places]
$u00205 = 0 (W) [With zero suppress]
$u00206 = 0 (W) [Leading spaces added]
$u00207 = 0 (W) [0 fixed]
FORMAT_STR $u00300 $u00100 $u00200

```

The result "_1234.00" is stored in \$u300 to \$u303.
(For a positive value, a space code 20H is added to the leftmost position.)

Supplemental remarks

- Conversion with this macro is in the order of LSB → MSB.
- A NULL code is added to the end of the string as a result of conversion. Even-number-byte string thereby uses one extra word.
- The following PLCs provided with PLC-specific data format are capable of handling negative values in BCD with a sign format. When you run this macro using such a value with any of these PLCs, the internal memory is not valid for [F1]. Therefore, be sure to assign the PLC memory (specific to the PLC model) to [F1].
 - Fuji Electric: All of the MICREX-F series
 - Yaskawa: Memobus [Trans. Mode: Type 1]
 - Omron: All [Transmission Mode 2]
- The result of macro execution is stored in \$s1057.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

4.8 Transfer

MOV


All models	<input type="radio"/>
------------	-----------------------

F0 = F1 (W) WORD

F0 = F1 (D)..... DWORD

Function: Transfer

This macro command is used to transfer the data at the address specified in [F1] to the address in [F0].



Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙	⊙	⊙	
F1	⊙	⊙	⊙	○

○ : Setting enabled (indirect designation disabled)


⊙ : Setting enabled (indirect designation enabled)

Setting range


	WORD	DWORD
F0	0000 - FFFF (HEX)	00000000 - FFFFFFFF (HEX)
F1		

Example

- \$u100 = PLC1 [D200] (W)



- \$u100 = PLC1 [D200] (D)



Supplemental remarks

- The result of macro execution is stored in \$s1057. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

BMOV


All models	<input type="radio"/>
------------	-----------------------

F0 = F1 C : F2 (BMOV)(W)..... WORD
F0 = F1 C : F2 (BMOV)(D)..... DWORD


Function: Block transfer

This macro command is used to transfer the data at the location starting from the address specified in [F1] in a block to the top address in [F0]. The data count is specified in [F2].

WORD



DWORD



Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙	⊙	⊙	
F1	⊙	⊙	⊙	
F2	○			○

○ : Setting enabled (indirect designation disabled)
 ⊙ : Setting enabled (indirect designation enabled)

Setting range


	WORD	DWORD
F0	0000 - FFFF	00000000 - FFFFFFFF
F1	(HEX)	(HEX)
F2	0 - 4096	0 - 4096

Example


- \$u100 = PLC1 [D200] C : 3 (BMOV) (W)



- PLC2 [1:#C100] = \$u100 C : 4 (BMOV) (D) or
PLC2 [1:#C100] = \$u100 C : 3 (BMOV) (D)



- \$u100 = PLC2 [1:#C100] C : 4 (BMOV) (D) or
\$u100 = PLC2 [1:#C100] C : 3 (BMOV) (D)




Supplemental remarks

- If Permit Double-Word Transfer by BMOV is not checked on the [General Settings] tab window ([System Setting] → [Unit Setting] → [General Settings]), DWORD cannot be selected.
If BMOV in double-word device memory is executed though the option is not checked, the following results:

PLC2 [1:#C100] = \$u100 C : 4 (BMOV)



\$u100 = PLC2 [1:#C100] C : 4 (BMOV)



- The result of macro execution is stored in \$s1057.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

CVMOV


All models	<input type="radio"/>
------------	-----------------------

F0 = F1 C : F2 (CVMOV)(W)..... WORD
F0 = F1 C : F2 (CVMOV)(D)..... DWORD


Function: Block transfer

This macro command is used to transfer the data at the location starting from the address specified in [F1] in a block to the top address in [F0]. The data count is specified in [F2]. Depending on the PLC models, data conversion takes place at the same time.

WORD



DWORD



Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙	⊙	⊙	
F1	⊙	⊙	⊙	
F2	○			○

○ : Setting enabled (indirect designation disabled)
 ⊙ : Setting enabled (indirect designation enabled)

Setting range

	WORD	DWORD
F0	0000 - FFFF	00000000 - FFFFFFFF
F1	(HEX)	(HEX)
F2	0 - 4096	0 - 4096

Example

Refer to the operation example applicable to your PLC model. If any PLC other than listed below is in use, the operation identical to the BMOV command takes place.

Device selection		Remarks	Operation
Fuji Electric	MICREX-F Series		2
Hitachi	HIDIC-S10/2 α , S10mini		1
	HIDIC-S10/2 α , S10mini (Ethernet)		
	HIDIC-S10/4 α		
	HIDIC-S10V		
	HIDIC-S10V (Ethernet)		
OMRON	All models	[Transmission Mode: Transmission Mode 2] in the [Communication Setting] tab window	2
Siemens	S5 PG Port*		1
	S7		
	S7-200PPI		
	S7-300/400MPI		
	TI500/505		
Yaskawa	Memobus	[Transmission Mode: Type 1] in the [Communication Setting] tab window	2


Device selection (temperature controller / servo / inverter)		Remarks	Operation
IAI	PCON/ACON/SCON(MODBUS RTU)		1

- Operation 1: With Hitachi's PLC selected as PLC1
 - \$u100 = PLC1 [FW0064] C : 3 (CVMOV) (W)





In the case of WORD, the operation identical to BMOV takes place.

- \$u100 = PLC1 [FW0064] C : 3 (CVMOV) (D) or \$u100 = PLC1 [FW0064] C : 4 (CVMOV) (D)



In the case of DWORD, a swap between the higher-order word and the lower-order word takes place.

- Operation 2: With Fuji's PLC selected as PLC2
 - \$u100 = PLC2 [WM100] C : 3 (CVMOV) (W)



PLC-format data (BCD with signs) converted to binary data is stored.

- PLC2 [BD100] = \$u100 C : 2 (CVMOV) (D)



Binary data converted to PLC-format data (BCD with signs) is stored.

Supplemental remarks

- The result of macro execution is stored in \$s1057. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error


CVSMOV

All models	<input type="radio"/>
------------	-----------------------

F0 = F1 C : F2 (CVSMOV) (W) WORD
F0 = F1 C : F2 (CVSMOV) (D)..... DWORD

Function: Block transfer with text process conversion

This macro command is used to transmit the data at the location starting from the address specified in [F1] in a block to the top address in [F0]. The data count is specified in [F2]. In transfer from the internal device memory to the PLCn device memory, from the PLCn device memory to the internal device memory, or from PLCm device memory to the PLCn device memory, text conversion is executed at the same time.

**Available device memory**

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙	⊙	⊙	
F1	⊙	⊙	⊙	
F2	○			○

○ : Setting enabled (indirect designation disabled)

⊙ : Setting enabled (indirect designation enabled)

Setting range

	Value	Remarks
F0	Text	102 bytes maximum (Varies depending on the bytes of the text)
F0+1		
:		
F1	Text	102 bytes maximum (Varies depending on the bytes of the text)
F1+1		
:		
F2	0 - 100	100 bytes maximum

Example

- When the [Communication Setting] → [Text Process] setting for the PLC that is the transfer destination (PLC3) is [MSB → LSB]:
- PLC3 [D100] = \$u100 C : 8 (CVSMOV) (W)

\$u100	7	4	7	3	HEX	ts
\$u101	6	9	7	2	HEX	ir
\$u102	6	7	6	E	HEX	gn
\$u103	0	0	0	0	HEX	Null code
	↓ CVSMOV					
D100	7	3	7	4	HEX	ts
D101	7	2	6	9	HEX	ir
D102	6	E	6	7	HEX	gn
D103	0	0	0	0	HEX	Null code

Supplemental remarks

- A null code is added to the end. Even-number-byte text thereby uses one extra word.
- The result of macro execution is stored in \$s1057.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error


FILL

F0 = F1 C : F2 (FILL)

All models	<input type="radio"/>
------------	-----------------------

Function: Transfer all

This macro command is used to write the data specified in [F1] to the words starting from the address in [F0]. The number of the words is specified in [F2].



Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙	⊙		
F1	○			○
F2	○			○


○ : Setting enabled (indirect designation disabled)
 ⊙ : Setting enabled (indirect designation enabled)

Setting range

	WORD
F0	0000 - FFFF (HEX)
F1	
F2	0 - 4096

Example

- \$u100 = \$u200 C : 3 (FILL)



Supplemental remarks

- When a PLC device memory address is specified for [F0], code conversion is not performed.
- The result of macro execution is stored in \$s1057. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

4.9 Comparison

CMP

All models	<input type="radio"/>
------------	-----------------------

IF (F0 condition F1) LB F2 (W) WORD

IF (F0 condition F1) LB F2 (D) DWORD

Function: Comparison

This macro command is used to compare the data with signs specified in [F0] and [F1] and to execute a jump to the label in [F2] if the comparison satisfies the condition.

Conditions

Symbol	Contents
==	Equal
!=	Different
<	Less than
>	Greater than
<=	Less than or equal to
>=	Greater than or equal to

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙			○
F1	⊙			○
F2				○

○ : Setting enabled (indirect designation disabled)

⊙ : Setting enabled (indirect designation enabled)

Setting range

	WORD	DWORD
F0	0000 - FFFF	00000000 - FFFFFFFF
F1	(HEX)	(HEX)
F2	0 - 127	0 - 127

Example

- IF (\$u100 == 500) LB 0 (W)
RET
LB0
:

If \$u100 = 500, a jump to LB0 (label 0) takes place and then macro execution proceeds to the next line.

If \$u100 ≠ 500, macro execution proceeds to the next line. In this example, RET terminates the macro.

Supplemental remarks

- A label (LB) must be specified as the jump target. If no label exists, "Error: 83" (no destination label for the jump) occurs as a result of an error check on MONITOUCH.
- The result of macro execution is stored in \$s1058.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

TST

All models	<input type="radio"/>
------------	-----------------------

IF condition (F0 & F1) LB F2 (W) WORD
IF condition (F0 & F1) LB F2 (D)..... DWORD

Function: Comparison with 0

This macro command is used to compare the result of [F0] ANDed with [F1] with "0", and to execute a jump to the label specified in [F2] if the comparison satisfies the condition.

Conditions

Conditions	Contents
ZERO	0
NON ZERO	Other than 0

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙			○
F1	⊙			○
F2				○

○ : Setting enabled (indirect designation disabled)
 ⊙ : Setting enabled (indirect designation enabled)

Setting range

	WORD	DWORD
F0	0000 - FFFF	00000000 - FFFFFFFF
F1	(HEX)	(HEX)
F2	0 - 127	0 - 127

Example

- IFNZ (\$u100 & 8000H) LB0 (W)
 RET
 LB0
 :

If bit 15 at \$u100 is set (ON), a jump to LB0 (label 0) takes place and then macro execution proceeds to the next line.
 If bit 15 at \$u100 is reset (OFF), macro execution proceeds to the next line. In this example, RET terminates the macro.

Supplemental remarks

- A label (LB) must be specified as the jump target. If no label exists, "Error: 83" (no destination label for the jump) occurs as a result of an error check on MONITOUCH.
- The result of macro execution is stored in \$s1058. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

IF
ELSE
ENDIF

IF (F0 (condition 1) F1) (W) WORD
IF (F0 (condition 1) F1) (D)..... DWORD
IF (condition 2) (F0) (B) BIT

All models	<input type="radio"/>
------------	-----------------------

(1)
ELSE
(2)
ENDIF

Function: Conditional branch

For WORD or DWORD, this macro command is used to compare [F0] and [F1], and to execute processing (1) if true, or (2) if false.
For BIT, [F0] and condition 2 is compared, and processing (1) is executed if true, or (2) if false.
Processing of "ELSE" and (2) can be omitted.



Condition 1

Symbol	Contents
==	Equal
!=	Different
<	Less than
>	Greater than
<=	Less than or equal to
>=	Greater than or equal to

Condition 2

Symbol	Contents
ZERO	0
NON ZERO	Other than 0

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙	⊙	⊙	○
F1	⊙	⊙	⊙	○

○ : Setting enabled (indirect designation disabled)
⊙ : Setting enabled (indirect designation enabled)

Setting range

	WORD	DWORD	BIT
F0	-32768 - +32767	-2147483648 - +2147483647	0, 1
F1	(Decimal system with signs)	(Decimal system with signs)	-

Example

- For WORD comparison
IF (\$u100 < 10) (W)
\$u100 = \$u100 + 1 (W)
ELSE
\$u100 = 0 (W)
ENDIF
"\$u100 = \$u100 + 1" is executed when \$u100 is smaller than 10. When \$u100 is 10 or more, "\$u100 = 0" is executed.

- For BIT comparison
 IFNZ (\$u100-00) (B)
 \$u100 = \$u100 + 1 (W)
 ELSE
 \$u100 = 0 (W)
 ENDIF
 “\$u100 = \$u100 + 1” is executed when \$u100-00 is set (ON). When \$u100-00 is reset (OFF), “\$u100 = 0” is executed.

Restrictions

- IF-ELSE-ENDIF commands can be nested up to 8 levels.

Supplemental remarks

- An error occurs to the macro editor when any of the following conditions is met.

1. When IF-ELSE-ENDIF commands are nested beyond 8 levels;

Ex.: IF (\$u100 > 0)
 IF (\$u100 < 10)
 :
 IF (\$u200 == 1)
 ENDIF

) × There are 9 or more IF commands between IF-ENDIF commands.

2. When the number of IF commands is not the same as the one of ENDIF commands;

Ex.: IF (\$u100 == 0)
 IF (\$u100 == 0)
 ENDIF

) × There are two IF commands while there is one ENDIF command.

3. When the number of IF commands is not the same as the one of ELSE commands;

Ex.: IF (\$u100 == 0)
 ELSE
 ELSE
 ENDIF

) × There is one IF command while there are two ELSE commands.

4. When FOR and NEXT commands are specified in a series of IF-ELSE-ENDIF commands.

Ex.: IF (\$u100 == 0)
 FOR 10
 ELSE
 ENDIF
 NEXT

) × Only ELSE and ENDIF commands are specified between FOR and NEXT commands.

- The result of macro execution is stored in \$s1059.
 When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error*

* When reading from [F0] and [F1] ends in failure, an error occurs and “-1” is stored in \$s1059.
 When an execution error occurs, it is regarded as a fault.

4.10 Macro Operation Control


CALL

All models	<input type="radio"/>
------------	-----------------------

CALL F0

Function: Macro block number designation

This macro command is used to execute the macro block specified in [F0].



Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	<input type="radio"/>			<input type="radio"/>

: Setting enabled (indirect designation disabled)


: Setting enabled (indirect designation enabled)

Setting range

	Value
F0	0 - 1023


Example

- CALL 5



Supplemental remarks

- If the macro block number called by CALL is not registered, an error check triggers a warning.
- The macro command can be nested up to 8 levels.
Ex.) 2 levels



- The result of macro execution is stored in \$s1059. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	End in error (9 or more levels of macro commands are nested, an attempt is made to execute macro commands of 160001 lines or more, etc.)


JMP

JMP LB F0

All models	<input type="radio"/>
------------	-----------------------

Function: Unconditional jump

This macro command is used to execute a jump to the label specified in [F0].



Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0				<input type="radio"/>

○ : Setting enabled (indirect designation disabled)


⊙ : Setting enabled (indirect designation enabled)

Setting range

	Value
F0	0 - 127

Example

- JMP LB5



Supplemental remarks

- A label (LB) must be specified as the jump target. If no label exists, error 83 (there is no destination label for the jump) will be detected by error check on MONITOUCH.
- The result of macro execution is stored in \$s1059. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	End in error (number of executed macro lines of 160001 or greater, etc.)


LABEL

All models	<input type="radio"/>
------------	-----------------------

LB F0:

Function: Label number

This macro command is used to create jump target labels for CMP, TST, and JMP.



Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0				<input type="radio"/>

: Setting enabled (indirect designation disabled)

: Setting enabled (indirect designation enabled)

Setting range

	Value
F0	0 - 127

Supplemental remarks

- A label (LB) must be specified as the jump target. If no label exists, error 83 (there is no destination label for the jump) will be detected by error check on MONITOUCH.
- The result of macro execution is stored in \$s1059. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	End in error (number of executed macro lines of 160001 or greater, etc.)

FOR/NEXT

All models	<input type="radio"/>
------------	-----------------------

**FOR F0
NEXT**

Function: FOR - NEXT

This macro command is used to execute a loop between FOR and NEXT the number of times specified in [F0].

```
FOR F0
  $u300 = $u300+5 ← The loop executes the number
NEXT                               of times specified in F0.
```

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	<input type="radio"/>			<input type="radio"/>

: Setting enabled (indirect designation disabled)
 : Setting enabled (indirect designation enabled)



Setting range

	Value
F0	0 - 65535

Example

```
$u300 = 0 (W)
$u301 = 0 (W)
FOR 3
  $u300 = $u300 + 1 (W)
  FOR $u400
    $u301 = $u301 + 5 (W)
  NEXT
NEXT
```


If \$u400 = 5, the loop is executed 5 times.

The loop is executed 3 times.

- Result
 \$u300 = 3
 \$u301 = 75

Supplemental remarks

- Loop between FOR and NEXT can be nested* up to 8 levels. Nesting beyond 8 levels triggers error 81 (macro: FOR-NEXT command number is wrong) as a result of error check on MONITOUCH.
 * Nesting means incorporating a FOR-NEXT loop into a loop of the same kind.



- The result of macro execution is stored in \$s1059. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	End in error (nesting of 9 or more levels / number of executed macro lines of 160001 or greater, etc.)

RET

All models	<input type="radio"/>
------------	-----------------------


RET**Function: Macro finish**

This macro command is used to finish a macro. Any lines after RET are not executed.

\$u300 = 1 (W)	← Execute
\$u301 = 10 (W)	← Execute
RET	← Finish
\$u302 = 100 (W)	← Not executed
\$u303 = 1000 (W)	← Not executed

Supplemental remarks

- In the case of a macro block called by CALL, RET executes a return to the original sequence.



SWRET

All models	<input type="radio"/>
------------	-----------------------

SWRET


Function: Execute switch function

This macro command is used in a switch ON macro.

- With SWRET:
Processing takes place in the order of the interruption of the macro, the execution of the switch function, and the execution of the remaining program of the macro.




- Without SWRET:
Processing takes place in the order of the execution of the switch ON macro and the execution of the switch function.




Example

- In a case where a macro runs based on the result written by the ENT key (in the entry mode) to the entry target D200, executing the switch function (for writing) by SWRET is required.



Supplemental remarks

- The macro command is valid in switch ON macros. The command, however, is not executed normally in the following cases:
 - SWRET exists in a macro block called by CALL.
 - JMP or FOR-NEXT triggers a movement to a label before the execution of SWRET.



EN_INT


All models




EN_INT

Function: Enabling interruption of switch processing

If a switch on the V series unit is pressed during the execution of macro processing, the switch processing is not executed immediately but is delayed until completion of the macro sheet.



When this command is executed while switch processing is pending, macro processing is suspended while the switch processing is executed. On completion of the switch processing macro execution is continued from the point of suspension.

**Supplemental remarks**

- If there is no switch processing pending, nothing happens in response to this command.

4.11 FROM Backup

In the FP-ROM (flash memory) for the V series screen program, its empty area can be used to back up the PLC device memory, internal device memory, and memory card. A maximum of 16k words can be allocated to the backup area.

FROM_WR

All models	<input type="radio"/>
------------	-----------------------

FROM_WR F0 F1

Function: Write to FROM

This macro command is used to write the data of words starting from the address specified in [F0] to the FP-ROM. The number of the words is specified in [F1].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙	⊙	⊙	
F1				○

○ : Setting enabled (indirect designation disabled)

⊙ : Setting enabled (indirect designation enabled)

Setting range

	Value
F0	Address in each device memory
F1	1 - 16384 (= 16k words)

Supplemental remarks

- When using the macro command, go to the [General Settings] tab window in the [Unit Setting] dialog ([System Setting] → [Unit Setting] → [General Settings]). On the window, check [Use Internal Flash ROM as Back-up Area].
 - * Checking this option reduces the available screen program capacity by 66 kbytes.
- Do not turn off the power supply of the V series while executing the macro command.
- Each FP-ROM allows 100,000 write operations. (Each execution of FROM_WR is counted as one time, regardless of the number of words.) It is thereby recommended that backup data be read after power-on and be written before power-off.
- Do not execute FROM_WR in every cycle using a CYCLE macro, etc.
- Writing to FP-ROM takes three to five seconds.
- The result of macro execution is stored in \$s728.

When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

FROM_RD

FROM_RD F0 F1

All models	<input type="radio"/>
------------	-----------------------

Function: Read from FROM

This macro command is used to read the data of words from the FP-ROM into the address specified in [F0]. The number of the words is specified in [F1].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙	⊙	⊙	
F1				○

○ : Setting enabled (indirect designation disabled)

⊙ : Setting enabled (indirect designation enabled)

Setting range

	Value
F0	Address in each device memory
F1	1 - 16384 (= 16k words)

Supplemental remarks

- When using the macro command, go to the [General Settings] tab window in the [Unit Setting] dialog ([System Setting] → [Unit Setting] → [General Settings]). On the window, check Use Internal Flash ROM as Back-up Area].
* Checking this option reduces the available screen program capacity by 66 kbytes.
- Do not execute FROM_RD in every cycle using a CYCLE macro, etc.
- The result of macro execution is stored in \$s728.

When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

4.12 Printer

The following macro commands are used to send commands to the printer connected with the V series:

MR_OUT

All models	<input type="radio"/>
------------	-----------------------

MR_OUT F0

Function: Execution of MR400 format table call setting number

This macro command is used to print the data in the format table (call setting number) specified in [F0].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙	⊙	⊙	○

○: Setting enabled (indirect designation disabled)

⊙: Setting enabled (indirect designation enabled)

Setting range

	Value
F0	1 - 128: Format table (call setting) number

Example

- MR_OUT 50

The above program prints the contents of the MR400 format table (call setting) No. 50.



Supplementary remarks

- The macro command is valid when [MR-400] is selected for [Model] at [System Setting] → [Hardware Setting] → [Printer].
- The result of macro execution is stored in \$s1060. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

MR_REG

All models	<input type="radio"/>
------------	-----------------------

MR_REG F0

Function: Execution of the MR400 format table registration setting number

This macro command is used to write the data in the format table (registration setting number) specified in [F0] to the memory card.

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙	⊙	⊙	○


○: Setting enabled (indirect designation disabled)
 ⊙: Setting enabled (indirect designation enabled)

Setting range

	Value
F0	1 - 128: Format table (registration setting) number

Example

- MR_REG 22



The memory card can be formatted.

- MR_REG 1



First: Format is registered as registration No. 1 in the MR400 memory card.

Second: Registration No. 1 contents are printed and the format can be checked.



Supplementary remarks

- The macro command is valid when [MR-400] is selected for [Model] in the [System Setting] → [Hardware Setting] → [Connection Device Selection] window of a printer.
- The result of macro execution is stored in \$s1060.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

OUT_PR

All models	○
TELLUS4 HMI	△

OUT_PR F0 F1

Function: Command output to printer

This macro command is used to send [F1]-specified bytes of data from the address specified in [F0] to the printer.

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙	⊙	⊙	
F1	⊙	⊙	⊙	○

○: Setting enabled (indirect designation disabled)

⊙: Setting enabled (indirect designation enabled)

Setting range

	Value
F0	Command for each printer*
F0+1	
:	
F0+ (F1/2-1)	
F1	1 - 255: Number of bytes

* TELLUS4 is supported only when printing with a barcode label printer from SATO.

Example

- Paper feed and auto cut are performed on the CBM (293) printer.

From the command table in the CBM printer manual:

1BH4AHn (paper feed n/360 in.)

Auto cutter drive partial cut: 1BH6DH

Code to be sent to the printer: 1BH 4AH 96H 1BH 6DH
n=150

Macros

\$u100 = 4A1BH

\$u101 = 1B96H

\$u102 = 006DH

OUT_PR \$u100 5


} Set in the little endian* system.

Supplementary remarks

- Little endian:
Data of two bytes or more are divided and transferred one byte at a time.
This divided data is recorded/transmitted from the least significant byte.

Little endian

Big endian



- The command name varies by the printer model.
The V series does not check the validity of the command before transmitting the command. Refer to the instruction manual for the printer and set the command correctly.
- The result of macro execution is stored in \$s1060.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

4.13 Video

VIDEO

V9 Advanced	
V910xiW	○
V907xiW	
V9 Standard	
All models	○
V9 Lite	
All models	
TELLUS	
TELLUS4 HMI	△

VIDEO MEMORY F1Device Memory Designation

Function 1: Size

This macro command is used to change the video display size to the size specified in [F1+1].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	○			

○: Setting enabled (indirect designation disabled)


◎: Setting enabled (indirect designation enabled)

Setting range

	Value
F0	MEMORY
F1	0: Size
F1+1	0: 160 × 120
	1: 320 × 240
	2: 640 × 480
	3: 640 × 240

Example

```
$u100 = 0 (W) [Size]
$u101 = 0 (W) [160 × 120]
VIDEO MEMORY $u100
```



The above program changes the video display size to 160 × 120.

Supplementary remarks

- The macro command is valid when a [Video Overlap] display is placed.
- The result of macro execution is stored in \$s1061. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

Function 2: Size (dot)

This macro command is used to change the video display size to the size specified in [F1+1] and [F1+2] (by dots).

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	○			

○: Setting enabled (indirect designation disabled)

⊙: Setting enabled (indirect designation enabled)

Setting range

	Value
F0	MEMORY
F1	7: Size (dot)
F1+1	1: ? Width 1024:
F1+2	1: ? Height 768:

Example

```
$u100 = 7 (W)    [Size (dot)]
$u101 = 100 (W) [Width 100]
$u102 = 75 (W)  [Height 75]
VIDEO MEMORY $u100
```

The above program changes the video display size to 100 × 75.

Supplementary remarks

- The macro command is valid when a [Video Overlap] display is placed.
- The result of macro execution is stored in \$s1061.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

Function 3: Channel

This macro command is used to change the video display to the channel specified in [F1+1].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	○			

○: Setting enabled (indirect designation disabled)

⊙: Setting enabled (indirect designation enabled)

Setting range


	Value
F0	MEMORY
F1	1: Channel
F1+1	1: 1CH
	2: 2CH
	3: 3CH
	4: 4CH

Example

\$u100 = 1 (W) [Channel]

\$u101 = 2 (W) [2CH]

VIDEO MEMORY \$u100



The above program changes the video display to channel 2.

Supplementary remarks

- The macro command is valid when a [Video Overlap] display is placed.
- The result of macro execution is stored in \$s1061.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

Function 4: Brightness

This macro command is used to change the brightness of the video display to the brightness specified in [F1+1].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	○			

○: Setting enabled (indirect designation disabled)

⊙: Setting enabled (indirect designation enabled)

Setting range

	Value
F0	MEMORY
F1	3: Brightness
F1+1	0: Dark ? 255: Bright

Example

- \$u100 = 3 (W) [Brightness]
- \$u101 = 100 (W) [Brightness 100]
- VIDEO MEMORY \$u100

The above program changes the brightness level of the video display to "100".

Supplementary remarks

- The macro command is valid when a [Video Overlap] display is placed.
- The result of macro execution is stored in \$s1061.

When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

Function 5: Contrast

This macro command is used to change the contrast of the video display to the contrast specified in [F1+1].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	○			

○: Setting enabled (indirect designation disabled)

◎: Setting enabled (indirect designation enabled)

Setting range

	Value
F0	MEMORY
F1	4: Contrast
F1+1	0: Low 255: High

Example

- \$u100 = 4 (W) [Contrast]
- \$u101 = 150 (W) [Contrast 150]
- VIDEO MEMORY \$u100

The above program changes the contrast level of the video display to "150".

Supplementary remarks

- The macro command is valid when a [Video Overlap] display is placed.
- The result of macro execution is stored in \$s1061.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

Function 6: Color intensity

This macro command is used to change the color intensity of the video display to the intensity specified in [F1+1].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	○			

○: Setting enabled (indirect designation disabled)

⊙: Setting enabled (indirect designation enabled)

Setting range

	Value
F0	MEMORY
F1	5: Color intensity
F1+1	0: Light ? 255:Dark

Example

- \$u100 = 5 (W) [Color intensity]
 - \$u101 = 120 (W) [Color intensity 120]
- VIDEO MEMORY \$u100

The above program changes the color intensity level of the video display to "120".

Supplementary remarks

- The macro command is valid when a [Video Overlap] display is placed.
- The result of macro execution is stored in \$s1061.

When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

Function 7: Save settings/reset to default

This macro command is used to save the current video settings or to reset them to default.

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	○			

○: Setting enabled (indirect designation disabled)

⊙: Setting enabled (indirect designation enabled)

Setting range

	Value	Default	
F0	MEMORY	-	
F1	6: Video_INF	-	
F1+1	0: SAVE	-	
F1+1	1: DEFAULT	BRIGHT	128
		CONTRAST	128
		COLOR	128

Example

- \$u100 = 6 (W) [Video_INF]

- \$u101 = 0 (W) [SAVE]

- VIDEO MEMORY \$u100

The above program saves the video settings. The settings are maintained even after the V series is turned off.

Supplementary remarks

- The macro command is valid when a [Video Overlap] display is placed.
- Do not turn off the power supply of the V series while executing the macro command.
- After the SAVE command has been executed, the video settings are maintained even after power-off.
- The execution of "VIDEO INF DEFAULT" may cause the V series to pause approximately for one second.
- The result of macro execution is stored in \$s1061.

When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

VIDEO SIZE F1 Command Designation

Function: Size


This macro command is used to change the video display size to the size specified in [F1].

Setting range

	Value
F0	SIZE
F1	160*120 320*240 640*480 640*240

Example

- VIDEO SIZE 160*120



The above program changes the video display size to 160 × 120.

Supplementary remarks

- The macro command is valid when a [Video Overlap] display is placed.
- The result of macro execution is stored in \$s1061.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

VIDEO SIZE F1 F2. Command Designation

Function: Size (dot)

This macro command is used to change the video display size to the size specified in [F1] and [F2] (by dots).

Setting range

	Value
F0	SIZE(Dot)
F1	1: Width 1024:
F2	1: Height 768:

Example

VIDEO SIZE 100 75

The above program changes the video display size to 100 × 75.

Supplementary remarks

- The macro command is valid when a [Video Overlap] display is placed.
- The result of macro execution is stored in \$s1061.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

VIDEO SEL_CH F1..... Command Designation

Function: Channel


This macro command is used to change the video display to the channel specified in [F1].

Setting range

	Value
F0	SEL_CH
F1	1 2 3 4

Example

- VIDEO SEL_CH2



The above program changes the video display to channel 2.

Supplementary remarks

- The macro command is valid when a [Video Overlap] display is placed.
- The result of macro execution is stored in \$s1061.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

VIDEO BRIGHT F1 Command Designation

Function: Brightness

This macro command is used to change the brightness of the video display to the brightness specified in [F1].

Setting range

	Value
F0	BRIGHT
F1	0: Dark 255: Bright

Example

- VIDEO BRIGHT 100
The above program changes the brightness level of the video display to "100".

Supplementary remarks

- The macro command is valid when a [Video Overlap] display is placed.
- The result of macro execution is stored in \$s1061.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

VIDEO CONTRAST F1 Command Designation**Function: Contrast**

This macro command is used to change the contrast of the video display to the contrast specified in [F1].

Setting range

	Value
F0	CONTRAST
F1	0: Low 255: High

Example

- VIDEO CONTRAST 150

The above program changes the contrast level of the video display to “150”.

Supplementary remarks

- The macro command is valid when a [Video Overlap] display is placed.
- The result of macro execution is stored in \$s1061.

When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

VIDEO COLOR F1 Command Designation

Function: Color intensity

This macro command is used to change the color intensity of the video display to the intensity specified in [F1].

Setting range

	Value
F0	COLOR
F1	0: Light 255: Dark

Example

- VIDEO COLOR 120

The above program changes the color intensity level of the video display to "120".

Supplementary remarks

- The macro command is valid when a [Video Overlap] display is placed.
- The result of macro execution is stored in \$s1061.

When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

VIDEO INF F1 Command Designation

Function: Save settings/reset to default

This macro command is used to save the current video settings or to reset them to default.

Setting range

	Value	Default	
F0	INF	-	
F1	SAVE	-	
F1	DEFAULT	BRIGHT	128
		CONTRAST	128
		COLOR	128

Example

- VIDEO INF SAVE

The above program saves the video settings. The settings are maintained even after the V series is turned off.

Supplementary remarks

- The macro command is valid when a [Video Overlap] display is placed.
- Do not turn off the power supply of the V series while executing the macro command.
- After the SAVE command has been executed, the video settings are maintained even after power-off.
- The execution of "VIDEO INF DEFAULT" may cause the V series to pause approximately for one second.
- The result of macro execution is stored in \$s1061.

When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

VIDEO2

V9 Advanced	
V910xiW	○
V907xiW	
V9 Standard	
All models	○
V9 Lite	
All models	
TELLUS	
TELLUS4 HMI	△

VIDEO2 MEMORY F1Device Memory Designation

Function 1: Single snapshot

This macro command is used to save a snapshot of the channel specified in [F1+1] to a storage device using the file number specified in [F1+2].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	○			

○: Setting enabled (indirect designation disabled)

⊙: Setting enabled (indirect designation enabled)

Setting range

	Value
F0	MEMORY
F1	0: SNAP
F1+1	1: 1CH
	2: 2CH
	3: 3CH
	4: 4CH
	5: 5CH (RGB)
	6: 6CH (RGB)
	-1: Auto *1
F1+2	0000: ↑ File number
	32767:
	-1: Auto *2

***1 Auto: CH**


- During "ZOOM", the macro command is executed with respect to the channel set for zooming.
- Tap the display area to select the channel for executing the macro command. The tapped channel number is stored in \$s934.
- When "ZOOM" is not in use and a channel is not selected by tapping, the macro command is executed as follows:
 - When only one channel is displayed, the macro command is executed for the displayed channel.
 - When multiple channels are displayed, the command is invalid.

***2 Auto: File**

If no files exist in the storage device, files are numbered by incrementing, starting from "0". If there are files in the storage device, files are numbered by incrementing the existing maximum file number. When the incremented value reaches [Maximum Number of Snap Files in Auto] in the [Video/RGB Setting] window, the subsequent action depends on the option selected for [When the Snap File Limitation is Exceeded]. With [Stop] selected, any further execution of the macro command is invalid. With [Overwrite] selected, the incremented value will be reset to "0" and the files will be overwritten.

Example

- \$u100 = 0 (W) [SNAP]
- \$u101 = 1 (W) [1CH]
- \$u102 = 5 (W) [File No. 5]
- VIDEO2 MEMORY \$u100



Supplementary remarks

- The macro command is valid when a video image is displayed on the V series with a storage device connected.
- The result of macro execution is stored in \$\$s1061. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

Function 2: Background snapshot

This macro command is used to save a snapshot of the channel specified in [F1+1] in the size specified in [F1+3] to a storage device using the file number specified in [F1+2].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	○			

○: Setting enabled (indirect designation disabled)

⊙: Setting enabled (indirect designation enabled)

Setting range

	Value
F0	MEMORY
F1	11: SNAP (background)
F1+1	1: 1CH
	2: 2CH
	3: 3CH
	4: 4CH
	5: 5CH (RGB)
	6: 6CH (RGB)
F1+2	00000: ? File number
	32767:
	-1: Auto *1
F1+3	0: 160 × 120
	1: 320 × 240
	2: 640 × 480
	3: 640 × 240 *2

*1 Auto: File


If no files exist in the storage device, files are numbered by incrementing, starting from "0". If there are files in the storage device, files are numbered by incrementing the existing maximum file number.

When the incremented value reaches [Maximum Number of Snap Files in Auto] in the [Video/RGB Setting] window, the subsequent action depends on the option selected for [When the Snap File Limitation is Exceeded]. With [Stop] selected, any further execution of the macro command is invalid. With [Overwrite] selected, the incremented value will be reset to "0" and the files will be overwritten.

*2 The snapshot area is distinguished based on the value at §957.

Example

- \$u100 = 11 (W) [Background snapshot]
- \$u101 = 1 (W) [1CH]
- \$u102 = 1000 (W) [File No.]
- \$u103 = 0 (W) [Size]
- VIDEO2 MEMORY \$u100



The above program saves the image of channel 1 in a size of 160 × 120 as “VD01000.jpg”.

Supplementary remarks

- The macro command is valid when a storage device is connected to the V series.
- Even if no video item setting is made in the screen program, the macro command takes a snapshot of the specified channel.
- If “PAUSE” is being executed for the specified channel, the channel image is re-captured and then a snapshot is taken.
- If the image of the specified channel is being zoomed in, zooming is canceled while the macro command is taking a snapshot.
- The result of macro execution is stored in \$s1061.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

Function 3: Strobe snapshot

This macro command is used to save a strobe snapshot of the channel specified in [F1+1] to a storage device using the file number specified in [F1+2].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	○			

○: Setting enabled (indirect designation disabled)

⊙: Setting enabled (indirect designation enabled)

Setting range

	Value
F0	MEMORY
F1	1: STROBE
F1+1	1: 1CH
	2: 2CH
	3: 3CH
	4: 4CH
	5: 5CH (RGB)
	6: 6CH (RGB)
	-1: Auto *1
F1+2	00000: ↵ File number 32767: -1: Auto *2

*1 Auto: CH


- During "ZOOM", the macro command is executed with respect to the channel set for zooming.
- Tap the display area to select the channel for executing the macro command. The tapped channel number is stored in \$s934.
- When "ZOOM" is not in use and a channel is not selected by tapping, the macro command is executed as follows:
 - When only one channel is displayed, the macro command is executed for the displayed channel.
 - When multiple channels are displayed, the command is invalid.

*2 Auto: File

If no files exist in the storage device, files are numbered by incrementing, starting from "0". If there are files in the storage device, files are numbered by incrementing the existing maximum file number. When the incremented value reaches [Maximum Number of Snap Files in Auto] in the [Video/RGB Setting] window, the subsequent action depends on the option selected for [When the Snap File Limitation is Exceeded]. With [Stop] selected, any further execution of the macro command is invalid. With [Overwrite] selected, the incremented value will be reset to "0" and the files will be overwritten.

Example

- \$u100 = 1 (W) [STROBE]
- \$u101 = 1 (W) [1CH]
- \$u102 = 15 (W) [File No.]
- VIDEO2 MEMORY \$u100



Supplementary remarks

- The macro command is valid when a video image is displayed on the V series with a storage device connected.
- The result of macro execution is stored in \$s1061.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

Function 4: Resize

This macro command is used to resize a video image that was enlarged using the ZOOM macro command or by the strobe snapshot function to its original size.

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	○			

○: Setting enabled (indirect designation disabled)


◎: Setting enabled (indirect designation enabled)

Setting range

	Value
F0	MEMORY
F1	2: RE_SIZE

Example

- \$u100 = 2 [RE_SIZE]
VIDEO2 MEMORY \$u100



Supplementary remarks

- In addition to the RE_SIZE command, double-clicking an enlarged image resizes it to its original size.
- The result of macro execution is stored in \$s1061. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

Function 5: Zoom

This macro command is used to enlarge the image of the channel specified in [F1+1] at the position specified in [F1+2] to 640 × 480.

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	○			

- : Setting enabled (indirect designation disabled)
- ⊙: Setting enabled (indirect designation enabled)

Setting range


	Value
F0	MEMORY
F1	3: ZOOM
F1+1	1: 1CH
	2: 2CH
	3: 3CH
	4: 4CH
	5: 5CH (RGB)
	6: 6CH (RGB)
	-1: Auto *1
F1+2	0: Centering
	1: Upper right
	2: Lower left

*1 Auto: CH

- Tap the display area to select the channel for executing the macro command. The tapped channel number is stored in \$s934.
- When a channel is not selected by tapping, the macro command is executed as follows:
 - When only one channel is displayed, the macro command is executed for the displayed channel.
 - When multiple channels are displayed, the command is invalid.

Example

- \$u100 = 3 (W) [ZOOM]
- \$u101 = 1 (W) [1CH]
- \$u102 = 0 (W) [Centering]
- VIDEO2 MEMORY \$u100



The above program enlarges the image of channel 1.

Supplementary remarks

- The result of macro execution is stored in \$s1061. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

Function 6: Brightness

This macro command is used to adjust the brightness of video images of the channel specified in [F1+1] according to the value specified in [F1+2].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	○			

○: Setting enabled (indirect designation disabled)

⊙: Setting enabled (indirect designation enabled)

Setting range

	Value
F0	MEMORY
F1	4: BRIGHT
F1+1	1: 1CH
	2: 2CH
	3: 3CH
	4: 4CH
	-1: Auto *1
F1+2	0: Dark
	?
	31: Bright

*1 Auto: CH

- During "ZOOM", the macro command is executed with respect to the channel set for zooming.
- Tap the display area to select the channel for executing the macro command. The tapped channel number is stored in \$s934.
- When "ZOOM" is not in use and a channel is not selected by tapping, the macro command is executed as follows:
 - When only one channel is displayed, the macro command is executed for the displayed channel.
 - When multiple channels are displayed, the command is invalid.

Example

- \$u100 = 4 (W) [BRIGHT]
- \$u101 = 1 (W) [1CH]
- \$u102 = 10 (W)
- VIDEO2 MEMOEY \$u100

The above program changes the brightness level of channel 1 to "10".

Supplementary remarks

- The macro command is valid for video channels (1CH to 4CH) and invalid for RGB channels (5CH and 6CH).
- The result of macro execution is stored in \$s1061. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

Function 7: Contrast

This macro command is used to adjust the contrast of video images of the channel specified in [F1+1] according to the value specified in [F1+2].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	○			

○: Setting enabled (indirect designation disabled)

⊙: Setting enabled (indirect designation enabled)

Setting range

	Value
F0	MEMORY
F1	5: CONTRAST
F1+1	1: 1CH
	2: 2CH
	3: 3CH
	4: 4CH
	-1: Auto *1
F1+2	0: Low
	1: 1
	31: High

*1 Auto: CH

- During "ZOOM", the macro command is executed with respect to the channel set for zooming.
- Tap the display area to select the channel for executing the macro command. The tapped channel number is stored in \$s934.
- When "ZOOM" is not in use and a channel is not selected by tapping, the macro command is executed as follows:
 - When only one channel is displayed, the macro command is executed for the displayed channel.
 - When multiple channels are displayed, the command is invalid.

Example

- \$u100 = 5 (W) [CONTRAST]
- \$u101 = 1 (W) [1CH]
- \$u102 = 10 (W)
- VIDEO2 MEMORY \$u100

The above program changes the contrast level of channel 1 to "10".

Supplementary remarks

- The macro command is valid for video channels (1CH to 4CH) and invalid for RGB channels (5CH and 6CH).
- The result of macro execution is stored in \$s1061. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

Function 8: Color intensity

This macro command is used to adjust the color intensity of video images of the channel specified in [F1+1] according to the value specified in [F1+2].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	○			

○: Setting enabled (indirect designation disabled)

⊙: Setting enabled (indirect designation enabled)

Setting range

	Value
F0	MEMORY
F1	6: COLOR
F1+1	1: 1CH
	2: 2CH
	3: 3CH
	4: 4CH
	-1: Auto *1
F1+2	0: Light
	?
	31: Dark

*1 Auto: CH

- During "ZOOM", the macro command is executed with respect to the channel set for zooming.
- Tap the display area to select the channel for executing the macro command. The tapped channel number is stored in \$s934.
- When "ZOOM" is not in use and a channel is not selected by tapping, the macro command is executed as follows:
 - When only one channel is displayed, the macro command is executed for the displayed channel.
 - When multiple channels are displayed, the command is invalid.

Example

- \$u100 = 6 (W) [COLOR]
- \$u101 = 1 (W) [1CH]
- \$u102 = 10 (W)
- VIDEO2 MEMORY \$u100

The above program changes the color intensity of channel 1 to "10".

Supplementary remarks

- The macro command is valid for video channels (1CH to 4CH) and invalid for RGB channels (5CH and 6CH).
- The result of macro execution is stored in \$s1061. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

Function 9: Save settings/reset to default

This macro command is used to save the settings of the channel specified in [F1+1] or to reset the settings to default.

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	○			

○: Setting enabled (indirect designation disabled)

⊙: Setting enabled (indirect designation enabled)

Setting range

	Value	Default	
F0	MEMORY	-	
F1	7: VIDEOINF	-	
F1+1	1: 1CH	-	
	2: 2CH		
	3: 3CH		
	4: 4CH		
	5: 5CH (RGB)		
	6: 6CH (RGB)		
	-1: Auto *1		
F1+2	0: SAVE	-	
	1: DEFAULT	BRIGHT	16
		CONTRAST	16
		COLOR	16
		Clip start position	*2
		Image clip size	
		MODE	Odd/even-numbered fields

◻ : ← V series (return data)

*1 Auto: CH

- During "ZOOM", the macro command is executed with respect to the channel set for zooming.
- Tap the display area to select the channel for executing the macro command. The tapped channel number is stored in \$s934.
- When "ZOOM" is not in use and a channel is not selected by tapping, the macro command is executed as follows:
 - When only one channel is displayed, the macro command is executed for the displayed channel.
 - When multiple channels are displayed, the command is invalid.

*2 The default setting for the clip start position and the image clip size change according to the input signal. For more information, refer to V9 Series Reference Manual 2.

Example

- \$u100 = 7 (W) [VIDEOINF]
- \$u101 = 1 (W) [1CH]
- \$u102 = 0 (W)
- VIDEO2 MEMORY \$u100

The above program saves the video settings for channel 1.

Supplementary remarks

- Do not turn off the power supply of the V series while executing the macro command.
- After the SAVE command has been executed, the data is maintained even after power-off.
- The result of macro execution is stored in \$s1061.

When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

Function 10: Pause playback

This macro command is used to pause video playback of the channel specified in [F1+1].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	○			

○: Setting enabled (indirect designation disabled)

⊙: Setting enabled (indirect designation enabled)

Setting range

	Value
F0	MEMORY
F1	8: PAUSE
F1+1	1: 1CH
	2: 2CH
	3: 3CH
	4: 4CH
	-1: Auto *1

*1 Auto: CH

- During "ZOOM", the macro command is executed with respect to the channel set for zooming.
- Tap the display area to select the channel for executing the macro command. The tapped channel number is stored in \$s934.
- When "ZOOM" is not in use and a channel is not selected by tapping, the macro command is executed as follows:
 - When only one channel is displayed, the macro command is executed for the displayed channel.
 - When multiple channels are displayed, the command is invalid.

Example

- \$u100 = 8 (W) [PAUSE]
- \$u101 = 1 (W) [1CH]
- VIDEO2 MEMORY \$u100

The above program pauses video playback of channel 1.

Supplementary remarks

- During the execution of "PAUSE", resizing is disabled.
- The macro command is valid for video channels (1CH to 4CH) and invalid for RGB channels (5CH and 6CH).
- The result of macro execution is stored in \$s1061.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

Function 11: Pause cancel

This macro command is used to resume video playback that has been paused by the PAUSE command.

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	○			

○: Setting enabled (indirect designation disabled)

⊙: Setting enabled (indirect designation enabled)

Setting range

	Value
F0	MEMORY
F1	9: RESTART
F1+1	1: 1CH
	2: 2CH
	3: 3CH
	4: 4CH
	-1: Auto *1

*1 Auto: CH

- During "ZOOM", the macro command is executed with respect to the channel set for zooming.
- Tap the display area to select the channel for executing the macro command. The tapped channel number is stored in \$s934.
- When "ZOOM" is not in use and a channel is not selected by tapping, the macro command is executed as follows:
 - When only one channel is displayed, the macro command is executed for the displayed channel.
 - When multiple channels are displayed, the command is invalid.

Example

- \$u100 = 9 (W) [RESTART]
 - \$u101 = 1 (W) [1CH]
- VIDEO2 MEMORY \$u100

The above program resumes video playback of channel 1.

Supplementary remarks

- The macro command is valid for video channels (1CH to 4CH) and invalid for RGB channels (5CH and 6CH).
- The result of macro execution is stored in \$s1061. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

Function 12: Deletion

This macro command is used to delete the snapshot file VDxxxxx.jpg from the storage device.

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	○			

○: Setting enabled (indirect designation disabled)

◎: Setting enabled (indirect designation enabled)

Setting range

	Value
F0	MEMORY
F1	10: DELETE
F1+1	00000: ? File number 32767:

Example

- \$u100 = 10 (W) [DELETE]
 - \$u101 = 1 (W) [File No.]
- VIDEO2 MEMORY \$u100

The above program deletes the file "VD00001.jpg" from the storage device.

Supplementary remarks

- The macro command is valid when a storage device is connected to the V series.
- The result of macro execution is stored in \$s1061.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

Function 13: Change periodical snapshot

This macro command is used to change the periodical snapshot operation of the channel specified in [F1+1] to the operation specified in [F1+2].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	○			

○: Setting enabled (indirect designation disabled)

⊙: Setting enabled (indirect designation enabled)

Setting range

	Value
F0	MEMORY
F1	12: SNAP_SEQ
F1+1	1: 1CH
	2: 2CH
	3: 3CH
	4: 4CH
	5: 5CH (RGB)
	6: 6CH (RGB)
F1+2	0: Stop
	1: Start


Example

- \$u100 = 12 (W) [SNAP_SEQ]
 - \$u101 = 1 (W) [1CH]
 - \$u102 = 1 (W) [Start]
- VIDEO2 MEMORY \$u100

The above program starts taking periodical snapshots of channel 1.

Supplementary remarks


- The interval and total time for taking snapshots periodically is set as follows according to the settings of a video/RGB item in the screen program.
 - When [Periodical Snap] is selected for [Double Click Action]:



4

Total Time for Periodical Snapshot	Snapshot Interval
Same as [Operation Select] → [Total Time] setting	Same as [Operation Select] → [Intervals] setting

- When other than [Periodical Snap] is selected for [Double Click Action]:



Total Time for Periodical Snapshot	Snapshot Interval
One minute (Fixed)	Same as [Operation Select] → [Strobe Speed] setting*

* When this setting is shorter than 1 sec, the interval is 1 sec.

- The result of macro execution is stored in \$s1061. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

Function 14: Change the clip start position

This macro command is used to change the coordinates for starting clipping (clip start position) of the image of the channel specified in [F1+1] according to [F1+2] and [F1+3].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	○			

○: Setting enabled (indirect designation disabled)

⊙: Setting enabled (indirect designation enabled)

Setting range

	Value
F0	MEMORY
F1	13: CLIP_POS
F1+1	1: 1CH
	2: 2CH
	3: 3CH
	4: 4CH
	5: 5CH (RGB)
	6: 6CH (RGB)
F1+2	0: ? Starting X coordinate 1023:
F1+3	0: ? Starting Y coordinate 767:

Example

- \$u100 = 13 (W) [CLIP_POS]
 - \$u101 = 1 (W) [1CH]
 - \$u102 = 100 (W) [Starting X coordinate 100]
 - \$u103 = 150 (W) [Starting Y coordinate 150]
- VIDEO2 MEMORY \$u100

The above program changes the clip start position coordinates to (100, 150).

Supplementary remarks

- For more information on the clip start position, refer to V9 Series Reference Manual 2.
- The result of macro execution is stored in \$\$s1061. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

Function 15: Change the image clip size

This macro command is used to change the size for clipping (image clip size) the image of the channel specified in [F1+1] according to [F1+2] and [F1+3].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	○			

○: Setting enabled (indirect designation disabled)

⊙: Setting enabled (indirect designation enabled)

Setting range

	Value
F0	MEMORY
F1	14: CLIP_SIZE
F1+1	1: 1CH
	2: 2CH
	3: 3CH
	4: 4CH
	5: 5CH (RGB)
	6: 6CH (RGB)
F1+2	1 - 1024: Width
F1+3	1 - 768: Height

4

Example

- \$u100 = 14 (W) [CLIP_SIZE]
\$u101 = 1 (W) [1CH]
\$u102 = 400 (W) [Width: 400]
\$u103 = 300 (W) [Height: 300]
VIDEO2 MEMORY \$u100

The above program changes the image clip size to 400 × 300 dots.

- \$u200 = 13 (W) [CLIP_POS]
\$u201 = 1 (W) [1CH]
\$u202 = 100 (W) [Starting X coordinate: 100]
\$u203 = 150 (W) [Starting Y coordinate: 150]
VIDEO2 MEMORY \$u200

The above program changes the clip start position coordinates to (100, 150).

Supplementary remarks

- For more information on the image clip size, refer to V9 Series Reference Manual 2.
- The result of macro execution is stored in \$s1061.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

Function 16: Change the operation mode

This macro command is used to change the operation mode of the channel specified in [F1+1].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	○			

○: Setting enabled (indirect designation disabled)

⊙: Setting enabled (indirect designation enabled)

Setting range

	Value
F0	MEMORY
F1	15: MODE
F1+1	1: 1CH
	2: 2CH
	3: 3CH
	4: 4CH
	-1: All
F1+2	0: Odd/even-numbered fields
	1: Odd-number field

Example

- \$u100 = 15 (W) [MODE]
 - \$u101 = 1 (W) [1CH]
 - \$u102 = 1 (W) [Odd-number field]
- VIDEO2 MEMORY \$u100

The above program changes the operation mode of channel 1 to odd-numbered field.

Supplementary remarks

- The result of macro execution is stored in \$s1061. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

VIDEO2 SNAP F1 F2 Command Designation

Function: Single snapshot

This macro command is used to save a snapshot of the channel specified in [F1] to a storage device using the file number specified in [F2] as a background process.

Setting range

	Value
F0	SNAP
F1	CH1 CH2 CH3 CH4 CH5 (RGB) CH6 (RGB) Auto *1
F2	VD00000 ? VD32767 Auto *2

*1 Auto: CH


- During "ZOOM", the macro command is executed with respect to the channel set for zooming.
- Tap the display area to select the channel for executing the macro command. The tapped channel number is stored in \$s934.
- When "ZOOM" is not in use and a channel is not selected by tapping, the macro command is executed as follows:
 - When only one channel is displayed, the macro command is executed for the displayed channel.
 - When multiple channels are displayed, the command is invalid.

*2 Auto: File

If no files exist in the storage device, files are numbered by incrementing, starting from "0". If there are files in the storage device, files are numbered by incrementing the existing maximum file number. When the incremented value reaches [Maximum Number of Snap Files in Auto] in the [Video/RGB Setting] window, the subsequent action depends on the option selected for [When the Snap File Limitation is Exceeded]. With [Stop] selected, any further execution of the macro command is invalid. With [Overwrite] selected, the incremented value will be reset to "0" and the files will be overwritten.

Example

- VIDEO2 SNAP CH1 VD00005



Supplementary remarks

- The macro command is valid when a video image is displayed on the V series with a storage device connected.
- The result of macro execution is stored in \$s1061.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

VIDEO2 SNAP F1 F2 (Size) Command Designation

Function: Background snapshot

This macro command is used to save a snapshot of the channel specified in [F1] in the desired size to a storage device using the file number specified in [F2].

Setting range

	Value
F0	SNAP
F1	CH1 CH2 CH3 CH4 CH5 (RGB) CH6 (RGB)
F2	VD00000 ? VD32767 Auto *1
<input checked="" type="checkbox"/> Snap in Background	160 × 120 320 × 240 640 × 480 640 × 240 *2

*1 Auto: File


If no files exist in the storage device, files are numbered by incrementing, starting from "0". If there are files in the storage device, files are numbered by incrementing the existing maximum file number.

When the incremented value reaches [Maximum Number of Snap Files in Auto] in the [Video/RGB Setting] window, the subsequent action depends on the option selected for [When the Snap File Limitation is Exceeded]. With [Stop] selected, any further execution of the macro command is invalid. With [Overwrite] selected, the incremented value will be reset to "0" and the files will be overwritten.

*2 The snapshot area is distinguished based on the value at \$s957.

Example

- VIDEO2 SNAP CH1 VD01000 160 × 120



The above program saves the image of channel 1 in a size of 160 × 120 as "VD01000.jpg".

Supplementary remarks

- The macro command is valid when a storage device is connected to the V series.
- Even if no video item setting is made in the screen program, the macro command takes a snapshot of the specified channel.
- Regardless of \$s931, superimposing of images is not performed.
- If "PAUSE" is being executed for the specified channel, the channel image is re-captured and then a snapshot is taken.
- If the image of the specified channel is being zoomed in, zooming is canceled while the macro command is taking a snapshot.
- The result of macro execution is stored in \$s1061.

When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

VIDEO2 STROBE CH FileNo. Command Designation

Function: Strobe snapshot

This macro command is used to save a strobe snapshot of the channel specified in [F1] to a storage device using the file number specified in [F2].

Setting range

	Value
F0	STROBE
F1	CH1 CH2 CH3 CH4 CH5 (RGB) CH6 (RGB) Auto *1
F2	VD00000 ? VD32767 Auto *2

*1 Auto: CH


- During "ZOOM", the macro command is executed with respect to the channel set for zooming.
- Tap the display area to select the channel for executing the macro command. The tapped channel number is stored in \$s934.
- When "ZOOM" is not in use and a channel is not selected by tapping, the macro command is executed as follows:
 - When only one channel is displayed, the macro command is executed for the displayed channel.
 - When multiple channels are displayed, the command is invalid.

*2 Auto: File

If no files exist in the storage device, files are numbered by incrementing, starting from "0". If there are files in the storage device, files are numbered by incrementing the existing maximum file number. When the incremented value reaches [Maximum Number of Snap Files in Auto] in the [Video/RGB Setting] window, the subsequent action depends on the option selected for [When the Snap File Limitation is Exceeded]. With [Stop] selected, any further execution of the macro command is invalid. With [Overwrite] selected, the incremented value will be reset to "0" and the files will be overwritten.

Example

- VIDEO2 STROBE CH1 VD00015



Supplementary remarks

- The macro command is valid when a video image is displayed on the V series with a storage device connected.
- The result of macro execution is stored in \$s1061.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

VIDEO2 RE_SIZE Command Designation

Function: Resize


This macro command is used to resize a video image that was enlarged using the ZOOM macro command or by the strobe snapshot function to its original size.

Setting range

	Value
F0	RE_SIZE

Example

- VIDEO2 RE_SIZE



Supplementary remarks

- In addition to the RE_SIZE command, double-clicking an enlarged image resizes it to its original size.
- The result of macro execution is stored in \$s1061. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

VIDEO2 ZOOM F1 F2 Command Designation

Function: Zoom

This macro command is used to enlarge the image of the channel specified in [F1] at the position specified in [F2] to 640 × 480.

Setting range


	Value
F0	ZOOM
F1	CH1 CH2 CH3 CH4 CH5 (RGB) CH6 (RGB) Auto *1
F2	Centering Upper right Lower left

*1 Auto: CH

- Tap the display area to select the channel for executing the macro command. The tapped channel number is stored in \$s934.
- When a channel is not selected by tapping, the macro command is executed as follows:
 - When only one channel is displayed, the macro command is executed for the displayed channel.
 - When multiple channels are displayed, the command is invalid.

Example

- VIDEO2 ZOOM 1CH Centering



The above program enlarges the image of channel 1.

Supplementary remarks

- The result of macro execution is stored in \$s1061. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

VIDEO2 BRIGHT F1 F2 Command Designation

Function: Brightness

This macro command is used to adjust the brightness of video images of the channel specified in [F1] according to the value specified in [F2].

Setting range

	Value
F0	BRIGHT
F1	CH1 CH2 CH3 CH4 Auto *1
F2	0: Dark 1 31: Bright

*1 Auto: CH

- During "ZOOM", the macro command is executed with respect to the channel set for zooming.
- Tap the display area to select the channel for executing the macro command. The tapped channel number is stored in \$s934.
- When "ZOOM" is not in use and a channel is not selected by tapping, the macro command is executed as follows:
 - When only one channel is displayed, the macro command is executed for the displayed channel.
 - When multiple channels are displayed, the command is invalid.

Example

- VIDEO2 BRIGHT CH1 10

The above program changes the brightness level of channel 1 to "10".

Supplementary remarks

- The macro command is valid for video channels (1CH to 4CH) and invalid for RGB channels (5CH and 6CH).
- The result of macro execution is stored in \$s1061. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

VIDEO2 CONTRAST F1 F2 Command Designation

Function: Contrast

This macro command is used to adjust the contrast of video images of the channel specified in [F1] according to the value specified in [F2].

Setting range

	Value
F0	CONTRAST
F1	CH1 CH2 CH3 CH4 Auto *1
F2	0: Low ? 31: High

*1 Auto: CH

- During "ZOOM", the macro command is executed with respect to the channel set for zooming.
- Tap the display area to select the channel for executing the macro command. The tapped channel number is stored in \$s934.
- When "ZOOM" is not in use and a channel is not selected by tapping, the macro command is executed as follows:
 - When only one channel is displayed, the macro command is executed for the displayed channel.
 - When multiple channels are displayed, the command is invalid.

Example

- VIDEO2 CONTRAST CH1 10

The above program changes the contrast level of channel 1 to "10".

Supplementary remarks

- The macro command is valid for video channels (1CH to 4CH) and invalid for RGB channels (5CH and 6CH).
- The result of macro execution is stored in \$s1061. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

VIDEO2 COLOR F1 F2 Command Designation

Function: Color intensity

This macro command is used to adjust the color intensity of video images of the channel specified in [F1] according to the value specified in [F2].

Setting range

	Value
F0	COLOR
F1	CH1 CH2 CH3 CH4 Auto *1
F2	0: Light 1 31: Dark

*1 Auto: CH

- During "ZOOM", the macro command is executed with respect to the channel set for zooming.
- Tap the display area to select the channel for executing the macro command. The tapped channel number is stored in \$s934.
- When "ZOOM" is not in use and a channel is not selected by tapping, the macro command is executed as follows:
 - When only one channel is displayed, the macro command is executed for the displayed channel.
 - When multiple channels are displayed, the command is invalid.

Example

- VIDEO2 COLOR CH1 10

The above program changes the color intensity of channel 1 to "10".

Supplementary remarks

- The macro command is valid for video channels (1CH to 4CH) and invalid for RGB channels (5CH and 6CH).
- The result of macro execution is stored in \$s1061. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

VIDEO2 VIDEOINF F1 F2. Command Designation

Function: Save settings/reset to default

This macro command is used to save the settings of the channel specified in [F1] or to reset the settings to default.

Setting range

	Value	Default	
F0	VIDEOINF	-	
F1	CH1 CH2 CH3 CH4 CH5 (RGB) CH6 (RGB) Auto *1	-	
F2	SAVE	-	
	DEFAULT	BRIGHT	16
		CONTRAST	16
		COLOR	16
		Clip start position	*2
		Image clip size	
MODE	Odd/even-numbered fields		

□ : ← V series (return data)

*1 Auto: CH

- During "ZOOM", the macro command is executed with respect to the channel set for zooming.
- Tap the display area to select the channel for executing the macro command. The tapped channel number is stored in \$s934.
- When "ZOOM" is not in use and a channel is not selected by tapping, the macro command is executed as follows:
 - When only one channel is displayed, the macro command is executed for the displayed channel.
 - When multiple channels are displayed, the command is invalid.

*2 The default setting for the clip start position and the image clip size change according to the input signal. For more information, refer to V9 Series Reference Manual 2.

Example

- VIDEO2 VIDEO_INF CH1 SAVE

The above program saves the video settings for channel 1.

Supplementary remarks

- Do not turn off the power supply of the V series while executing the macro command.
- After the SAVE command has been executed, the data is maintained even after power-off.
- The result of macro execution is stored in \$s1061.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

VIDEO2 PAUSE F1 Command Designation

Function: Pause playback

This macro command is used to pause video playback of the channel specified in [F1].

Setting range

	Value
F0	PAUSE
F1	CH1 CH2 CH3 CH4 Auto *1

*1 Auto: CH

- During "ZOOM", the macro command is executed with respect to the channel set for zooming.
- Tap the display area to select the channel for executing the macro command. The tapped channel number is stored in \$s934.
- When "ZOOM" is not in use and a channel is not selected by tapping, the macro command is executed as follows:
 - When only one channel is displayed, the macro command is executed for the displayed channel.
 - When multiple channels are displayed, the command is invalid.

Example

- VIDEO2 PAUSE CH1

The above program pauses video playback of channel 1.

Supplementary remarks

- During the execution of "PAUSE", resizing is disabled.
- The macro command is valid for video channels (1CH to 4CH) and invalid for RGB channels (5CH and 6CH).
- The result of macro execution is stored in \$s1061.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

VIDEO2 RESTART F1 Command Designation

Function: Pause cancel

This macro command is used to resume video playback that has been paused by the PAUSE command.

Setting range

	Value
F0	RESTART
F1	CH1 CH2 CH3 CH4 Auto *1

*1 Auto: CH

- During "ZOOM", the macro command is executed with respect to the channel set for zooming.
- Tap the display area to select the channel for executing the macro command. The tapped channel number is stored in \$s934.
- When "ZOOM" is not in use and a channel is not selected by tapping, the macro command is executed as follows:
 - When only one channel is displayed, the macro command is executed for the displayed channel.
 - When multiple channels are displayed, the command is invalid.

Example

- VIDEO2 RESTART CH1
The above program resumes video playback of channel 1.

Supplementary remarks

- The macro command is valid for video channels (1CH to 4CH) and invalid for RGB channels (5CH and 6CH).
- The result of macro execution is stored in \$s1061.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

VIDEO2 DELETE F1 Command Designation

Function: Deletion

This macro command is used to delete the snapshot file VDxxxxx.jpg from the storage device.

Setting range

	Value
F0	DELETE
F1	VD00000 ? VD32767

Example

- VIDEO2 DELETE VD00001
The above program deletes the file "VD00001.jpg" from the storage device.

Supplementary remarks

- The macro command is valid when a storage device is connected to the V series.
- The result of macro execution is stored in \$s1061.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

VIDEO2 SNAP_SEQ F1 F2 Command Designation

Function: Change periodical snapshot

This macro command is used to change the periodical snapshot operation of the channel specified in [F1] to the operation specified in [F2].

Setting range


	Value
F0	SNAP_SEQ
F1	CH1 CH2 CH3 CH4 CH5 (RGB) CH6 (RGB)
F2	START STOP

Example

- VIDEO2 SNAP_SEQ CH 1 START
The above program starts taking periodical snapshots of channel 1.


Supplementary remarks

- The interval and total time for taking snapshots periodically is set as follows according to the settings of a video/RGB item in the screen program.
 - When [Periodical Snap] is selected for [Double Click Action]:



Total Time for Periodical Snapshot	Snapshot Interval
Same as [Operation Select] → [Total Time] setting	Same as [Operation Select] → [Intervals] setting

- When other than [Periodical Snap] is selected for [Double Click Action]:



Total Time for Periodical Snapshot	Snapshot Interval
One minute (Fixed)	Same as [Operation Select] → [Strobe Speed] setting *

- * When this setting is shorter than 1 sec, the interval is 1 sec.
- The result of macro execution is stored in \$s1061. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

VIDEO2 CLIP_POS F1 F2 F3 Command Designation

Function: Change the clip start position

This macro command is used to change the coordinates for starting clipping (clip start position) of the image of the channel specified in [F1] according to [F2] and [F3].

Setting range

	Value
F0	CLIP_POS
F1	CH1 CH2 CH3 CH4 CH5 (RGB) CH6 (RGB)
F2	0: ? Starting X coordinate 1023:
F3	0: ? Starting Y coordinate 767:

Example

- VIDEO2 CLIP_POS CH 1 100 150

The above program changes the clip start position coordinates to (100, 150).

Supplementary remarks

- For more information on the clip start position, refer to V9 Series Reference Manual 2.
- The result of macro execution is stored in \$s1061. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

VIDEO2 CLIP_SIZE F1 F2 F3 Command Designation

Function: Change the image clip size

This macro command is used to change the size for clipping (image clip size) the image of the channel specified in [F1] according to [F2] and [F3].

Setting range

	Value
F0	CLIP_SIZE
F1	CH1 CH2 CH3 CH4 CH5 (RGB) CH6 (RGB)
F2	1: ? Width 1024:
F3	1: ? Height 768:

Example

- VIDEO2 CLIP_SIZE CH 1 400 300
The above program changes the image clip size to 400 × 300 dots.
VIDEO2 CLIP_POS CH 1 100 150
The above program changes the clip start position coordinates to (100, 150).

Supplementary remarks

- For more information on the image clip size, refer to V9 Series Reference Manual 2.
- The result of macro execution is stored in \$s1061.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

VIDEO2 MODE F1 F2 F3 Command Designation

Function 16: Change the operation mode

This macro command is used to change the operation mode of the channel specified in [F1].

Setting range

	Value
F0	CLIP_SIZE
F1	CH1 CH2 CH3 CH4 All: All channels
F2	ODD/EVEN-FIELD: Odd/even-numbered fields ODD-FIELD: Odd-numbered field
F3	Fixed to 0

Example

- VIDEO2 MODE CH 1 ODD-FIELD 0
The above program changes the operation mode of channel 1 to odd-numbered field.

Supplementary remarks

- The result of macro execution is stored in \$s1061.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

4.14 PLC

PLC_CLND

PLC_CLND F0 PLC F1 F2 F3

All models	<input type="radio"/>
------------	-----------------------

Function: Calendar control function for PLC [F1]

This macro command is used to control the calendar for the PLC specified in [F1]. Depending on the value specified in [F0] it specifies reading or writing of the calendar data.

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	<input type="radio"/>			<input type="radio"/>
F1	<input type="radio"/>			<input type="radio"/>
F2	<input type="radio"/>			
F3	<input type="radio"/>			

: Setting enabled (indirect designation disabled)

: Setting enabled (indirect designation enabled)

Setting range

	Value	
F0	0: Calendar reading *1 1: Calendar writing (specified by user) *2 2: Calendar writing (by the system) *3	
F1	2 - 8: PLC number	
F2	0 - 31: PLC station number	Invalid with 1:1 connections
F2+1	0 - 255: PLC sub station number	Invalid with 1:1 connections Only valid for PLCs with sub station number designations
F3	0 - : Year (4-digit/2-digit)	
F3+1	1 - 12: Month	
F3+2	1 - 31: Day	
F3+3	0 - 23: Hour	
F3+4	0 - 59: Minute	
F3+5	0 - 59: Second	
F3+6	0: Sunday 1: Monday 2: Tuesday 3: Wednesday 4: Thursday 5: Friday 6: Saturday	Only valid with a read ([F0] = 0) setting Invalid with a write ([F0] = 1 or 2) setting because the calculation is done internally in the unit

* Details of calendar function specification

*1 When [F0] = 0: Calendar reading

When the connection method specified in [F1] is "1:1", the calendar is read for the connected device and the information is saved in the [F3] device memory. (The contents in the [F2] device memory are ignored.)

When the connection method specified in [F1] is "1:n", the calendar for the connected device with the station number specified in [F2] or the sub station number specified in [F2+1] is read and saved in the [F3] device memory.

The V series system calendar is not changed by any command. To change the system calendar, use "SYS (SET_SYS_CLND) F1" (page 4-304).

- *2 When [F0] = 1: Calendar writing (specified by user)
 When the connection method specified in [F1] is "1:1", the calendar data in the [F3] device memory is written to the connected device.
 (The contents in the [F2] device memory are ignored.)
 When the connection method specified in [F1] is "1:n", the calendar data specified in [F3] is written to the connected device with the station number specified in [F2] or the sub station number specified in [F2+1].
- *3 When [F0] = 2: Calendar writing (by the system)
 When the connection method specified in [F1] is "1:1", the V series unit's system calendar data is written to the connected device.
 (The contents in the [F2] device memory and the [F3] device memory are ignored.)
 When the connection method specified in [F1] is "1:n", the system's calendar data specified in [F3] is written to the connected device with the station number specified in [F2] or the sub station number specified in [F2+1].
 (The contents in the [F3] device memory are ignored.)

Example

- Setting the calendar for PLC2, station No. 1 to 20:00:00 on October 15, 2007

```

$u100 = 1 (W)      — [PLC station number: 1]
$u200 = 2007 (W)  —
$u201 = 10 (W)   — [October 15, 2007, Monday, 20:00:00]
$u202 = 15 (W)   —
$u203 = 20 (W)   —
$u204 = 0 (W)    —
$u205 = 0 (W)    —
PLC_CLND 1 PLC2 $u100 $u200
SYS (SET_SYS_CLND) $u200 (V series calendar setting)
      
```

Supplemental remarks

- If the relevant equipment doesn't incorporate a calendar, nothing happens in response to the command. (The V series automatically judges whether or not the equipment incorporates a calendar.)
- Nothing happens to the equipment whose link has been dead in response to the command.
- The result of macro execution is stored in \$s729.
 When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (HEX)	Contents
2004	A PLC [F1] communication error has occurred during processing.
FFFF	Execution error

PLC_CTL

PLC_CTL PLC F0 F1 F2

All models	<input type="radio"/>
------------	-----------------------

Function: PLC [F1] control function

This macro command is used to control the operation specified in the words starting from the address in [F1] in relation to the PLC specified in [F0]. The number of words is specified in [F2].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	<input type="radio"/>			<input type="radio"/>
F1	<input type="radio"/>			
F2				<input type="radio"/>

○ : Setting enabled (indirect designation disabled)
 ◎ : Setting enabled (indirect designation enabled)

Setting range

	Value
F0	1 - 8: PLC number
F1	0 - 31: PLC station number
F1+1	Command and others
:	The items to be set differ depending on the equipment. For more information, refer to the V9 Series Connection Manual.
F2	The number of words to be transferred

Example

- Bringing Omron's E5ZN (station No. 1) connected to the PLC2 to a state of RUN:
 \$u100 = 1 (W) [PLC station number]
 \$u101 = 30H (W) [Command]
 \$u102 = 100H (W) [Operation command (RUN)]
 PLC_CTL PLC2 \$u100 3

Contents	F0	F1 (= \$u n)	= \$u100	F2		
Operation command	1 - 8 (PLC1 - 8)	n	= \$u100	Station number*	3	
		n+1	= \$u101	Command: 0030H		
		n+2	= \$u102	0000H: Communication writing OFF (disabled)		0100H: RUN
				0001H: Communication writing ON (enabled)		
				0101H: STOP		
				0200H: Multi-SP (Set point 0)		
				0201H: Multi-SP (Set point 1)		
				0202H: Multi-SP (Set point 2)		
				0203H: Multi-SP (Set point 3)		
				0300H: AT cancel		
				0301H: AT execution		
				0400H: Write mode (Backup)		
0401H: Write mode (RAM)						
0500H: Save RAM data						
0600H: Software reset						
0700H: Move to set area 1						
0800H: Move to protect level						

* 8000 (HEX): broadcasting

- The result of macro execution is stored in \$s729.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (HEX)	Contents
2002	Memory cannot be allocated.
2004	A PLC [F0] communication error has occurred during processing.

TBL_READ**TBL_READ F0 <- TABLE:PLC F1 : F2**

All models	<input type="radio"/>
------------	-----------------------

Function: Read from device memory map

This macro command is used to transfer the data at the addresses registered in the device memory map specified in [F2] of the PLC specified in [F1] to the addresses starting with the one specified in [F0].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙	⊙	⊙	
F1	○			○
F2	○			○

○ : Setting enabled (indirect designation disabled)
 ⊙ : Setting enabled (indirect designation enabled)

4

Setting range

	Value
F0	Top address of the target
F1	1 - 8: PLC number
F2	0 - 31: Device memory map No.

Example

- Transferring the data of the addresses registered in device memory map No. 5 defined at PLC3 to \$u500 onward
 TBL_READ \$u500 <- TABLE : PLC3 : 5

Supplemental remarks

- As many addresses as the data count set in the device memory map must be allocated to the target memory, to which data will be transferred.
- The result of macro execution is stored in \$s729.
 When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (HEX)	Contents
2001	The address set in the device memory map does not exist.
2002	The device memory cannot be allocated.
2004	A PLC [F1] communication error has occurred during processing.

TBL_WRITE

TBL_WRITE TABLE:PLC F1 : F0 <- F2

All models	<input type="radio"/>
------------	-----------------------

Function: Write to device memory map

This macro command is used to transfer the data at the location starting from the address specified in [F2] to the address registered in the device memory map [F0] for the PLC [F1].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	<input type="radio"/>			<input type="radio"/>
F1	<input type="radio"/>			<input type="radio"/>
F2	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	

: Setting enabled (indirect designation disabled)

: Setting enabled (indirect designation enabled)

Setting range

	Value
F0	0 - 31: Device memory map No.
F1	1 - 8: PLC number
F2	Top memory address of the source

Example

- Transferring the data of \$u500 onward to the addresses registered in device memory map No. 5 defined at PLC3
TBL_WRITE TABLE : PLC3 : 5 <- \$u00500

Supplemental remarks

- As many addresses as the data count set in the device memory map must be allocated to the target memory, to which data will be transferred.
- The result of macro execution is stored in \$s729.

When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (HEX)	Contents
2001	The address set in the device memory map does not exist.
2002	The device memory cannot be allocated.
2004	A PLC [F1] communication error has occurred during processing.

4.15 Ethernet

SEND

All models	<input type="radio"/>
------------	-----------------------

SEND F0 C:F1 TO F2

Function: Transfer to server

This macro command is used to transfer the data of words starting from the address specified in [F0] to the server of the network table number in [F2]. The number of the words is specified in [F1].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙	⊙	⊙	
F1	⊙			○
F2	⊙			○


○ : Setting enabled (indirect designation disabled)
 ⊙ : Setting enabled (indirect designation enabled)

Setting range

	Value
F0	Top address of the source
F1	0 - 2000: The number of words to be transferred
F2	0 - 255: Transfer target (network table number)

Example

- SEND PLC2 [D10] C:2 TO:3
 The above program transfers two words of data starting from D10 of PLC2:B to network table No. 3 (server A).



Supplemental remarks

The following system device memory addresses are related to this command. For more information, refer to V9 Series Reference Manual 1.

Address	Contents	Remarks
\$s512	Select the port used for sending and receiving. 0: LAN (built-in) 1: Ethernet unit 2: LAN2 (built-in) 3: WLAN (wireless)	→V
\$s514	The macro execution format (wait request) is set.	→V
\$s515	The result of macro execution is stored.	←V

EReAD

EReAD F0 = F1 C:F2 F3

All models

**Function: Read on the network**

This macro command is used to read the data of words starting from the address specified in [F1] set in the [F3]-specified network table into the address in [F0]. The number of the words is specified in [F2].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙	⊙	⊙	
F1	⊙	⊙	⊙	
F2	⊙			○
F3	⊙			○

○ : Setting enabled (indirect designation disabled)

⊙ : Setting enabled (indirect designation enabled)


Setting range

	Value
F0	Top address of the target
F1	Top address of the source
F2	0 - 2000: The number of words to be transferred
F3	0 - 255: Transfer source (network table number)

Example

- EREAD PLC1 [D200] = PLC1 [D100] C:2 5

The above program reads two words of data starting from D100 of PLC1:B, which is connected to network table No. 5 (V series:B), into D200 onward of PLC1:A.

**Supplemental remarks**

The following system device memory addresses are related to this command. For more information, refer to V9 Series Reference Manual 1.

Address	Contents	Remarks
\$s512	Select the port used for sending and receiving. 0: LAN (built-in) 1: Ethernet unit 2: LAN2 (built-in) 3: WLAN (wireless)	→V
\$s514	The macro execution format (wait request) is set.	→V
\$s515	The result of macro execution is stored.	←V

EWRITE

All models

EWRITE F0 F1 = F2 C:F3

Function: Write on the network

This macro command is used to write data starting from the address specified in [F2] to the address specified in [F0] of the equipment connected to the network table number specified in [F1]. The number of words is specified in [F3].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙	⊙	⊙	
F1	⊙			○
F2	⊙	⊙	⊙	
F3	⊙			○


○ : Setting enabled (indirect designation disabled)
 ⊙ : Setting enabled (indirect designation enabled)

Setting range

	Value
F0	Top address of the target
F1	0 - 255: Transfer target (network table number)
F2	Top address of the source
F3	0 - 2000: The number of words to be transferred

Example

- EWRITE PLC1 [D100] 5 = \$u100 C:2
 The above program writes two words of data starting from \$u100 of the V series:A to D100 onward of PLC1:B which is connected to network table No. 5 (V series:B).



Supplemental remarks

The following system device memory addresses are related to this command. For more information, refer to V9 Series Reference Manual 1.

Address	Contents	Remarks
\$s512	Select the port used for sending and receiving. 0: LAN (built-in) 1: Ethernet unit 2: LAN2 (built-in) 3: WLAN (wireless)	→V
\$s514	The macro execution format (wait request) is set.	→V
\$s515	The result of macro execution is stored.	←V

4.16 MES

MES

All models	<input type="radio"/>
------------	-----------------------

MES CHECK F1 F2 F3

Function: V-server start check

This macro command is used to check whether V-Server is running at the location specified in table No. [F2]. The returned value specified in [F3] is stored in the memory at the return address of [F1].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F1	⊙			
F2	○			○
F3	○			○

○: Setting enabled (indirect designation disabled)


⊙: Setting enabled (indirect designation enabled)

Setting range

	Value
F0	MES CHECK
F1	Return address
F2	0 - 255: Network table number
F3	0 - 65535 (-32768 - 32767): Return value

Example

- MES CHECK (\$u0000, 10, 1)



The above program checks whether V-Server is running on the computer registered to network table number 10. If V-Server is running, a return value of "1" is stored at the return address of \$u0000.

Supplementary remarks

- Execute the macro after setting a value other than the returned value at the return address.
- The returned value will not be placed at the [F1] return address immediately. Monitor the [F1] return address using an event timer macro, etc.
- If an error occurs when writing the result (return value, data retrieved by a search) of accessing the database, the result and log data are not output to the V9 series unit.
- The following system device memory addresses are related to this command. For more information, refer to V9 Series Reference Manual 1.

Address	Contents	Remarks
\$s512	Select the port used for sending and receiving. 0: LAN (built-in) 1: Ethernet unit 2: LAN2 (built-in) 3: WLAN (wireless)	→V
\$s514	The macro execution format (wait request) is set. * When a macro command is executed while V-Server is not running and "1" (other than "0") is set for \$s514, no response is received from V-Server and the V9 series unit will enter the standby state. It is recommended to execute this command with "0" set for \$s514.	→V
\$s515	The result of macro execution is stored.	←V

MES WRITE F1 F2 F3

Function: Adding data to the database

This macro command is used to add the data set on the [Write] tab under MES setting No. [F3] to the database. The data is added using V-Server at the location specified in table No. [F2]. The result is stored at the [F1] return address.

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F1	⊙			
F2	○			○
F3	○			○

○: Setting enabled (indirect designation disabled)


⊙: Setting enabled (indirect designation enabled)

Setting range

	Value	
F0	MES WRITE	
F1	Return address	Return value 0: Successful completion -1: Ended in error
F2	0 - 255: Network table number	
F3	0 - 255: MES setting No.	

Example

- MES WRITE (\$u0000, 10, 0)



The above program adds data to the database of the computer specified in network table No. 10. The data to be added depends on the settings made for MES setting No. 0.

When the data is successfully written, a return value of "0" is stored at the return address of \$u0000.

Supplementary remarks

- The returned value will not be placed at the [F1] return address immediately. Monitor the [F1] return address using an event timer macro, etc.
- The primary key for V-Server must be set to the database table. For more information, refer to V9 Series Reference Manual 2.
- If an error occurs when writing the result (return value, data retrieved by a search) of accessing the database, the result and log data are not output to the V9 series unit.
- The following system device memory addresses are related to this command. For more information, refer to V9 Series Reference Manual 1.

Address	Contents	Remarks
\$s512	Select the port used for sending and receiving. 0: LAN (built-in) 1: Ethernet unit 2: LAN2 (built-in) 3: WLAN (wireless)	→V
\$s514	The macro execution format (wait request) is set.	→V
\$s515	The result of macro execution is stored. -40: Settings on the [Write] tab are not configured for the specified MES setting number, or there is a setting error. For more information on other error numbers, refer to V9 Series Reference Manual 1.	←V

MES READ F1 F2 F3

Function: Searching the database

This macro command is used to search the line set on the [Read] tab for MES setting No. [F3]. The search is performed based on the specified search conditions via V-Server at the location specified in table No. [F2]. The result is stored at the [F1] return address.

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F1	⊙			
F2	○			○
F3	○			○

○: Setting enabled (indirect designation disabled)

⊙: Setting enabled (indirect designation enabled)

Setting range

	Value
F0	MES READ
F1	Return address
F2	0 - 255: Network table number
F3	0 - 255: MES setting No.

Return address

The following data is stored at the addresses starting from the [F1] return address.

	Value
n	Execution result Successfully completion:0 Error: Other than 0
n + 1	Number of retrieved records The number of records that match the search conditions is stored. If no records are found, "0" is stored. The maximum number of records is set on the [Read] tab in the MES settings.
n+2 -	Obtained data 1 The retrieved data is stored in the format specified on the [Read] tab in the MES settings.
:	Obtained data 2
:	Obtained data 3
:	:
:	Obtained data m (maximum number of records)

Example

- MES READ (\$u0000, 10, 0)



The above program searches the database on the computer specified in network table No. 10. The search is performed according to the settings on the [Read] and [Search condition] tabs for MES setting No. 0.

When the search is successfully completed, a return value of "0" and the obtained data are stored at the addresses starting from the return address of \$u0000.

Supplementary remarks

- The returned value will not be placed at the [F1] return address immediately. Monitor the [F1] return address using an event timer macro, etc.
- If settings are not configured on the [Search condition] tab for the specified MES setting number, all records are extracted as the results of the search.
- If an error occurs when writing the result (return value, data retrieved by a search) of accessing the database, the result and log data are not output to the V9 series unit.
- The following system device memory addresses are related to this command. For more information, refer to V9 Series Reference Manual 1.

Address	Contents	Remarks
\$s512	Select the port used for sending and receiving. 0: LAN (built-in) 1: Ethernet unit 2: LAN2 (built-in) 3: WLAN (wireless)	→V
\$s514	The macro execution format (wait request) is set.	→V
\$s515	The result of macro execution is stored. -40: Settings on the [Read] tab are not configured for the specified MES setting number, or there is a setting error. For more information on other error numbers, refer to V9 Series Reference Manual 1.	←V

MES DEL F1 F2 F3

Function: Deleting records from the database

This macro command is used to search the database according to the settings on the [Search condition] tab for MES setting No. [F3]. The search is performed via V-Server at the location specified in table No. [F2]. The records that match the conditions are deleted. The result is stored at the [F1] return address.

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F1	⊙			
F2	○			○
F3	○			○


○: Setting enabled (indirect designation disabled)
 ⊙: Setting enabled (indirect designation enabled)

Setting range

	Value	
F0	MES DEL	
F1	Return address	Return value 0: Successful completion -1: Ended in error
F2	0 - 255: Network table number	
F3	0 - 255: MES setting No.	

Example

- MES DEL (\$u0000, 10, 0)



The above program searches the database of the computer specified in network table No. 10 and deletes the retrieved data. The search is performed according to the settings on the [Search condition] tab for MES setting No. 0. When the data deletion is successfully completed, a return value of "0" is stored at the return address of \$u0000.

Supplementary remarks

- If an error occurs when writing the result (return value, data retrieved by a search) of accessing the database, the result and log data are not output to the V9 series unit.
- The following system device memory addresses are related to this command. For more information, refer to V9 Series Reference Manual 1.

Address	Contents	Remarks
\$s512	Select the port used for sending and receiving. 0: LAN (built-in) 1: Ethernet unit 2: LAN2 (built-in) 3: WLAN (wireless)	→V
\$s514	The macro execution format (wait request) is set.	→V
\$s515	The result of macro execution is stored. -40: Settings on the [Search condition] tab are not configured for the specified MES setting number, or there is a setting error. For more information on other error numbers, refer to V9 Series Reference Manual 1.	←V

MES UPDATE F1 F2 F3

Function: Updating the database

This macro command is used to search the line set on the [Write] tab for MES setting No. [F3]. The search is performed based on the specified search conditions via V-Server at the location specified in table No. [F2], and then the database is updated. The result is stored at the [F1] return address.

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F1	⊙			
F2	○			○
F3	○			○

○: Setting enabled (indirect designation disabled)


⊙: Setting enabled (indirect designation enabled)

Setting range

	Value	
F0	MES UPDATE	
F1	Return address	Return value 0: Successful completion -1: Ended in error
F2	0 - 255: Network table number	
F3	0 - 255: MES setting No.	

Example

- MES UPDATE (\$u0000, 10, 0)



The above macro searches the database on the computer specified in network table No. 10 and updates the database. The search is performed according to the settings on the [Write] and [Search condition] tabs for MES setting No. 0.

When the data is successfully written, a return value of "0" is stored at the return address of \$u0000.

Supplementary remarks

- The returned value will not be placed at the [F1] return address immediately. Monitor the [F1] return address using an event timer macro, etc.
- This macro command cannot be executed when "Update" is set on the [Search condition] tab.
- If an error occurs when writing the result (return value, data retrieved by a search) of accessing the database, the result and log data are not output to the V9 series unit.
- The following system device memory addresses are related to this command. For more information, refer to V9 Series Reference Manual 1.

Address	Contents	Remarks
\$s512	Select the port used for sending and receiving. 0: LAN (built-in) 1: Ethernet unit 2: LAN2 (built-in) 3: WLAN (wireless)	→V
\$s514	The macro execution format (wait request) is set.	→V
\$s515	The result of macro execution is stored. -40: Settings are not configured on the [Write] or [Search condition] tab for the specified MES setting number, or there is a setting error. For more information on other error numbers, refer to V9 Series Reference Manual 1.	←V

4.17 Storage (Recipe)

LD_RECIPE

LD_RECIPE F0 F1

All models	<input type="radio"/>
------------	-----------------------

Function: Read CSV file

This macro command is used to transfer the CSV file specified in [F1] to the location starting from the address in [F0].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙	⊙	⊙	
F1	○	○	○	○

○ : Setting enabled (indirect designation disabled)

⊙ : Setting enabled (indirect designation enabled)

Setting range

	Value
F0	Transfer target address
F1	0000 - 9999: CSV file number

CSV file

Storage target: \(\access folder\)RECIPE

File name: \RECxxx.csv


0000 - 9999: File No.

The designation of the line and column numbers in a CSV file differs, depending on the options selected for [Format Setting] ([Recipe] → [File Format]). The ♦ mark indicates the position of line No. 1 and column No. 1 in the CSV file.

	<input type="checkbox"/> Add title to data	<input checked="" type="checkbox"/> Add title to data																		
<input type="checkbox"/> Add record name	<table border="1"> <tr><td>♦</td><td></td><td></td></tr> <tr><td></td><td></td><td></td></tr> <tr><td></td><td></td><td></td></tr> </table>	♦									<table border="1"> <tr><td colspan="3">Title</td></tr> <tr><td>♦</td><td></td><td></td></tr> <tr><td></td><td></td><td></td></tr> </table>	Title			♦					
♦																				
Title																				
♦																				
<input checked="" type="checkbox"/> Add record name	<table border="1"> <tr><td>Record</td><td>♦</td><td></td></tr> <tr><td></td><td></td><td></td></tr> <tr><td></td><td></td><td></td></tr> </table>	Record	♦								<table border="1"> <tr><td>-</td><td colspan="2">Title</td></tr> <tr><td>Record</td><td>♦</td><td></td></tr> <tr><td></td><td></td><td></td></tr> </table>	-	Title		Record	♦				
Record	♦																			
-	Title																			
Record	♦																			

Example

- LD_RECIPE \$u200 1
The data in the REC0001.csv file is transferred to the location starting from \$u200.



Supplemental remarks

- Recipe settings are required for each CSV file.

The file "REC0001.csv" is used.


- For reading text, whether to convert a null to 20H (space) or read it as "00" can be selected.
Go to the [General Setting] tab window in the [Unit Setting] dialog ([System Setting] → [Unit Setting] → [General Settings]). On the tab window, check or uncheck [Convert NULL to Space with the LD/RD Macro].

Example:

CSV file

```
A,B,
C,,
```

Format setting



Execution result

Storage target	Checked	Unchecked
n	2041H	0041H
n+1	2042H	0042H
n+2	2043H	0043H
n+3	2020H	0000H

A null is converted to 20H.

A null remains "00".

- The result of macro execution is stored in \$s1062.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

LD_RECIP2

LD_RECIP2 F0 F1 F2

All models	<input type="radio"/>
------------	-----------------------

Function: Read CSV file (recipe number designation)

This macro command is used to transfer the CSV file number [F1] in the format of the recipe number [F2] to the location starting from the address [F0].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙	⊙	⊙	
F1	○	○	○	○
F2	○	○	○	○

○ : Setting enabled (indirect designation disabled)

⊙ : Setting enabled (indirect designation enabled)

Setting range

	Value
F0	Transfer target address
F1	0000 - 9999: CSV file number
F2	0 - 255: Recipe number

CSV file

Storage target: \(\access folder)\RECIP2

File name: \RECxxx.csv

0000 - 9999: File No.


The designation of the line and column numbers in a CSV file differs, depending on the options selected for [Format Setting] ([Recipe] → [File Format]). The ♦ mark indicates the position of line No. 1 and column No. 1 in a CSV file.

	<input type="checkbox"/> Add title to data	<input checked="" type="checkbox"/> Add title to data																		
<input type="checkbox"/> Add record name	<table border="1"> <tr><td>♦</td><td></td><td></td></tr> <tr><td></td><td></td><td></td></tr> <tr><td></td><td></td><td></td></tr> </table>	♦									<table border="1"> <tr><td colspan="3">Title</td></tr> <tr><td>♦</td><td></td><td></td></tr> <tr><td></td><td></td><td></td></tr> </table>	Title			♦					
♦																				
Title																				
♦																				
<input checked="" type="checkbox"/> Add record name	<table border="1"> <tr><td>Record</td><td>♦</td><td></td></tr> <tr><td></td><td></td><td></td></tr> <tr><td></td><td></td><td></td></tr> </table>	Record	♦								<table border="1"> <tr><td>-</td><td colspan="2">Title</td></tr> <tr><td>Record</td><td>♦</td><td></td></tr> <tr><td></td><td></td><td></td></tr> </table>	-	Title		Record	♦				
Record	♦																			
-	Title																			
Record	♦																			

Example


- LD_RECIPE2 \$u100 2 0

The above program transfers the data in the file "REC0002.csv" in the format of recipe No. 0 to the location starting from \$u100.



Supplemental remarks

- Recipe settings must be made in the same format as the CSV file.



- For reading text, whether to convert a null to 20H (space) or read it as "00" can be selected. For more information, refer to page 4-171.
- The result of macro execution is stored in \$s1062. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

LD_RECIPESSEL

LD_RECIPESSEL F0 F1

All models	<input type="radio"/>
------------	-----------------------

Function: Read CSV file (in units of a cell)

This macro command is used to transfer part of the CSV file specified in [F1] to the location starting from the address in [F0].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⓪	⓪	⓪	
F1	⓪	⓪	⓪	

○ : Setting enabled (indirect designation disabled)
 ◎ : Setting enabled (indirect designation enabled)

Setting range

	Value	
	Line: Record, Column: Data	Line: Data, Column: Record
F0	Transfer source address	
F1	0000 - 9999: CSV file number	
F1+1	1 - 32767: Top line number	1 - 4096: Top line number
F1+2	0* - 4096: Top column number	0* - 4096: Top column number
F1+3	1 - 32767: Number of lines	1 - 4096: Number of lines
F1+4	1 - 4096: Number of columns	1 - 4096: Number of columns

* Specify "0" if you wish to transfer the record name as well. In that case, select [Record Name + Data] for [Transfer Target] under [Transfer Device Setting] ([Recipe] → [File Format]) The number of columns specified in F1+4 includes the cell of the record name.

CSV file

Storage target: \(\access folder)\RECIPE

File name: \RECxxxx.csv

└─ 0000 - 9999: File No.


The designation of the line and column numbers in a CSV file differs, depending on the options selected for [Format Setting] ([Recipe] → [File Format]). The ♦ mark indicates the position of line No. 1 and column No. 1 in a CSV file.

	<input type="checkbox"/> Add title to data	<input checked="" type="checkbox"/> Add title to data																		
<input type="checkbox"/> Add record name	<table border="1"> <tr><td style="text-align: center;">♦</td><td></td><td></td></tr> <tr><td></td><td></td><td></td></tr> <tr><td></td><td></td><td></td></tr> </table>	♦									<table border="1"> <tr><td colspan="3" style="text-align: center;">Title</td></tr> <tr><td style="text-align: center;">♦</td><td></td><td></td></tr> <tr><td></td><td></td><td></td></tr> </table>	Title			♦					
♦																				
Title																				
♦																				
<input checked="" type="checkbox"/> Add record name	<table border="1"> <tr><td style="text-align: center;">Record</td><td style="text-align: center;">♦</td><td></td></tr> <tr><td></td><td></td><td></td></tr> <tr><td></td><td></td><td></td></tr> </table>	Record	♦								<table border="1"> <tr><td style="text-align: center;">-</td><td colspan="2" style="text-align: center;">Title</td></tr> <tr><td style="text-align: center;">Record</td><td style="text-align: center;">♦</td><td></td></tr> <tr><td></td><td></td><td></td></tr> </table>	-	Title		Record	♦				
Record	♦																			
-	Title																			
Record	♦																			

Example


- \$u100 = 1 (W) [File number 1]
- \$u101 = 2 (W) [Top line number]
- \$u102 = 3 (W) [Top column number]
- \$u103 = 2 (W) [Number of lines]
- \$u104 = 3 (W) [Number of columns]
- LD_RECIPESL \$u300 \$u100

The above program transfers part of the data in the REC0001.csv file to the location starting from \$u300.



Supplemental remarks

- Attribute setting is required for each CSV file.



- For reading text, whether to convert a null to 20H (space) or read it as "00" can be selected. For more information, refer to page 4-171.

- Difference between reading one line and reading multiple lines

	Line: Record, Column: Data	Line: Data, Column: Record																																								
CSV	<p>CSV file</p> <table border="1"> <thead> <tr> <th>DEC</th> <th>CHAR</th> <th>DEC</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>A</td> <td>100</td> </tr> <tr> <td>2</td> <td>B</td> <td>200</td> </tr> <tr> <td>3</td> <td>C</td> <td>300</td> </tr> <tr> <td>4</td> <td>D</td> <td>400</td> </tr> </tbody> </table>	DEC	CHAR	DEC	1	A	100	2	B	200	3	C	300	4	D	400	<p>CSV file</p> <table border="1"> <thead> <tr> <th>DEC</th> <th>1</th> <th>2</th> <th>3</th> <th>4</th> </tr> </thead> <tbody> <tr> <th>CHAR</th> <td>A</td> <td>B</td> <td>C</td> <td>D</td> </tr> <tr> <th>DEC</th> <td>100</td> <td>200</td> <td>300</td> <td>400</td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> </tbody> </table>	DEC	1	2	3	4	CHAR	A	B	C	D	DEC	100	200	300	400										
DEC	CHAR	DEC																																								
1	A	100																																								
2	B	200																																								
3	C	300																																								
4	D	400																																								
DEC	1	2	3	4																																						
CHAR	A	B	C	D																																						
DEC	100	200	300	400																																						
One line	<p>Reading one line and two columns from top line No. 2 and top column No.2</p> <table border="1"> <thead> <tr> <th>DEC</th> <th>CHAR</th> <th>DEC</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>A</td> <td>100</td> </tr> <tr> <td>2</td> <td>B</td> <td>200</td> </tr> <tr> <td>3</td> <td>C</td> <td>300</td> </tr> <tr> <td>4</td> <td>D</td> <td>400</td> </tr> </tbody> </table>	DEC	CHAR	DEC	1	A	100	2	B	200	3	C	300	4	D	400	<p>Reading one line and two columns from top line No. 2 and top column No.2</p> <table border="1"> <thead> <tr> <th>DEC</th> <th>1</th> <th>2</th> <th>3</th> <th>4</th> </tr> </thead> <tbody> <tr> <th>CHAR</th> <td>A</td> <td>B</td> <td>C</td> <td>D</td> </tr> <tr> <th>DEC</th> <td>100</td> <td>200</td> <td>300</td> <td>400</td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> </tbody> </table>	DEC	1	2	3	4	CHAR	A	B	C	D	DEC	100	200	300	400										
DEC	CHAR	DEC																																								
1	A	100																																								
2	B	200																																								
3	C	300																																								
4	D	400																																								
DEC	1	2	3	4																																						
CHAR	A	B	C	D																																						
DEC	100	200	300	400																																						
Two lines	<p>Reading two lines and two columns from top line No. 2 and top column No. 2</p> <table border="1"> <thead> <tr> <th>DEC</th> <th>CHAR</th> <th>DEC</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>A</td> <td>100</td> </tr> <tr> <td>2</td> <td>B</td> <td>200</td> </tr> <tr> <td>3</td> <td>C</td> <td>300</td> </tr> <tr> <td>4</td> <td>D</td> <td>400</td> </tr> </tbody> </table>	DEC	CHAR	DEC	1	A	100	2	B	200	3	C	300	4	D	400	<p>Reading two lines and two columns from top line No. 2 and top column No. 2</p> <table border="1"> <thead> <tr> <th>DEC</th> <th>1</th> <th>2</th> <th>3</th> <th>4</th> </tr> </thead> <tbody> <tr> <th>CHAR</th> <td>A</td> <td>B</td> <td>C</td> <td>D</td> </tr> <tr> <th>DEC</th> <td>100</td> <td>200</td> <td>300</td> <td>400</td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> </tbody> </table> <p>* Execute reading line by line (specifying multiple lines at one time is not allowed).</p>	DEC	1	2	3	4	CHAR	A	B	C	D	DEC	100	200	300	400										
DEC	CHAR	DEC																																								
1	A	100																																								
2	B	200																																								
3	C	300																																								
4	D	400																																								
DEC	1	2	3	4																																						
CHAR	A	B	C	D																																						
DEC	100	200	300	400																																						

- The result of macro execution is stored in \$s1062.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

LD_RECIPSEL2 LD_RECIPSEL2 F0 F1 F2

All models	<input type="radio"/>
------------	-----------------------

Function: Read CSV file (in units of a cell/recipe No. designation)

This macro command is used to transfer a part of data in the CSV file number [F1] in the format of the recipe number [F2] to the location starting from the address [F0].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙	⊙	⊙	
F1	⊙	⊙	⊙	
F2	○	○	○	○

○ : Setting enabled (indirect designation disabled)

⊙ : Setting enabled (indirect designation enabled)

4

Setting range

	Value	
	Line: Record, Column: Data	Line: Data, Column: Record
F0	Transfer target address	
F1	0000 - 9999: CSV file number	
F1+1	1 - 32767: Top line number	1 - 4096: Top line number
F1+2	0* - 4096: Top column number	0* - 4096: Top column number
F1+3	1 - 32767: Number of lines	1 - 4096: Number of lines
F1+4	1 - 4096: Number of columns	1 - 4096: Number of columns
F2	0 - 255: Recipe number	

* Specify "0" if you wish to transfer the record name as well. In that case, select [Record Name + Data] for [Transfer Target] under [Transfer Device Setting] ([Recipe] → [File Format]) The number of columns specified in F1+4 includes the cell of the record name.

CSV file

Storage target: \(\access folder\)RECIPE

File name: \RECxxxx.csv

0000 - 9999: File number


The designation of the line and column numbers in a CSV file differs, depending on the options selected for [Format Setting] ([Recipe] → [File Format]). The ♦ mark indicates the position of line No. 1 and column No. 1 in a CSV file.

	<input type="checkbox"/> Add title to data	<input checked="" type="checkbox"/> Add title to data																		
<input type="checkbox"/> Add record name	<table border="1"> <tr><td>♦</td><td></td><td></td></tr> <tr><td></td><td></td><td></td></tr> <tr><td></td><td></td><td></td></tr> </table>	♦									<table border="1"> <tr><td colspan="3">Title</td></tr> <tr><td>♦</td><td></td><td></td></tr> <tr><td></td><td></td><td></td></tr> </table>	Title			♦					
♦																				
Title																				
♦																				
<input checked="" type="checkbox"/> Add record name	<table border="1"> <tr><td>Record</td><td>♦</td><td></td></tr> <tr><td></td><td></td><td></td></tr> <tr><td></td><td></td><td></td></tr> </table>	Record	♦								<table border="1"> <tr><td>-</td><td colspan="2">Title</td></tr> <tr><td>Record</td><td>♦</td><td></td></tr> <tr><td></td><td></td><td></td></tr> </table>	-	Title		Record	♦				
Record	♦																			
-	Title																			
Record	♦																			

Example


- \$u100 = 2 (W) [File number]
- \$u101 = 1 (W) [Top line number]
- \$u102 = 1 (W) [Top column number]
- \$u103 = 1 (W) [Number of lines]
- \$u104 = 5 (W) [Number of columns]
- LD_RECIPESL2 \$u500 \$u100 0

The above program transfers a part of data in the file "REC0002.csv" in the format of recipe No. 0 to the location starting from \$u500.



Supplemental remarks

- Recipe settings must be made in the same format as the CSV file.



- For reading text, whether to convert a null to 20H (space) or read it as "00" can be selected. For more information, refer to page 4-171.
- Difference between reading one line and reading multiple lines

	Line: Record, Column: Data	Line: Data, Column: Record																																								
CSV	CSV file <table border="1"> <thead> <tr> <th>DEC</th> <th>CHAR</th> <th>DEC</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>A</td> <td>100</td> </tr> <tr> <td>2</td> <td>B</td> <td>200</td> </tr> <tr> <td>3</td> <td>C</td> <td>300</td> </tr> <tr> <td>4</td> <td>D</td> <td>400</td> </tr> </tbody> </table>	DEC	CHAR	DEC	1	A	100	2	B	200	3	C	300	4	D	400	CSV file <table border="1"> <thead> <tr> <th>DEC</th> <th>1</th> <th>2</th> <th>3</th> <th>4</th> </tr> </thead> <tbody> <tr> <td>CHAR</td> <td>A</td> <td>B</td> <td>C</td> <td>D</td> </tr> <tr> <td>DEC</td> <td>100</td> <td>200</td> <td>300</td> <td>400</td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> </tbody> </table>	DEC	1	2	3	4	CHAR	A	B	C	D	DEC	100	200	300	400										
DEC	CHAR	DEC																																								
1	A	100																																								
2	B	200																																								
3	C	300																																								
4	D	400																																								
DEC	1	2	3	4																																						
CHAR	A	B	C	D																																						
DEC	100	200	300	400																																						
One line	Reading one line and two columns from top line No. 2 and top column No. 2 <table border="1"> <thead> <tr> <th>DEC</th> <th>CHAR</th> <th>DEC</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>A</td> <td>100</td> </tr> <tr> <td>2</td> <td>B</td> <td>200</td> </tr> <tr> <td>3</td> <td>C</td> <td>300</td> </tr> <tr> <td>4</td> <td>D</td> <td>400</td> </tr> </tbody> </table>	DEC	CHAR	DEC	1	A	100	2	B	200	3	C	300	4	D	400	Reading one line and two columns from top line No. 2 and top column No. 2 <table border="1"> <thead> <tr> <th>DEC</th> <th>1</th> <th>2</th> <th>3</th> <th>4</th> </tr> </thead> <tbody> <tr> <td>CHAR</td> <td>A</td> <td>B</td> <td>C</td> <td>D</td> </tr> <tr> <td>DEC</td> <td>100</td> <td>200</td> <td>300</td> <td>400</td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> </tbody> </table>	DEC	1	2	3	4	CHAR	A	B	C	D	DEC	100	200	300	400										
DEC	CHAR	DEC																																								
1	A	100																																								
2	B	200																																								
3	C	300																																								
4	D	400																																								
DEC	1	2	3	4																																						
CHAR	A	B	C	D																																						
DEC	100	200	300	400																																						
Two lines	Reading two lines and two columns from top line No. 2 and top column No. 2 <table border="1"> <thead> <tr> <th>DEC</th> <th>CHAR</th> <th>DEC</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>A</td> <td>100</td> </tr> <tr> <td>2</td> <td>B</td> <td>200</td> </tr> <tr> <td>3</td> <td>C</td> <td>300</td> </tr> <tr> <td>4</td> <td>D</td> <td>400</td> </tr> </tbody> </table>	DEC	CHAR	DEC	1	A	100	2	B	200	3	C	300	4	D	400	Reading two lines and two columns from top line No. 2 and top column No. 2 <table border="1"> <thead> <tr> <th>DEC</th> <th>1</th> <th>2</th> <th>3</th> <th>4</th> </tr> </thead> <tbody> <tr> <td>CHAR</td> <td>A</td> <td>B</td> <td>C</td> <td>D</td> </tr> <tr> <td>DEC</td> <td>100</td> <td>200</td> <td>300</td> <td>400</td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> </tbody> </table> <p>* Execute reading line by line (specifying multiple lines at one time is not allowed).</p>	DEC	1	2	3	4	CHAR	A	B	C	D	DEC	100	200	300	400										
DEC	CHAR	DEC																																								
1	A	100																																								
2	B	200																																								
3	C	300																																								
4	D	400																																								
DEC	1	2	3	4																																						
CHAR	A	B	C	D																																						
DEC	100	200	300	400																																						

- The result of macro execution is stored in \$s1062.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

SV_RECIPE

SV_RECIPE F0 F1 F2

All models	<input type="radio"/>
------------	-----------------------

Function: Save to CSV file

This macro command is used to save the data of words starting from the address specified in [F0] to the CSV file in [F2]. The number of the words is specified in [F1].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	
F1	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
F2	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

: Setting enabled (indirect designation disabled)
 : Setting enabled (indirect designation enabled)

4

Setting range

	Value
F0	Transfer source address
F1	1 - 4096: Word count
F2	0000 - 9999: CSV file number

CSV file

Storage target: \(\access folder)\RECIPE

File name: \RECxxx.csv

0000 - 9999: File number


The designation of the line and column numbers in a CSV file differs, depending on the options selected for [Format Setting] ([Recipe] → [File Format]). The ♦ mark indicates the position of line No. 1 and column No. 1 in a CSV file.

	<input type="checkbox"/> Add title to data	<input checked="" type="checkbox"/> Add title to data																		
<input type="checkbox"/> Add record name	<table border="1"> <tr><td>♦</td><td></td><td></td></tr> <tr><td></td><td></td><td></td></tr> <tr><td></td><td></td><td></td></tr> </table>	♦									<table border="1"> <tr><td colspan="3">Title</td></tr> <tr><td>♦</td><td></td><td></td></tr> <tr><td></td><td></td><td></td></tr> </table>	Title			♦					
♦																				
Title																				
♦																				
<input checked="" type="checkbox"/> Add record name	<table border="1"> <tr><td>Record</td><td>♦</td><td></td></tr> <tr><td></td><td></td><td></td></tr> <tr><td></td><td></td><td></td></tr> </table>	Record	♦								<table border="1"> <tr><td>-</td><td colspan="2">Title</td></tr> <tr><td>Record</td><td>♦</td><td></td></tr> <tr><td></td><td></td><td></td></tr> </table>	-	Title		Record	♦				
Record	♦																			
-	Title																			
Record	♦																			

Example


- SV_RECIPE \$u500 5 2

The above program saves the five-word data at \$u500 - 504 to the REC0002.csv file.



Supplemental remarks

- Recipe settings are required for each CSV file.



- If the specified CSV file does not exist in the storage, a new file will be created. Creating the CSV file in advance is not necessary.
- The result of macro execution is stored in \$s1062. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

SV_RECIP2

SV_RECIP2 F0 F1 F2 F3

All models	<input type="radio"/>
------------	-----------------------

Function: Save to CSV file (recipe No. designation)

This macro command is used to save the data of words specified in [F1] starting from the address [F0] to the CSV file number [F2] in the format of the recipe number [F3].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙	⊙	⊙	
F1	○	○	○	○
F2	○	○	○	○
F3	○	○	○	○

○ : Setting enabled (indirect designation disabled)

⊙ : Setting enabled (indirect designation enabled)

Setting range

	Value
F0	Transfer source address
F1	1 - 4096: Word count
F2	0000 - 9999: CSV file number
F3	0 - 255: Recipe number

CSV file

Storage target: \(\text{access folder})\RECIPE

File name: \RECxxx.csv

0000 - 9999: File No.


The designation of the line and column numbers in a CSV file differs, depending on the options selected for [Format Setting] ([Recipe] → [File Format]). The ♦ mark indicates the position of line No. 1 and column No. 1 in a CSV file.

	<input type="checkbox"/> Add title to data	<input checked="" type="checkbox"/> Add title to data																		
<input type="checkbox"/> Add record name	<table border="1"> <tr> <td>♦</td> <td></td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> </tr> </table>	♦									<table border="1"> <tr> <td colspan="3">Title</td> </tr> <tr> <td>♦</td> <td></td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> </tr> </table>	Title			♦					
♦																				
Title																				
♦																				
<input checked="" type="checkbox"/> Add record name	<table border="1"> <tr> <td>Record</td> <td>♦</td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> </tr> </table>	Record	♦								<table border="1"> <tr> <td>-</td> <td colspan="2">Title</td> </tr> <tr> <td>Record</td> <td>♦</td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> </tr> </table>	-	Title		Record	♦				
Record	♦																			
-	Title																			
Record	♦																			

Example


- SV_RECIP2 PLC1 [D400] 10 9999 0

The above program saves the ten-word data at D400 - 409 in PLC1 to the file "REC9999.csv" in the format of recipe No. 0.



Supplemental remarks

- Recipe settings must be made in the same format as the CSV file.



- If the specified CSV file does not exist in the storage, a new file will be created. Creating the CSV file in advance is not necessary.
- The result of macro execution is stored in \$S1062. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

SV_RECIPESSEL

SV_RECIPESSEL F0 F1

All models	<input type="radio"/>
------------	-----------------------

Function: Save to CSV file

This macro command is used to save the data at the location starting from the address specified in [F0] to the specified line/column in the CSV file in [F1].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙	⊙	⊙	
F1	⊙	⊙	⊙	

○ : Setting enabled (indirect designation disabled)
 ⊙ : Setting enabled (indirect designation enabled)

Setting range

	Value	
	Line: Record, Column: Data	Line: Data, Column: Record
F0	Transfer source address	
F1	0000 - 9999: CSV file number	
F1+1	1 - 32767: Top line number	1 - 4096: Top line number
F1+2	0* - 4096: Top column number	0* - 4096: Top column number
F1+3	1 - 4096: Number of lines	1 - 4096: Number of lines
F1+4	1 - 4096: Number of columns	1 - 4096: Number of columns

* Specify "0" if you wish to transfer the record name as well. In that case, select [Record Name + Data] for [Transfer Target] under [Transfer Device Setting] ([Recipe] → [File Format]). The number of columns specified in F1+4 includes the cell of the record name.

CSV file

Storage target: \access folder\RECIPE

File name: \RECxxx.csv

0000 - 9999: File No.


The designation of the line and column numbers in a CSV file differs, depending on the options selected for [Format Setting] ([Recipe] → [File Format]). The ♦ mark indicates the position of line No. 1 and column No. 1 in a CSV file.

	<input type="checkbox"/> Add title to data	<input checked="" type="checkbox"/> Add title to data																		
<input type="checkbox"/> Add record name	<table border="1"> <tr> <td>♦</td> <td></td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> </tr> </table>	♦									<table border="1"> <tr> <td colspan="3">Title</td> </tr> <tr> <td>♦</td> <td></td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> </tr> </table>	Title			♦					
♦																				
Title																				
♦																				
<input checked="" type="checkbox"/> Add record name	<table border="1"> <tr> <td>Record</td> <td>♦</td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> </tr> </table>	Record	♦								<table border="1"> <tr> <td>-</td> <td colspan="2">Title</td> </tr> <tr> <td>Record</td> <td>♦</td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> </tr> </table>	-	Title		Record	♦				
Record	♦																			
-	Title																			
Record	♦																			

Example


- \$u100 = 0 (W) [File number]
- \$u101 = 3 (W) [Top line number]
- \$u102 = 1 (W) [Top column number]
- \$u103 = 1 (W) [Number of lines]
- \$u104 = 2 (W) [Number of columns]
- SV_RECIPSEL \$u300 \$u100

The above program saves the data at the location starting from \$u300 to line No. 3 in the REC0000.csv file.



Supplemental remarks

- Recipe settings are required for each CSV file.



- If the specified CSV file does not exist in the storage, a new file will be created. Creating the CSV file in advance is not necessary.
- The result of macro execution is stored in \$s1062.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

SV_RECIPESL2 SV_RECIPESL2 F0 F1 F2

All models	<input type="radio"/>
------------	-----------------------

Function: Save to CSV file (recipe No. designation)

This macro command is used to save the data at the location starting from the address specified in [F0] in the format of the recipe number in [F2] to the specified line/column in the CSV file in [F1].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙	⊙	⊙	
F1	⊙	⊙	⊙	
F2	○	○	○	○

○ : Setting enabled (indirect designation disabled)
 ⊙ : Setting enabled (indirect designation enabled)

Setting range

	Value	
	Line: Record, Column: Data	Line: Data, Column: Record
F0	Transfer source address	
F1	0000 - 9999: CSV file number	
F1+1	1 - 32767: Top line number	1 - 4096: Top line number
F1+2	0* - 4096: Top column number	0* - 4096: Top column number
F1+3	1 - 32767: Number of lines	1 - 4096: Number of lines
F1+4	1 - 4096: Number of columns	1 - 4096: Number of columns
F2	0 - 255: Recipe number	

* Specify "0" if you wish to transfer the record name as well. In that case, select [Record Name + Data] for [Transfer Target] under [Transfer Device Setting] ([Recipe] → [File Format]) The number of columns specified in F1+4 includes the cell of the record name.

CSV file

Storage target: \(\access folder)\RECIPE

File name: \RECxxxx.csv

0000 - 9999: File No.


The designation of the line and column numbers in a CSV file differs, depending on the options selected for [Format Setting] ([Recipe] → [File Format]). The ♦ mark indicates the position of line No. 1 and column No. 1 in a CSV file.

	<input type="checkbox"/> Add title to data	<input checked="" type="checkbox"/> Add title to data																		
<input type="checkbox"/> Add record name	<table border="1"> <tr><td>♦</td><td></td><td></td></tr> <tr><td></td><td></td><td></td></tr> <tr><td></td><td></td><td></td></tr> </table>	♦									<table border="1"> <tr><td colspan="3">Title</td></tr> <tr><td>♦</td><td></td><td></td></tr> <tr><td></td><td></td><td></td></tr> </table>	Title			♦					
♦																				
Title																				
♦																				
<input checked="" type="checkbox"/> Add record name	<table border="1"> <tr><td>Record</td><td>♦</td><td></td></tr> <tr><td></td><td></td><td></td></tr> <tr><td></td><td></td><td></td></tr> </table>	Record	♦								<table border="1"> <tr><td>-</td><td colspan="2">Title</td></tr> <tr><td>Record</td><td>♦</td><td></td></tr> <tr><td></td><td></td><td></td></tr> </table>	-	Title		Record	♦				
Record	♦																			
-	Title																			
Record	♦																			

Example


- \$u100 = 9000 (W) [File number]
- \$u101 = 2 (W) [Top line number]
- \$u102 = 1 (W) [Top column number]
- \$u103 = 1 (W) [Number of lines]
- \$u104 = 5 (W) [Number of columns]
- SV_RECIPESL2 \$u300 \$u100 0

The above program saves the data at the location starting from \$u300 in the format of recipe No. 3 to line No. 2 in the REC9000.csv file.



Supplemental remarks

- Recipe settings must be made in the same format as the CSV file.



- If the specified CSV file does not exist in the storage, a new file will be created. Creating the CSV file in advance is not necessary.
- The result of macro execution is stored in \$s1062. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

SET_RECIPEFOLDER

All models	<input type="radio"/>
------------	-----------------------

SET_RECIPEFOLDER F0

Function: Folder designation

This macro command is used to designate the folder storing CSV files in [F0].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙			

- : Setting enabled (indirect designation disabled)
 ⊙ : Setting enabled (indirect designation enabled)

Setting range


	Value
F0	
F0+1	ASCII code (8 one-byte upper-case alphanumeric characters*1): Access target folder name*2
F0+2	
F0+3	

*1 These options under [System Setting] → [Unit Setting] → [General Setting] must be checked:

- [File name designation in Recipe Macro (V7 compatible)]
- [Allow max. 8 characters for naming files used in V8 recipe mode (V8 compatible)]

Maximum number of the character will be 64 words when [Allow max. 8 characters for naming files used in V8 recipe mode (V8 compatible)] is not checked. (32 words in total from F0 to F0 + 31 will be occupied.)

*2 Text processing (LSB → MSB or MSB → LSB) for the folder name is determined whether [Follow to the PLC1 setting for the text process in a recipe file.] on the [General Settings] tab window that is displayed by [System Setting] → [Unit Setting] is checked or not.



<input checked="" type="checkbox"/> Follow to the PLC1 setting for the text process in a recipe file.	<input type="checkbox"/> Follow to the PLC1 setting for the text process in a recipe file.
Text processing specified for the PLC1	Fixed to "LSB → MSB"

Example

- \$u100 = 4154H (W) 54 41 52 47 45 54 = TARGET
- \$u101 = 4752H (W) (ASCII)
- \$u102 = 5445H (W)
- \$u103 = 0000H (W)
- SET_RECIPFOLDER \$u100

The above program specifies the folder at \(\access folder)\RECIPE\TARGET.

- The CHR or STRING macro command will simplify the designation of a folder if it is a fixed name.
 - (When text processing is performed according to the setting on the PLC1: use a "CHR" command.)
 - \$u100 = 'TARGET'
 - SET_RECIPFOLDER \$u100
 - (When "LSB → MSB" is selected: use a "STRING" command.)
 - \$u100 = 'TARGET' (STRING)
 - SET_RECIPFOLDER \$u100

Supplemental remarks

- Four consecutive words starting from the address in [F0] are used. Be sure that these words are not already used elsewhere.
- Once the macro command is executed, the effect is maintained until any of the following takes place.
 - Turning off the power
 - Switching the V series from a state of RUN to STOP (Local mode)
 - Removing the storage device
 Execute the macro command again after any of the above or if you access a CSV file in a different folder.
- The result of macro execution is stored in \$s1062.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

RD_RECIPE_FILE RD_RECIPE_FILE F0 F1

All models	<input type="radio"/>
------------	-----------------------

Function: Read CSV file

This macro command is used to transfer all data in the CSV file specified in [F1] to the address in [F0].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙	⊙	⊙	
F1	⊙	⊙	⊙	

○ : Setting enabled (indirect designation disabled)
 ⊙ : Setting enabled (indirect designation enabled)

Setting range

	Value
F0	Transfer target
F1	ASCII code (8 one-byte upper-case alphanumeric characters*1): CSV file name**2
F1+1	
F1+2	
F1+3	

*1 These options under [System Setting] → [Unit Setting] → [General Setting] must be checked:

- [File name designation in Recipe Macro (V7 compatible)]
- [Allow max. 8 characters for naming files used in V8 recipe mode (V8 compatible)]

Maximum number of the character will be 64 words when [Allow max. 8 characters for naming files used in V8 recipe mode (V8 compatible)] is not checked. (32 words in total from F0 to F0 + 31 will be occupied.)

*2 For details on text processing of the file name, refer to “Supplemental remarks” on Page 4-193.

CSV file

Storage target: \(\access folder)\RECIPE\(\arbitrary folder)

File name: \xxxxxxx.csv

8 one-byte upper-case alphanumeric characters or less

The designation of the line and column numbers in a CSV file differs, depending on the options selected for [Format Setting] ([Recipe] → [File Format]). The ♦ mark indicates the position of line No. 1 and column No. 1 in a CSV file.

	<input type="checkbox"/> Add title to data	<input checked="" type="checkbox"/> Add title to data																		
<input type="checkbox"/> Add record name	<table border="1"> <tr><td>♦</td><td></td><td></td></tr> <tr><td></td><td></td><td></td></tr> <tr><td></td><td></td><td></td></tr> </table>	♦									<table border="1"> <tr><td colspan="3">Title</td></tr> <tr><td>♦</td><td></td><td></td></tr> <tr><td></td><td></td><td></td></tr> </table>	Title			♦					
♦																				
Title																				
♦																				
<input checked="" type="checkbox"/> Add record name	<table border="1"> <tr><td>Record</td><td>♦</td><td></td></tr> <tr><td></td><td></td><td></td></tr> <tr><td></td><td></td><td></td></tr> </table>	Record	♦								<table border="1"> <tr><td>-</td><td colspan="2">Title</td></tr> <tr><td>Record</td><td>♦</td><td></td></tr> <tr><td></td><td></td><td></td></tr> </table>	-	Title		Record	♦				
Record	♦																			
-	Title																			
Record	♦																			


Example

- \$u100 = 'TARGET'
 - SET_RECIPFOLDER \$u100
 - \$u110 = 5250H (W)
 - \$u111 = 444FH (W)
 - \$u112 = 4355H (W)
 - \$u113 = 3154H (W)
 - RD_RECIPF_FILE PLC1 [D200] \$u110
- } Not required if SET_FOLDER has
already been executed
- } 50 52 4F 44 55 43 54 31 = PRODUCT1
(ASCII)

The above program transfers all data in the PRODUCT1.csv file stored in the TARGET folder to PLC1: D200.

Supplemental remarks

- Four consecutive words starting from the address in [F1] are used. Be sure that these words are not already used elsewhere.
- If the CSV file specified in [F1] does not exist, a storage read error occurs (\$s497 = 16).
- For reading text, whether to convert a null to 20H (space) or read it as "00" can be selected. For more information, refer to page 4-171.
- Text processing (LSB → MSB or MSB → LSB) for the file name is determined whether [Follow to the PLC1 setting for the text process in a recipe file.] on the [General Settings] tab window that is displayed by [System Setting] → [Unit Setting] is checked or not.



Device memory	<input checked="" type="checkbox"/> Follow to the PLC1 setting for the text process in a recipe file.	<input type="checkbox"/> Follow to the PLC1 setting for the text process in a recipe file.
Internal device memory	Text processing specified for the PLC1	Fixed to "LSB → MSB"
PLC 1 - 8 device memory	Text processing specified for the PLC1	Text processing specified for each PLC

- The result of macro execution is stored in \$s1062. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

RD_RECIFE_LINE RD_RECIFE_LINE F0 F1 F2 F3

All models	<input type="radio"/>
------------	-----------------------

Function: Read CSV file (line designation)

This macro command is used to transfer the data of specified lines in the [F1]-specified CSV file to the address in [F0].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙	⊙	⊙	
F1	⊙	⊙	⊙	
F2	⊙	⊙	⊙	○
F3	⊙	⊙	⊙	○

○ : Setting enabled (indirect designation disabled)

⊙ : Setting enabled (indirect designation enabled)

Setting range

	Value			
	Line: Record, Column: Data		Line: Data, Column: Record	
F0	Transfer target			
F1	ASCII code (8 one-byte upper-case alphanumeric characters ^{*1}): CSV file name ^{*2}			
F1+1				
F1+2				
F1+3				
F2	1 - 32767:	Top line	1 - 4096:	Top line
F3	1 - 32767:	Final line	1 - 4096:	Final line

*1 These options under [System Setting] → [Unit Setting] → [General Setting] must be checked:

- [File name designation in Recipe Macro (V7 compatible)]
- [Allow max. 8 characters for naming files used in V8 recipe mode (V8 compatible)]

Maximum number of the character will be 64 words when [Allow max. 8 characters for naming files used in V8 recipe mode (V8 compatible)] is not checked. (32 words in total from F0 to F0 + 31 will be occupied.)

*2 For details on text processing of the file name, refer to "Supplemental remarks" on page 4-193.

CSV file

Storage target: \(\access folder)\RECIPE\(\arbitrary folder)

File name: \xxxxxxx.csv

8 one-byte upper-case alphanumeric characters or less

The designation of the line and column numbers in a CSV file differs, depending on the options selected for [Format Setting] ([Recipe] → [File Format]). The ♦ mark indicates the position of line No. 1 and column No. 1 in a CSV file.

	<input type="checkbox"/> Add title to data	<input checked="" type="checkbox"/> Add title to data																					
<input type="checkbox"/> Add record name	<table border="1"> <tr><td>♦</td><td></td><td></td></tr> <tr><td></td><td></td><td></td></tr> <tr><td></td><td></td><td></td></tr> </table>	♦									<table border="1"> <tr><td colspan="4">Title</td></tr> <tr><td>♦</td><td></td><td></td><td></td></tr> <tr><td></td><td></td><td></td><td></td></tr> </table>	Title				♦							
♦																							
Title																							
♦																							
<input checked="" type="checkbox"/> Add record name	<table border="1"> <tr><td>Record</td><td>♦</td><td></td></tr> <tr><td></td><td></td><td></td></tr> <tr><td></td><td></td><td></td></tr> </table>	Record	♦								<table border="1"> <tr><td>-</td><td colspan="3">Title</td></tr> <tr><td>Record</td><td>♦</td><td></td><td></td></tr> <tr><td></td><td></td><td></td><td></td></tr> </table>	-	Title			Record	♦						
Record	♦																						
-	Title																						
Record	♦																						

Example

- \$u100 = 'TARGET'
SET_RECIPFOLDER \$u100
\$u110 = 5250H (W)
\$u111 = 444FH (W)
\$u112 = 4355H (W)
\$u113 = 3154H (W)
RD_RECIPFOLDER PLC1 [D200] \$u110 3 3

Not required if SET_FOLDER has already been executed

50 52 4F 44 55 43 54 31 = PRODUCT1 (ASCII)

The above program transfers line No. 3 (record No. 3) data in the PRODUCT1.csv file stored in the TARGET folder to PLC1: D200.

Supplemental remarks

- Four consecutive words starting from the address in [F1] are used. Be sure that these words are not already used elsewhere.
- If the CSV file specified in [F1] does not exist, a storage read error occurs (\$s497 = 16).
- For reading text, whether to convert a null to 20H (space) or read it as "00" can be selected. For more information, refer to page 4-171.
- Difference between reading one line and reading multiple lines

	Line: Record, Column: Data	Line: Data, Column: Record																																								
CSV	<p>CSV file</p> <table border="1"> <thead> <tr><th>DEC</th><th>CHAR</th><th>DEC</th></tr> </thead> <tbody> <tr><td>1</td><td>A</td><td>100</td></tr> <tr><td>2</td><td>B</td><td>200</td></tr> <tr><td>3</td><td>C</td><td>300</td></tr> <tr><td>4</td><td>D</td><td>400</td></tr> </tbody> </table>	DEC	CHAR	DEC	1	A	100	2	B	200	3	C	300	4	D	400	<p>CSV file</p> <table border="1"> <thead> <tr><th>DEC</th><th>1</th><th>2</th><th>3</th><th>4</th></tr> </thead> <tbody> <tr><td>CHAR</td><td>A</td><td>B</td><td>C</td><td>D</td></tr> <tr><td>DEC</td><td>100</td><td>200</td><td>300</td><td>400</td></tr> <tr><td></td><td></td><td></td><td></td><td></td></tr> <tr><td></td><td></td><td></td><td></td><td></td></tr> </tbody> </table>	DEC	1	2	3	4	CHAR	A	B	C	D	DEC	100	200	300	400										
DEC	CHAR	DEC																																								
1	A	100																																								
2	B	200																																								
3	C	300																																								
4	D	400																																								
DEC	1	2	3	4																																						
CHAR	A	B	C	D																																						
DEC	100	200	300	400																																						
One line	<p>Reading based on top line No. 2 and final line No. 2</p> <table border="1"> <thead> <tr><th>DEC</th><th>CHAR</th><th>DEC</th></tr> </thead> <tbody> <tr><td>1</td><td>A</td><td>100</td></tr> <tr><td>2</td><td>B</td><td>200</td></tr> <tr><td>3</td><td>C</td><td>300</td></tr> <tr><td>4</td><td>D</td><td>400</td></tr> </tbody> </table>	DEC	CHAR	DEC	1	A	100	2	B	200	3	C	300	4	D	400	<p>Reading based on top line No. 2 and final line No. 2</p> <table border="1"> <thead> <tr><th>DEC</th><th>1</th><th>2</th><th>3</th><th>4</th></tr> </thead> <tbody> <tr><td>CHAR</td><td>A</td><td>B</td><td>C</td><td>D</td></tr> <tr><td>DEC</td><td>100</td><td>200</td><td>300</td><td>400</td></tr> <tr><td></td><td></td><td></td><td></td><td></td></tr> <tr><td></td><td></td><td></td><td></td><td></td></tr> </tbody> </table>	DEC	1	2	3	4	CHAR	A	B	C	D	DEC	100	200	300	400										
DEC	CHAR	DEC																																								
1	A	100																																								
2	B	200																																								
3	C	300																																								
4	D	400																																								
DEC	1	2	3	4																																						
CHAR	A	B	C	D																																						
DEC	100	200	300	400																																						

	Line: Record, Column: Data	Line: Data, Column: Record																																							
Two lines	Reading based on top line No. 2 and final line No. 3	Reading based on top line No. 2 and final line No. 3																																							
	<table border="1"> <thead> <tr> <th>DEC</th> <th>CHAR</th> <th>DEC</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>A</td> <td>100</td> </tr> <tr> <td>2</td> <td>B</td> <td>200</td> </tr> <tr> <td>3</td> <td>C</td> <td>300</td> </tr> <tr> <td>4</td> <td>D</td> <td>400</td> </tr> </tbody> </table>	DEC	CHAR	DEC	1	A	100	2	B	200	3	C	300	4	D	400	<table border="1"> <thead> <tr> <th>DEC</th> <th>1</th> <th>2</th> <th>3</th> <th>4</th> </tr> </thead> <tbody> <tr> <th>CHAR</th> <td>A</td> <td>B</td> <td>C</td> <td>D</td> </tr> <tr> <th>DEC</th> <td>100</td> <td>200</td> <td>300</td> <td>400</td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> </tbody> </table> <p>* Execute reading line by line (specifying multiple lines at one time is not allowed).</p>	DEC	1	2	3	4	CHAR	A	B	C	D	DEC	100	200	300	400									
DEC	CHAR	DEC																																							
1	A	100																																							
2	B	200																																							
3	C	300																																							
4	D	400																																							
DEC	1	2	3	4																																					
CHAR	A	B	C	D																																					
DEC	100	200	300	400																																					

- The result of macro execution is stored in \$s1062. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

RD_RECIP_ COLUMN

All models	<input type="radio"/>
------------	-----------------------

RD_RECIP_ COLUMN F0 F1 F2 F3

Function: Read CSV file (column designation)

This macro command is used to transfer the data of specified columns in the [F1]-specified CSV file to the address in [F0].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙	⊙	⊙	
F1	⊙	⊙	⊙	
F2	⊙	⊙	⊙	○
F3	⊙	⊙	⊙	○

○ : Setting enabled (indirect designation disabled)
 ⊙ : Setting enabled (indirect designation enabled)

4

Setting range

	Value	
	Line: Record, Column: Data	Line: Data, Column: Record
F0	Transfer target	
F1	ASCII code (8 one-byte upper-case alphanumeric characters ^{*1}): CSV file name ^{*2}	
F1+1		
F1+2		
F1+3		
F2	0: Column of record name 1 - 4096: Top column of data	
F3	0: Column of record name 1 - 4096: Final column of data	

*1 These options under [System Setting] → [Unit Setting] → [General Setting] must be checked:

- [File name designation in Recipe Macro (V7 compatible)]
- [Allow max. 8 characters for naming files used in V8 recipe mode (V8 compatible)]

Maximum number of the character will be 64 words when [Allow max. 8 characters for naming files used in V8 recipe mode (V8 compatible)] is not checked. (32 words in total from F0 to F0 + 31 will be occupied.)

*2 For details on text processing of the file name, refer to "Supplemental remarks" on page 4-193.

CSV file

Storage target: \(\access folder)\RECIPE\(\arbitrary folder)

File name: \xxxxxxx.csv

8 one-byte upper-case alphanumeric characters or less

The designation of the line and column numbers in a CSV file differs, depending on the options selected for [Format Setting] ([Recipe] → [File Format]). The ♦ mark indicates the position of line No. 1 and column No. 1 in a CSV file.

	<input type="checkbox"/> Add title to data	<input checked="" type="checkbox"/> Add title to data																		
<input type="checkbox"/> Add record name	<table border="1"> <tr><td>♦</td><td></td><td></td></tr> <tr><td></td><td></td><td></td></tr> <tr><td></td><td></td><td></td></tr> </table>	♦									<table border="1"> <tr><td colspan="3">Title</td></tr> <tr><td>♦</td><td></td><td></td></tr> <tr><td></td><td></td><td></td></tr> </table>	Title			♦					
♦																				
Title																				
♦																				
<input checked="" type="checkbox"/> Add record name	<table border="1"> <tr><td>Record</td><td>♦</td><td></td></tr> <tr><td></td><td></td><td></td></tr> <tr><td></td><td></td><td></td></tr> </table>	Record	♦								<table border="1"> <tr><td>-</td><td colspan="2">Title</td></tr> <tr><td>Record</td><td>♦</td><td></td></tr> <tr><td></td><td></td><td></td></tr> </table>	-	Title		Record	♦				
Record	♦																			
-	Title																			
Record	♦																			

Example

- \$u100 = 'TARGET'
 SET_RECIPFOLDER \$u100
 \$u110 = 5250H (W)
 \$u111 = 444FH (W)
 \$u112 = 4355H (W)
 \$u113 = 3154H (W)
 RD_RECIPFOLDER PLC1 [D300] \$u110 5 5

Not required if SET_FOLDER has already been executed
 50 52 4F 44 55 43 54 31 = PRODUCT1 (ASCII)

The above program transfers column No. 5 data in the PRODUCT1.csv file stored in the TARGET folder to PLC1: D300.

Supplemental remarks

- Four consecutive words starting from the address in [F1] are used. Be sure that these words are not already used elsewhere.
- If the CSV file specified in [F1] does not exist, a storage read error occurs (\$s497 = 16).
- For reading text, whether to convert a null to 20H (space) or read it as "00" can be selected. For more information, refer to page 4-171.
- Difference between reading one column and reading multiple columns

	Line: Record, Column: Data	Line: Data, Column: Record																																			
CSV	<p>CSV file</p> <table border="1"> <tr><td>DEC</td><td>CHAR</td><td>DEC</td></tr> <tr><td>1</td><td>A</td><td>100</td></tr> <tr><td>2</td><td>B</td><td>200</td></tr> <tr><td>3</td><td>C</td><td>300</td></tr> <tr><td>4</td><td>D</td><td>400</td></tr> </table>	DEC	CHAR	DEC	1	A	100	2	B	200	3	C	300	4	D	400	<p>CSV file</p> <table border="1"> <tr><td>DEC</td><td>1</td><td>2</td><td>3</td><td>4</td></tr> <tr><td>CHAR</td><td>A</td><td>B</td><td>C</td><td>D</td></tr> <tr><td>DEC</td><td>100</td><td>200</td><td>300</td><td>400</td></tr> <tr><td></td><td></td><td></td><td></td><td></td></tr> </table>	DEC	1	2	3	4	CHAR	A	B	C	D	DEC	100	200	300	400					
	DEC	CHAR	DEC																																		
1	A	100																																			
2	B	200																																			
3	C	300																																			
4	D	400																																			
DEC	1	2	3	4																																	
CHAR	A	B	C	D																																	
DEC	100	200	300	400																																	
One line	<p>Reading based on top column No. 2 and final column No. 2</p> <table border="1"> <tr><td>DEC</td><td>CHAR</td><td>DEC</td></tr> <tr><td>1</td><td>A</td><td>100</td></tr> <tr><td>2</td><td>B</td><td>200</td></tr> <tr><td>3</td><td>C</td><td>300</td></tr> <tr><td>4</td><td>D</td><td>400</td></tr> </table>	DEC	CHAR	DEC	1	A	100	2	B	200	3	C	300	4	D	400	<p>Reading based on top column No. 2 and final column No. 2</p> <table border="1"> <tr><td>DEC</td><td>1</td><td>2</td><td>3</td><td>4</td></tr> <tr><td>CHAR</td><td>A</td><td>B</td><td>C</td><td>D</td></tr> <tr><td>DEC</td><td>100</td><td>00</td><td>300</td><td>400</td></tr> <tr><td></td><td></td><td></td><td></td><td></td></tr> </table>	DEC	1	2	3	4	CHAR	A	B	C	D	DEC	100	00	300	400					
DEC	CHAR	DEC																																			
1	A	100																																			
2	B	200																																			
3	C	300																																			
4	D	400																																			
DEC	1	2	3	4																																	
CHAR	A	B	C	D																																	
DEC	100	00	300	400																																	

	Line: Record, Column: Data	Line: Data, Column: Record																																								
Two lines	Reading based on top column No. 2 and final column No. 3	Reading based on top column No. 2 and final column No. 3																																								
	<table border="1"> <thead> <tr> <th>DEC</th> <th>CHAR</th> <th>DEC</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>A</td> <td>100</td> </tr> <tr> <td>2</td> <td>B</td> <td>200</td> </tr> <tr> <td>3</td> <td>C</td> <td>300</td> </tr> <tr> <td>4</td> <td>D</td> <td>400</td> </tr> </tbody> </table>	DEC	CHAR	DEC	1	A	100	2	B	200	3	C	300	4	D	400	<table border="1"> <thead> <tr> <th>DEC</th> <th>1</th> <th>2</th> <th>3</th> <th>4</th> </tr> </thead> <tbody> <tr> <td>CHAR</td> <td>A</td> <td>B</td> <td>C</td> <td>D</td> </tr> <tr> <td>DEC</td> <td>100</td> <td>200</td> <td>300</td> <td>400</td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> </tbody> </table>	DEC	1	2	3	4	CHAR	A	B	C	D	DEC	100	200	300	400										
	DEC	CHAR	DEC																																							
	1	A	100																																							
2	B	200																																								
3	C	300																																								
4	D	400																																								
DEC	1	2	3	4																																						
CHAR	A	B	C	D																																						
DEC	100	200	300	400																																						
	* Execute reading column by column (specifying multiple columns at one time is not allowed).																																									

- The result of macro execution is stored in \$s1062. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

WR_RECIPE_FILE WR_RECIPE_FILE F0 F1

All models	<input type="radio"/>
------------	-----------------------

Function: Save to CSV file

This macro command is used to save the data at the location starting from the address specified in [F0] to the CSV file in [F1].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	
F1	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	

: Setting enabled (indirect designation disabled)
 : Setting enabled (indirect designation enabled)

Setting range

	Value
F0	Transfer source
F1	ASCII code (8 one-byte upper-case alphanumeric characters*1): CSV file name*2
F1+1	
F1+2	
F1+3	

*1 These options under [System Setting] → [Unit Setting] → [General Setting] must be checked:

- [File name designation in Recipe Macro (V7 compatible)]
- [Allow max. 8 characters for naming files used in V8 recipe mode (V8 compatible)]

Maximum number of the character will be 64 words when [Allow max. 8 characters for naming files used in V8 recipe mode (V8 compatible)] is not checked. (32 words in total from F0 to F0 + 31 will be occupied.)

*2 For details on text processing of the file name, refer to “Supplemental remarks” on page 4-193.

CSV file

Storage target: \(\access folder)\RECIPE\(\arbitrary folder)

File name: \xxxxxxx.csv

8 one-byte upper-case alphanumeric characters or less

The designation of the line and column numbers in a CSV file differs, depending on the options selected for [Format Setting] ([Recipe] → [File Format]). The ♦ mark indicates the position of line No. 1 and column No. 1 in a CSV file.

	<input type="checkbox"/> Add title to data	<input checked="" type="checkbox"/> Add title to data																		
<input type="checkbox"/> Add record name	<table border="1"> <tr><td>♦</td><td></td><td></td></tr> <tr><td></td><td></td><td></td></tr> <tr><td></td><td></td><td></td></tr> </table>	♦									<table border="1"> <tr><td colspan="3">Title</td></tr> <tr><td>♦</td><td></td><td></td></tr> <tr><td></td><td></td><td></td></tr> </table>	Title			♦					
♦																				
Title																				
♦																				
<input checked="" type="checkbox"/> Add record name	<table border="1"> <tr><td>Record</td><td>♦</td><td></td></tr> <tr><td></td><td></td><td></td></tr> <tr><td></td><td></td><td></td></tr> </table>	Record	♦								<table border="1"> <tr><td>-</td><td colspan="2">Title</td></tr> <tr><td>Record</td><td>♦</td><td></td></tr> <tr><td></td><td></td><td></td></tr> </table>	-	Title		Record	♦				
Record	♦																			
-	Title																			
Record	♦																			

Example

- \$u100 = 'TARGET'
 - SET_RECIPFOLDER \$u100
 - \$u110 = 5250H (W)
 - \$u111 = 444FH (W)
 - \$u112 = 4355H (W)
 - \$u113 = 3754H (W)
 - WR_RECIPF_FILE PLC1 [D200] \$u110
-] Not required if SET_FOLDER has
already been executed
-] 50 52 4F 44 55 43 54 37 = PRODUCT7
(ASCII)

The above program overwrites the PRODUCT7.csv file stored in the TARGET folder with the data at the location starting from PLC1: D200.

Supplemental remarks

- Four consecutive words starting from the address in [F1] are used. Be sure that these words are not already used elsewhere.
- If the CSV file specified in [F1] does not exist, a storage read error occurs (\$s497 = 16).
- The result of macro execution is stored in \$s1062.

When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

WR_RECIPE_LINE WR_RECIPE_LINE F0 F1 F2 F3

All models	<input type="radio"/>
------------	-----------------------

Function: Save to CSV file (line designation)

This macro command is used to save the data at addresses from the one specified in [F0] in a specified line, or an additional final line, of the CSV file specified in [F1].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙	⊙	⊙	
F1	⊙	⊙	⊙	
F2	⊙	⊙	⊙	○
F3	⊙	⊙	⊙	○

○ : Setting enabled (indirect designation disabled)

⊙ : Setting enabled (indirect designation enabled)

Setting range

	Value	
	Line: Record, Column: Data	Line: Data, Column: Record
F0	Transfer source	
F1	ASCII code (8 one-byte upper-case alphanumeric characters ^{*1}): CSV file name ^{*2}	
F1+1		
F1+2		
F1+3		
F2	1 - 32767: Top line -1: Additional final line ^{*3}	1 - 4096: Top line
F3	1 - 32767: Final line -1: Additional final line ^{*3}	1 - 4096: Final line

^{*1} These options under [System Setting] → [Unit Setting] → [General Setting] must be checked:

- [File name designation in Recipe Macro (V7 compatible)]
- [Allow max. 8 characters for naming files used in V8 recipe mode (V8 compatible)]

Maximum number of the character will be 64 words when [Allow max. 8 characters for naming files used in V8 recipe mode (V8 compatible)] is not checked. (32 words in total from F0 to F0 + 31 will be occupied.)

^{*2} For details on text processing of the file name, refer to "Supplemental remarks" on page 4-193.

^{*3} An additional final line is only saved if "-1" is set for both F2 and F3.

CSV file

Storage target: \(\access folder\)RECIPE\(\arbitrary folder\)

File name: \xxxxxxx.csv

8 one-byte upper-case alphanumeric characters or less

The designation of the line and column numbers in a CSV file differs, depending on the options selected for [Format Setting] ([Recipe] → [File Format]). The ♦ mark indicates the position of line No. 1 and column No. 1 in a CSV file.

	<input type="checkbox"/> Add title to data	<input checked="" type="checkbox"/> Add title to data																		
<input type="checkbox"/> Add record name	<table border="1"> <tr><td>♦</td><td></td><td></td></tr> <tr><td></td><td></td><td></td></tr> <tr><td></td><td></td><td></td></tr> </table>	♦									<table border="1"> <tr><td colspan="3">Title</td></tr> <tr><td>♦</td><td></td><td></td></tr> <tr><td></td><td></td><td></td></tr> </table>	Title			♦					
♦																				
Title																				
♦																				
<input checked="" type="checkbox"/> Add record name	<table border="1"> <tr><td>Record</td><td>♦</td><td></td></tr> <tr><td></td><td></td><td></td></tr> <tr><td></td><td></td><td></td></tr> </table>	Record	♦								<table border="1"> <tr><td>-</td><td colspan="2">Title</td></tr> <tr><td>Record</td><td>♦</td><td></td></tr> <tr><td></td><td></td><td></td></tr> </table>	-	Title		Record	♦				
Record	♦																			
-	Title																			
Record	♦																			

4

Example

- \$u100 = 'TARGET'
SET_RECIPFOLDER \$u100
\$u110 = 5250H (W)
\$u111 = 444FH (W)
\$u112 = 4355H (W)
\$u113 = 3754H (W)
WD_RECIPF_LINE PLC1 [D200] \$u110 3 3
-] Not required if SET_FOLDER has already been executed
-] 50 52 4F 44 55 43 54 37 = PRODUCT7 (ASCII)

The above program overwrites line No. 3 in the PRODUCT7.csv file stored in the TARGET folder with the data at the location starting from PLC1: D200.

Supplemental remarks

- Four consecutive words starting from the address in [F1] are used. Be sure that these words are not already used elsewhere.
- If the specified CSV file does not exist, specifying "1" or "-1" for [F2] creates a new file. If [F2] ≠ 1, a storage read error (\$s497 = 16) occurs. However, when [Line: Data, Column: Record] is selected, use "WR_RECIPF_COLUM" to create a new file.
- When setting "-1" for [F2] and [F3] and adding an additional final line, make sure that the number of lines does not exceed 32767. The macro will not operate correctly on files with more than 32767 lines.
- The result of macro execution is stored in \$s1062. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

WR_RECIPE_
COLUMN

All models	<input type="radio"/>
------------	-----------------------

WR_RECIPE_COLUMN F0 F1 F2 F3**Function: Save to CSV file (column designation)**

This macro command is used to save the data at the location starting from the address in [F0] to the specified column in the F1-specified CSV file.

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙	⊙	⊙	
F1	⊙	⊙	⊙	
F2	⊙	⊙	⊙	○
F3	⊙	⊙	⊙	○

○ : Setting enabled (indirect designation disabled)

⊙ : Setting enabled (indirect designation enabled)

Setting range

	Value	
	Line: Record, Column: Data	Line: Data, Column: Record
F0	Transfer source	
F1	ASCII code (8 one-byte upper-case alphanumeric characters ^{*1}): CSV file name ^{*2}	
F1+1		
F1+2		
F1+3		
F2	0: Column of record name 1 - 4096: Top column of data	
F3	0: Column of record name 1 - 4096: Final column of data	

*1 These options under [System Setting] → [Unit Setting] → [General Setting] must be checked:

- [File name designation in Recipe Macro (V7 compatible)]
- [Allow max. 8 characters for naming files used in V8 recipe mode (V8 compatible)]

Maximum number of the character will be 64 words when [Allow max. 8 characters for naming files used in V8 recipe mode (V8 compatible)] is not checked. (32 words in total from F0 to F0 + 31 will be occupied.)

*2 For details on text processing of the file name, refer to "Supplemental remarks" on page 4-193.

CSV file

Storage target: \(\text{access folder})\RECIPE\(\text{arbitrary folder})

File name: \xxxxxxx.csv

8 one-byte upper-case alphanumeric characters or less

The designation of the line and column numbers in a CSV file differs, depending on the options selected for [Format Setting] ([Recipe] → [File Format]). The ♦ mark indicates the position of line No. 1 and column No. 1 in a CSV file.

	<input type="checkbox"/> Add title to data	<input checked="" type="checkbox"/> Add title to data																		
<input type="checkbox"/> Add record name	<table border="1"> <tr><td>♦</td><td></td><td></td></tr> <tr><td></td><td></td><td></td></tr> <tr><td></td><td></td><td></td></tr> </table>	♦									<table border="1"> <tr><td colspan="3">Title</td></tr> <tr><td>♦</td><td></td><td></td></tr> <tr><td></td><td></td><td></td></tr> </table>	Title			♦					
♦																				
Title																				
♦																				
<input checked="" type="checkbox"/> Add record name	<table border="1"> <tr><td>Record</td><td>♦</td><td></td></tr> <tr><td></td><td></td><td></td></tr> <tr><td></td><td></td><td></td></tr> </table>	Record	♦								<table border="1"> <tr><td>-</td><td colspan="2">Title</td></tr> <tr><td>Record</td><td>♦</td><td></td></tr> <tr><td></td><td></td><td></td></tr> </table>	-	Title		Record	♦				
Record	♦																			
-	Title																			
Record	♦																			

Example

- \$u100 = 'TARGET'
SET_RECIPFOLDER \$u100
\$u110 = 5250H (W)
\$u111 = 444FH (W)
\$u112 = 4355H (W)
\$u113 = 3754H (W)
WR_RECIPFOLDER_COLUMN PLC1 [D300] \$u110 5 5
-] Not required if SET_FOLDER has already been executed
] 50 52 4F 44 55 43 54 37 = PRODUCT7 (ASCII)

The above program overwrites column No. 5 in the PRODUCT7.csv file stored in the TARGET folder with the data at the location starting from PLC1: D300.

Supplemental remarks

- Four consecutive words starting from the address in [F1] are used. Be sure that these words are not already used elsewhere.
- If the CSV file specified in [F1] does not exist, a storage read error occurs (\$s497 = 16).
- When [Line: Data, Column: Record] is selected, a new CSV file is created by specifying [F2] = 1.
- The result of macro execution is stored in \$s1062.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

GET_RECIPE_
FILEINFO

All models	<input type="radio"/>
------------	-----------------------

GET_RECIPE_FILEINFO F0 F1 F2**Function: CSV file information**

This macro command is used to store the number of lines/columns of the F1-specified CSV file in memory at the address in [F2].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>
F1	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	
F2	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	

: Setting enabled (indirect designation disabled)

: Setting enabled (indirect designation enabled)

Setting range

	Value
F0	0: Number of lines 1: Number of columns
F1	0000 - 9999: CSV file number designation (RECxxx.csv) -1 (FFFFH): CSV file name designation (xxxxxxx.csv)
F1+1	Valid if F1 = -1 ASCII code (8 one-byte upper-case alphanumeric characters* ¹): CSV file name* ²
F1+2	
F1+3	
F1+4	
F2	Information storage device memory

*1 These options under [System Setting] → [Unit Setting] → [General Setting] must be checked:

- [File name designation in Recipe Macro (V7 compatible)]
- [Allow max. 8 characters for naming files used in V8 recipe mode (V8 compatible)]

Maximum number of the character will be 64 words when [Allow max. 8 characters for naming files used in V8 recipe mode (V8 compatible)] is not checked. (32 words in total from F0 to F0 + 31 will be occupied.)

*2 For details on text processing of the file name, refer to "Supplemental remarks" on page 4-193.

Example

- CSV file number designation
\$u100 = 0 (W) [Line]
\$u200 = 1 (W) [File number]
GET_RECIPE_FILEINFO \$u100 \$u200 \$u300

The above program stores the number of lines of the REC0001.CSV file located in the RECIPE folder in \$u300.

- CSV file name designation
`$u400 = 'TEST'`
`SET_RECIPFOLDER $u400`] Not required if SET_FOLDER has
already been executed
`$u100 = 1 (W) [Column]`
`$u200 = -1 (W) [File name]`
`$u201 = 'SUBDATA' [File name]`
`GET_RECIPF_FILEINFO $u100 $u200 $u300`

The above program reads the number of columns in the file "SUBDATA.CSV" under the TEST folder from the recipe setting and stores it in \$u300.

Supplemental remarks

- When a CSV file name is specified, the next four consecutive words starting from the address in [F1+1] are used. Be sure that these words are not already used elsewhere.
- If [Add title to data] is checked under [Format Setting] ([Recipe] → [File Format]), the number of lines to be stored does not include the title line.
- If [Add record name] is checked under [Format Setting] ([Recipe] → [File Format]), the number of columns to be stored does not include the column of the record name.
- In the event of storing the number of columns with [Line: Record, Column: Data] checked or storing the number of lines with [Line: Data, Column: Record] checked under [Format Setting] ([Recipe] → [File Format]), the data is stored based on the readout from the settings made under [Format Setting].
- The result of macro execution is stored in \$s990.

Code (DEC)	Contents
0	Normal
1	F0 parameter invalid
2	F1 parameter invalid
3	F2 parameter invalid
4	F3 parameter invalid
5	Error found during accessing the specified file
6	Unable to process the specified file

- The result of macro execution is stored in \$s1062.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

4.18 Storage (Sampling)

SMPL_BAK

All models	<input type="radio"/>
------------	-----------------------

SMPL_BAK F0

Function: Save backup (bin file)

This macro command is used to make a backup file of logging or alarm data in block No. [F0] and to save the file to the year/month/day folder in the storage.

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	<input type="radio"/>			<input type="radio"/>

: Setting enabled (indirect designation disabled)

: Setting enabled (indirect designation enabled)

\$s1671

The output destination server (logging server, alarm server, V8 compatible operation) is changed according to the value in \$s1671.

\$s1671	Contents
0	V8 compatible operation (buffering area number designation)
1	Logging server designation
2	Alarm server designation

Setting range

	Value
F0	0 - 11: Block number

File

- Logging server

Storage target: \(\access folder)\LOGGING\(\year/month folder)\(\year/month/day folder)

File name: LOGGINGxx_YYYYMMDDHHMMSS.bin

00 - 11: Block number

Output time in year, month, day, hour, minute, and second

- Alarm server

Storage target: \(\access folder)\ALARM\(\year/month folder)\(\year/month/day folder)

File name: ALARMxx_YYYYMMDDHHMMSS.bin (alarm)

EVENTxx_YYYYMMDDHHMMSS.bin (event)


00 - 11: Block number

Output time in year, month, day, hour, minute, and second

Example

- \$s01671 = 1 (W) [Logging server designation]
SMPL_BAK 2


The above program creates a backup file for logging block 2 (LOGGING02.bin) on April 20, 2014.



4

Supplemental remarks

- This macro command is valid when [Number of Data to Save] under [Storage Output Settings] is checked in the [Output Destination] window of the logging or alarm block.



- Data stored in SRAM is output to the storage and saved in a backup file.
- The result of macro execution is stored in \$s1062. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

SMPL_CSV

All models	<input type="radio"/>
------------	-----------------------

SMPL_CSV F0**Function: Create CSV file**

This macro command is used to convert the logging or alarm data in block No. [F0] to the CSV file, and to save the file to the LOGGING or ALARM folder in the storage.

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	<input type="radio"/>			<input type="radio"/>

: Setting enabled (indirect designation disabled)

: Setting enabled (indirect designation enabled)

\$\$s1671

The output destination server (logging server, alarm server, V8 compatible operation) is changed according to the value in \$\$s1671.

\$\$s1671	Contents
0	V8 compatible operation (buffering area number designation)
1	Logging server designation
2	Alarm server designation

Setting range

	Value
F0	0 - 11: Block number

File

- Logging server

Storage target: \(\access folder)\LOGGING

File name: \xxxxxxx.csv

File name

- Alarm server

Storage target: \(\access folder)\ALARM

File name: \xxxxxxx.csv

File name


- * Specify a file name as desired in [Form Setting] in the [Logging Block] or [Alarm Block] window.

Example


- \$s01671 = 1 (W)[Logging server designation]
SMPL_CSV 1

The above program converts the data of logging block 1 to CSV format (SMP_01.CSV) and saves the file.


With [Number of Data to Save] under [Storage Output Settings] unchecked:



With [Number of Data to Save] under [Storage Output Settings] checked:

**Supplemental remarks**

- When [Number of Data to Save] under [Storage Output Settings] is checked in the [Output Destination] window, data stored in SRAM is output to the storage device and saved in a CSV file.
- [Format Setting] is required for each block number.



- If the specified file already exists, it will be overwritten.
- If the block is empty, no CSV file will be created.
- The result of macro execution is stored in \$s1062.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

SMPL_CSV2

All models	<input type="radio"/>
------------	-----------------------

SMPL_CSV2 F0 F1**Function: Create CSV file (file name designation)**

This macro command is used to convert the logging or alarm data in block No. [F0] to the CSV file under a name specified for [F1], and to save the file to the LOGGING or ALARM folder in the storage. If the specified file does not exist, a new file will be created.

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙			○
F1	⊙			

○ : Setting enabled (indirect designation disabled)

⊙ : Setting enabled (indirect designation enabled)

\$\$s1671

The output destination server (logging server, alarm server, V8 compatible operation) is changed according to the value in \$\$s1671.

\$\$s1671	Contents
0	V8 compatible operation (buffering area number designation)
1	Logging server designation
2	Alarm server designation

Setting range


	Value
F0	0 - 11: Block number
F1	ASCII code (64 one-byte uppercase alphanumerics at the maximum): CSV file name

File


- Logging server
Storage target: \\(access folder)LOGGING
File name: xxxxxxxx.csv
- Alarm server
Storage target: \\(access folder)ALARM
File name: xxxxxxxx.csv

Example


- The file named "SEISAN.CSV" is created from the data in logging block No. 1.
 \$s01671 = 1 (W) [Logging server designation]
 \$u00100 = 'SEISAN' (STRING) [Filename]
 SMPL_CSV2 1 \$u00100



With [Number of Data to Save] under [Storage Output Settings] unchecked:




With [Number of Data to Save] under [Storage Output Settings] checked:



* If [Insert/Overwrite together with STRING Command] is checked in the [Device Setting] or [Macro Editing Support] dialog, the macro command STRING can also be registered.
 For more information on STRING, refer to page 4-46.

Supplemental remarks

- When [Number of Data to Save] under [Storage Output Settings] is checked in the [Output Destination] window, data stored in SRAM is output to the storage device and saved in a CSV file.
- [Format Setting] is required for each block number.



- If the specified file already exists, it will be overwritten.
- If the block is empty, no CSV file will be created.
- A full pathname can be specified for [F1].
- The result of macro execution is stored in \$s1062.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

Restrictions

- Symbols, [], [()], [:], [*], [?], ["], [<], [>] and [()], cannot be used for a file name.

- The result of macro execution is stored in \$s1062. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

SMPLCSV_BAK

All models	<input type="radio"/>
------------	-----------------------

SMPLCSV_BAK F0**Function: Save backup (CSV file)**

This macro command is used to convert the logging or alarm data in block No. [F0] to the CSV file, and to save the file to the year/month/day folder in the storage.

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	<input type="radio"/>			<input type="radio"/>

: Setting enabled (indirect designation disabled)

: Setting enabled (indirect designation enabled)

\$s1671

The output destination server (logging server, alarm server, V8 compatible operation) is changed according to the value in \$s1671.

\$s1671	Contents
0	V8 compatible operation (buffering area number designation)
1	Logging server designation
2	Alarm server designation

Setting range

Device	Value
F0	0 - 11: Block number

File

- Logging server

Storage target: `\\(access folder)\LOGGING\year/month folder\year/month/day folder`

File name: `\\xxxxxxx_YYYYMMDDHHMMSS.csv`

File name

Output time in year, month, day, hour, minute, and second

- Alarm server

Storage target: `\\(access folder)\ALARM\year/month folder\year/month/day folder`

File name: `\\xxxxxxx_YYYYMMDDHHMMSS.csv`

File name

Output time in year, month, day, hour, minute, and second


- * Specify a file name as desired in [Form Setting] in the [Logging Block] or [Alarm Block] window.

Example


- \$s01671 = 1 (W) [Logging server designation]
SMPLCSV_BAK 1

The above program creates a CSV file for logging block 1 (LOGGING01.bin) on April 20, 2014.

With [Number of Data to Save] under [Storage Output Settings] unchecked:




With [Number of Data to Save] under [Storage Output Settings] checked:



Supplemental remarks

- When [Number of Data to Save] under [Storage Output Settings] is checked in the [Output Destination] window, data stored in SRAM is output to the storage device and saved in a CSV file.
- [Format Setting] is required for each block number.



- If the block is empty, no CSV file will be created.
- The result of macro execution is stored in \$s1062. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

SMPLCSV_BAK2

SMPLCSV_BAK2

All models	<input type="radio"/>
------------	-----------------------

Function: Create CSV backup file (file name designation)

This macro command is used to convert the logging or alarm data in block No. [F0] to the CSV file under a name specified for [F1], and to save the file to the year/month/day folder in the storage.

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙			○
F1	⊙			

○ : Setting enabled (indirect designation disabled)

⊙ : Setting enabled (indirect designation enabled)

\$\$s1671

The output destination server (logging server, alarm server, V8 compatible operation) is changed according to the value in \$\$s1671.

\$\$s1671	Contents
0	V8 compatible operation (buffering area number designation)
1	Logging server designation
2	Alarm server designation

Setting range

	Value
F0	0 - 11: Block number
F1	ASCII code (64 one-byte uppercase alphanumerics at the maximum): CSV file name

File

- Logging server
Storage target: \\(access folder)\LOGGING\year\month\day\folder
File name: \xxxxxxx_YYYYMMDDHHMMSS.csv

File name	Output time in year, month, day, hour, minute, and second
- Logging server
Storage target: \\(access folder)\LOGGING\year\month\day\folder
File name: \xxxxxxx_YYYYMMDDHHMMSS.csv

File name	Output time in year, month, day, hour, minute, and second

4.19 Storage (Others)

HDCOPY

All models	<input type="radio"/>
------------	-----------------------

HDCOPY

Function: Hardcopy

This macro command is used to save the image of the screen displayed at the time of the macro execution to the storage.


Storage target

Storage target: \\(access folder)\HDCOPY
File name: \\HDxxx.PNG

0000 - 1023: Screen number

Supplemental remarks

- One file saves one screen. If a screen file you wish to save already exists in the storage, the file will be overwritten.
- Files can also be saved in JPEG format. Select the [System Setting] → [Other] → [Storage Setting] → [Store HDCOPY Macro in JPEG Format] checkbox.



- The result of macro execution is stored in \$s1062. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

HDCOPY2

All models	<input type="radio"/>
------------	-----------------------

HDCOPY2 F0

Function: Hardcopy

This macro command is used to save the image of the screen displayed at the time of macro execution with the backup number specified in [F0].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙			○

○ : Setting enabled (indirect designation disabled)
 ⊙ : Setting enabled (indirect designation enabled)

Setting range

	Value
F0	0 - 99: Backup number


Storage target

Storage target: (access folder)\HDCOPY
 File name: HDxxx~yy.PNG

| |
 00 - 99: Backup number
 000 - 999: Screen number
 (Screen Nos. 1000 - 1023 invalid)

Supplemental remarks

- With the use of backup numbers, a maximum of 100 hardcopy images can be saved per screen. You can, therefore, view time-series variations in these images.
- Files can also be saved in JPEG format.
 Select the [System Setting] → [Other] → [Storage Setting] → [Store HDCOPY Macro in JPEG Format] checkbox.



- The result of macro execution is stored in \$s1062
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended..

Code (DEC)	Contents
-1	Execution error

HDCOPY3

All models	<input type="radio"/>
------------	-----------------------

HDCOPY3**Function: Hardcopy (file name designation)**

This macro command is used to save the screen image (PNG) displayed at the time of the macro execution, under a file name specified in [F0], to the storage.

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	Ⓞ			

○ : Setting enabled (indirect designation disabled)

Ⓞ : Setting enabled (indirect designation enabled)

Setting range

	Value
F0	ASCII code (64 one-byte uppercase alphanumerics at the maximum): File name

File

Storage target: \(\text{access folder})\HDCOPY

File name: \xxxxxxx.PNG

└ File name

Example

- The file named "SCREEN10.PNG" is created.

\$u00100 = 'SCREEN10' (STRING)


HDCOPY3 \$u00100

└ File name designation

- * If [Insert/Overwrite together with STRING Command] is checked in the [Device Setting] or [Macro Editing Support] dialog, the macro command STRING can also be registered. For more information on STRING, refer to page 4-46.

Supplemental remarks

- One file saves one screen. If a screen file you wish to save already exists in the storage, the file will be overwritten.
- A full pathname can be specified for [F0].
- Files can also be saved in JPEG format.
Select the [System Setting] → [Other] → [Storage Setting] → [Store HDCOPY Macro in JPEG Format] checkbox.



- The result of macro execution is stored in \$s1062. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

Restrictions

- Symbols, [\], [/], [:], [*], [?], ["], [<], [>] and [()], cannot be used for a file name.

SET_DRIVE

All models	<input type="radio"/>
------------	-----------------------

SET_DRIVE F0**Function: Select drive**

This macro command is used to select a storage drive to be accessed by a macro command.

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	<input type="radio"/>			

: Setting enabled (indirect designation disabled)

: Setting enabled (indirect designation enabled)

Setting range

	Value
F0	Drive name designation* C: Built-in SD card drive D: Storage device connected to USB port

* The drive name must be followed by a colon.

For details on text processing of the drive name, refer to "Supplemental remarks" on page 4-193.

Example

- \$u0010 = 'D:'
SET_DRIVE \$u0010

The above program switches access to the D drive (storage device connected to the USB port).

Supplemental remarks

- If the drive name is not correctly specified, no operation takes place.
- The result of macro execution is stored in \$s1062.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

- A drive change due to this macro command occurs only when any recipe macro command is executed.
No drive change will be made for sampling data storage and macro commands other than that which is recipe-related.
- After the drive has been changed with this command, files under the folder specified for [Access Folder Name] in [System Setting] → [Storage Setting] are accessed. To change the folder to access using a recipe-related macro command, use "SET_RECIPFOLDER" (page 4-190).

COPY_FILE**COPY_FILE F0 F1**

All models	<input type="radio"/>
------------	-----------------------

Function: Copy file

This macro command is used to copy the file specified in [F0] to the file specified in [F1].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	<input type="radio"/>			
F1	<input type="radio"/>			

: Setting enabled (indirect designation disabled)

: Setting enabled (indirect designation enabled)

Setting range

	Value	Remarks
F0	Full pathname of the copy source*	Drive name designation C: Built-in SD card drive D: Memory device connected to USB port
F1	Full pathname of the copy destination*	


* For details on text processing of the file name, refer to "Supplemental remarks" on page 4-193.

Example

• Operation 1

The program below copies "C:\EXT0000\RECIPE\abc.csv" to "D:\EXT0000\RECIPE\abc.csv".


- \$u00100 = 'C:\EXT0000\RECIPE\abc.csv'
- \$u00200 = 'D:\EXT0000\RECIPE\'
- COPY_FILE \$u00100 \$u00200



• Operation 2

The program below copies all files stored in "C:\EXT0000\RECIPE" to "D:\EXT0000\RECIPE".

- \$u00100 = 'C:\EXT0000\RECIPE*.*)'
- \$u00200 = 'D:\EXT0000\RECIPE\'
- COPY_FILE \$u00100 \$u00200



Supplemental remarks

- When an asterisk "*" is specified for the copy source file name (F0) or extension name, all of the files or files with all extensions are copied. The contents of subfolders are also copied.
- If the file name of the copy destination (F1) is omitted, the data is copied to the file under the same name.
- If the full pathname is not correctly specified, no operation takes place.
- The result of macro execution is stored in \$s1062.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

MOVE_FILE**MOVE_FILE F0 F1 F2**

All models	<input type="radio"/>
------------	-----------------------

Function: Move file

This macro command is used to move the file or folder specified in [F0] to the path specified in [F1].

File renaming is also possible.

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	<input type="radio"/>			
F1	<input type="radio"/>			
F2	<input type="radio"/>			

: Setting enabled (indirect designation disabled)

: Setting enabled (indirect designation enabled)

4

Setting range

	Value	Remarks
F0	Source full pathname (within 255 alphanumeric)*	Drive name designation C: Built-in SD card drive D: Storage device connected to USB port
F1	Target full pathname (within 255 alphanumeric)*	
F2	0 fixed	

* For details on text processing of the file name, refer to "Supplemental remarks" on page 4-193.

Example

- The program below moves "C:\EXT0000\RECIPE\REC0000.csv" to "C:\EXT0000\RECIPE\SEISAN\abc.csv".

```
$u00100 = 'C:\EXT0000\RECIPE\REC0000.csv'
```

```
$u00200 = 'C:\EXT0000\RECIPE\SEISAN\abc.csv'
```


```
$u00300 = 0 (W)
```

```
MOVE_FILE $u00100 $u00200 $u00300
```

(Drive C:)



(Drive C:)



* The file "REC0000.csv" is deleted.

Supplemental remarks

- If the full pathname is not correctly specified, no operation takes place. An error will result.
- The result of macro execution is stored in \$s1062.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

- In the case of a read-only file movement between drives, the file is copied to the target location, and the file at the original location is not deleted.
- A folder to be moved is allowed to contain a maximum of 5 hierarchical levels under the folder. If files or folders at further lower levels exist under the folder, they can be copied to the target location, but those at the original location are not deleted.

Restrictions

- Use alphanumerics to specify full pathnames as the source and the target. If any characters other than alphanumerics are used, the function of this macro command is not assured.
- Wildcard characters (such as "*" and "?") cannot be used for full pathnames as the source and the target.
- If a file of the same name already exists in the target location, it will not be overwritten.
In this case, "-1" is set in \$s1062 (execution error). Change the file name and execute the macro again.

READ_FILE**READ_FILE F0 F1 F2 F3**

All models	<input type="radio"/>
------------	-----------------------

Function: Read universal file

This macro command is used to read the file [F0] in binary format and to store the obtained data in memory [F1] and after.

It is also possible to acquire the size of the file [F0].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	<input type="radio"/>			
F1	<input checked="" type="radio"/>			
F2	<input type="radio"/>			
F3	<input type="radio"/>			

: Setting enabled (indirect designation disabled)

: Setting enabled (indirect designation enabled)

Setting range

	Value		Remarks
	File read	File size acquisition	
F0	Source full pathname (within 255 alphanumeric)		Drive designation C: Built-in SD card drive D: Memory connected to USB port
F1	Storage memory	0 fixed	
F2	0 - 10485760 bytes: Size	0 fixed	DEC
F2+1			
F2+2	0 - 10485760 bytes: Offset from the top of the file	0 fixed	DEC
F2+3			
F2+4	0 fixed		
F3	Read data size storage memory (Data size successfully read)	File size storage memory	
F3+1			

 : ← V series (return data)

Example

- File read
The file "ABC.DAT" is read from its 11th byte by 512 bytes into \$u1000 - \$u1255.

\$u00100 = 'C:\EXT0000\ABC\ABC.DAT' [Source full pathname]

\$u00200 = 512 (D) [Size]

\$u00202 = 10 (D) [Offset]

\$u00204 = 0 (W) [0 fixed]

READ_FILE \$u00100 \$u01000 \$u00200 \$u00300

- File size acquisition
The size of the file "ABC.DAT" is read into \$u300.

```

$u00100 = 'C:\EXT0000\ABC\ABC.DAT'    [Source full pathname]
$u00200 = 0 (D)                        [0 fixed]
$u00202 = 0 (D)                        [0 fixed]
$u00204 = 0 (W)                        [0 fixed]
READ_FILE $u00100 $u01000 $u00200 $u00300
    
```

Supplemental remarks

- If any characters other than alphanumerics are used to specify a source full pathname, this macro command may not work normally. Be sure to use alphanumerics.
- Wildcard characters (such as "*" and "?") cannot be used for a full pathname as the source.
- If the file specified as the source does not exist, a macro execution error will occur and "-1" will be stored in the Read data size storage memory ([F3] and [F3+1]).
- If the full pathname is not correctly specified, no operation takes place and a macro execution error will occur.
- In the event of an error during file reading, the data having been read is stored in memory. However, the size of the data does not affect the successfully read data size in [F3] and [F3+1].
- The result of macro execution is stored in \$s1062.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

WRITE_FILE**WRITE_FILE F0 F1 F2**

All models	<input type="radio"/>
------------	-----------------------

Function: Write to universal file

This macro command is used to write the data from memory [F1] and after in binary format to the file [F0].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	<input type="radio"/>			
F1	<input checked="" type="radio"/>			
F2	<input type="radio"/>			

: Setting enabled (indirect designation disabled)

: Setting enabled (indirect designation enabled)

4

Setting range

	Value			Remarks
	New creation	Overwriting	Addition	
F0	Target full pathname			Drive designation C: Built-in SD card drive D: Memory connected to USB port
F1	Source memory			
F2	0 fixed	1 fixed	2 fixed	
F2+1	0 - 10485760 bytes: Size			DEC
F2+2				
F2+3	0 fixed	0 - 10485760 bytes: Offset from the top of the file	0 fixed	
F2+4				
F2+5	0 fixed			

Example

- New creation
The 512 bytes of data in \$u1000 - \$u1255 is written to the new file "ABC.DAT" created in the folder "ABC".

```

$u00100 = 'C:\EXT0000\ABC\ABC.DAT' [Target full pathname]
$u00200 = 0 (W) [0: New creation]
$u00201 = 512 (D) [Size]
$u00203 = 0 (D) [0 fixed]
$u00205 = 0 (W) [0 fixed]
WRITE_FILE $u00100 $u01000 $u00200

```

- **Overwriting**
The 33rd byte and after in the existing file "ABC.DAT" is overwritten with the 16 bytes of data in \$u1000 - \$u1007.

```

$u00100 = 'C:\EXT0000\ABC\ABC.DAT' [Target full pathname]
$u00200 = 1 (W) [1: Overwriting]
$u00201 = 16 (D) [Size]
$u00203 = 32 (D) [Offset]
$u00205 = 0 (W) [0 fixed]
WRITE_FILE $u00100 $u01000 $u00200
    
```

- **Addition**
The 512 bytes of data in \$u1000 - \$u1255 is added to the existing file "ABC.DAT".

```

$u00100 = 'C:\EXT0000\ABC\ABC.DAT' [Target full pathname]
$u00200 = 2 (W) [2: Addition]
$u00201 = 512 (D) [Size]
$u00203 = 0 (D) [0 fixed]
$u00205 = 0 (W) [0 fixed]
WRITE_FILE $u00100 $u01000 $u00200
    
```

Supplemental remarks

- If the name of a new file you intend to create is already used, delete the existing file first and create a new file.
- If the size specified with [F2+1] and [F2+2] is zero for a new file, an empty file will be created.
- If the file you specified for overwriting or data addition does not exist, an error will result.
- Wildcard characters (such as "*" and "?") cannot be used for a full pathname as the target, to which data is written.
- If an illegal full pathname is specified, this macro command does not work. An error will result.
- In the event of an error during writing to a file, the data having been written remains in the file.
- The result of macro execution is stored in \$s1062.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

F_SUB(-)

All models	<input type="radio"/>
------------	-----------------------

F0 = F1 - F2 (F)

Function: Real number subtraction

This macro command is used to write the result of [F1] real number data minus [F2] real number data to [F0].

DWORD

	F1+1	F1
—	F2+1	F2
	F0+1	F0

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙			
F1	⊙			○
F2	⊙			○

○ : Setting enabled (indirect designation disabled)
 ⊙ : Setting enabled (indirect designation enabled)

Setting range

	Value
F0	IEEE 32-bit single precision real number
F1	
F2	

Supplemental remarks

- For more information on the IEEE 32-bit single precision real numbers, refer to the V9 Series Reference Manual.
- The result of macro execution is stored in \$s1056.
 When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
1	Overflow
2	Underflow
-1	Execution error

F_MUL(X)

All models	<input type="radio"/>
------------	-----------------------

F0 × F2 (F)**Function: Real number multiplication**

This macro command is used to write the result of [F1] real number data multiplied by [F2] real number data to [F0].

DWORD

×	F1+1	F1
	F2+1	F2
	F0+1	F0

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙			
F1	⊙			○
F2	⊙			○

○ : Setting enabled (indirect designation disabled)

⊙ : Setting enabled (indirect designation enabled)

Setting range

	Value
F0	IEEE 32-bit single precision real number
F1	
F2	

Supplemental remarks

- For more information on the IEEE 32-bit single precision real numbers, refer to the V9 Series Reference Manual.
- The result of macro execution is stored in \$s1056.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
1	Overflow
2	Underflow
-1	Execution error

F_DIV(I)

All models	<input type="radio"/>
------------	-----------------------

F0 = F1 / F2 (F)

Function: Real number division

This macro command is used to write the result of [F1] real number data divided by [F2] real number data to [F0].

DWORD

	F1+1	F1	
÷	F2+1	F2	
	F0+1	F0	... Remainder

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙			
F1	⊙			○
F2	⊙			○

○ : Setting enabled (indirect designation disabled)

⊙ : Setting enabled (indirect designation enabled)

Setting range

	Value
F0	IEEE 32-bit single precision real number
F1	
F2	

Supplemental remarks

- For more information on the IEEE 32-bit single precision real numbers, refer to the V9 Series Reference Manual.
- The result of macro execution is stored in \$s1056.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
1	Overflow
2	Underflow
3	Calculation operation execution error
-1	Execution error

4.21 Real No. Statistics


F_SUM

F0 = F_SUM (F1 C:F2) (F)

All models	<input type="radio"/>
------------	-----------------------

Function: Sum of real number data

This macro command is used to sum the real number data at the location starting from the address specified in [F1] and write the result to [F0]. The data count is specified in [F2].



Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙			
F1	⊙			
F2	○			○

○ : Setting enabled (indirect designation disabled)

⊙ : Setting enabled (indirect designation enabled)

Setting range

	Value
F0	IEEE 32-bit single precision real number
F1	
F2	0 - 512

Supplemental remarks

- For more information on the IEEE 32-bit single precision real numbers, refer to the V9 Series Reference Manual.
- The result of macro execution is stored in \$s1056. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
1	Overflow
2	Underflow
-1	Execution error


F_AVG

All models	<input type="radio"/>
------------	-----------------------

F0 = F_AVG (F1 C:F2) (F)

Function: Average of real number data

This macro command is used to average the real number data at the location starting from the address specified in [F1] and write the result to [F0]. The data count is specified in [F2].



Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙			
F1	⊙			
F2	○			○

○ : Setting enabled (indirect designation disabled)
 ⊙ : Setting enabled (indirect designation enabled)

Setting range

	Value
F0	IEEE 32-bit single precision real number
F1	
F2	0 - 512

Supplemental remarks

- For more information on the IEEE 32-bit single precision real numbers, refer to the V9 Series Reference Manual.
- The result of macro execution is stored in \$s1056. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.


Code (DEC)	Contents
1	Overflow
2	Underflow
-1	Execution error

F_MAX**F0 = F_MAX (F1 C:F2) (F)**

All models	<input type="radio"/>
------------	-----------------------

Function: Maximum of real number data

This macro command is used to find the maximum of the real number data at the location starting from the address specified in [F1] and write the result to [F0]. The data count is specified in [F2].

**Available device memory**

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙			
F1	⊙			
F2	○			○

○ : Setting enabled (indirect designation disabled)

⊙ : Setting enabled (indirect designation enabled)

Setting range

	Value
F0	IEEE 32-bit single precision real number
F1	
F2	0 - 512

Supplemental remarks

- For more information on the IEEE 32-bit single precision real numbers, refer to the V9 Series Reference Manual.
- The result of macro execution is stored in \$s1056.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
1	Overflow
2	Underflow
-1	Execution error


F_MIN

F0 = F_MIN (F1 C:F2) (F)

All models	<input type="radio"/>
------------	-----------------------

Function: Minimum of real number data

This macro command is used to find the minimum of the real number data at the location starting from the address specified in [F1] and write the result to [F0]. The data count is specified in [F2].



Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙			
F1	⊙			
F2	○			○

○ : Setting enabled (indirect designation disabled)

⊙ : Setting enabled (indirect designation enabled)

Setting range

	Value
F0	IEEE 32-bit single precision real number
F1	
F2	0 - 512

Supplemental remarks

- For more information on the IEEE 32-bit single precision real numbers, refer to the V9 Series Reference Manual.
- The result of macro execution is stored in \$s1056.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
1	Overflow
2	Underflow
-1	Execution error

4.22 Others


;(Comment)

All models	<input type="radio"/>
------------	-----------------------

;(Comment)

Function: Comment

- This is treated as a comment line. No command processing is required.
- Comment can be inserted after a command so that both the command and the comment are on the same line.



- For debugging, you can comment out the lines which you want to temporarily disable by putting "; " at the start of each line.

BRIGHT

All models	<input type="radio"/>
TELLUS4 HMI	

BRIGHT F0**Function: Brightness adjustment**

This command is used to change the brightness of the TFT display to the level specified in [F0].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	<input type="radio"/>			<input type="radio"/>

: Setting enabled (indirect designation disabled)

: Setting enabled (indirect designation enabled)

Setting range

	Value
F0	0: Bright : : 127: Dark

Supplemental remarks

- Do not turn off the power supply of the V series while executing the macro command.
- The current brightness is output to \$s956.
- When the macro command is executed, communication will pause for several hundred milliseconds to allow for saving the setting value to the FROM. Avoid the frequent use of the macro command.
- If MONITOUCH set to a low brightness is turned off, the backlight may not light up at the next power-on.
- The result of macro execution is stored in \$s1063.

When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

GET_MSGBLK

GET_MSGBLK F0 F1

All models	<input type="radio"/>
------------	-----------------------

Function: Message acquisition

This macro command is used to store the [F1]-specified message (text) in [F0] memory using ASCII/shifted JIS codes.

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	<input type="radio"/>			
F1	<input type="radio"/>			<input type="radio"/>


○ : Setting enabled (indirect designation disabled)
 ◎ : Setting enabled (indirect designation enabled)

Setting range

	Value
F0	Storage memory
F1	0 - 32767: Message No.

Example

- \$u00050 = 256 (W)
 GET_MSGBLK \$u00100 \$u00050



GET_MSGBLK

\$u100	7	4	7	3	HEX	ts
\$u101	6	9	7	2	HEX	ir
\$u102	6	7	6	E	HEX	gn
\$u103	0	0	0	0	HEX	Null code

The above program stores message No. 256 (= GNo. 1 and line No. 0) in memory at \$u100 and after using shifted JIS codes.

Supplemental remarks

- Regardless of the [Text Process] setting under [Communication Setting] for PLC1, the data is stored in memory in the [LSB → MSB] sequence.
- A null code is added to the end. Even-number-byte text thereby uses one extra word.
- The result of macro execution is stored in \$s1063.
 When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

PLC_ULR

PLC_ULR F0 F1

All models	<input type="radio"/>
------------	-----------------------

Function: Read user log

This macro command is used to read the user log of the PLC with the station number / CPU number specified in [F0] of the PLC1 into the address specified in [F1].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	<input type="radio"/>			
F1	<input type="radio"/>			

○ : Setting enabled (indirect designation disabled)
 ◎ : Setting enabled (indirect designation enabled)

Setting range

		Value		Remarks
Device memory information definition	F0	Higher-order	01 - 1F: Station number	Setting required only for 1:n connection
		Lower-order	00 : CPU No.1 01 : CPU No.2 02 : CPU No.3 03 : CPU No.4	
	F0+1	-1: Reading the number of user log registrations 0: Reading the most recent user log 1 - 63: Reading user log No. n		
Reading the number of registrations	F1	Number of registrations (decimal)		Stored also in the special register Z105
	F1+1			
Log read	F1	0: Normal -1: Error	"-1" to be stored if no data exists in the user log specified in F0 or a communication error occurs	
	F1+1	Year (ASCII)		
	F1+2	Month (ASCII)		
	F1+3	Day (ASCII)		
	F1+4	Hour (ASCII)		
	F1+5	Minute (ASCII)		
	F1+6	Second (ASCII)		
	F1+7	Main code (decimal)		
	F1+8	Sub-code (decimal)		

:- V series (Return data)

Example

If a user log reading results in "05/10/19 11 : 20 : 34 +1 +23", its format for storage is as the following:

	Storage format
m+0	0
m+1	3530HEX (= 05DEC)
m+2	3031HEX (= 10DEC)
m+3	3931HEX (= 19DEC)
m+4	3131HEX (= 11DEC)
m+5	3032HEX (= 20DEC)
m+6	3433HEX (= 34DEC)
m+7	1DEC
m+8	23DEC

Supplemental remarks

- The macro command is valid only when Yokogawa's FA-M3xxx is selected as the PLC1.
- The result of macro execution is stored in \$s1063.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

RECONNECT

All models	<input type="radio"/>
------------	-----------------------

RECONNECT F0**Function: Multi-drop reconnection (PLC1)**

This macro command is used to establish a connection again to the stations specified in [F0] or the sub stations specified in [F0+1] when a multi-drop connection is set at the PLC1.

When “-1” is specified for [F0], reconnection with all ports is established, and when “-1” is specified for [F0+1], reconnection with all sub ports is established.

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	<input type="radio"/>			<input type="radio"/>

: Setting enabled (indirect designation disabled)

: Setting enabled (indirect designation enabled)

Setting range

	Value	Remarks
F0	0 - 255: PLC station number	-1: All station numbers designation
F0+1	0 - 255: PLC sub-station number	-1: All sub-station numbers designation

Supplemental remarks

- This command is only valid when a multi-drop connection (1:n) is set at PLC1. To re-establish a connection other than with PLC1, use a “RECONNECT_EX” command (page 4-251).
- The macro command is used in the event of a communication fault.
- Reconnection with the specified station is performed only once.
- When reconnection is successful, the “interrupted” information in system device memory (§s114 to 159) and 8-way communication device memory (§p[1] : 10 to 25) in the PLC1 are cleared.
- The result of macro execution is stored in \$s1063. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

RECONNECT_EX RECONNECT_EX PLC F0 F1

All models	<input type="radio"/>
------------	-----------------------

Function: Reconnection

This macro command is used to establish a connection again with the station number [F1] or the sub-station number [F1+1] specified in [F0] of the PLC. When “-1” is specified for [F1], reconnection with all stations is established, and when “-1” is specified for [F1+1], reconnection with all sub stations is established.

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	<input type="radio"/>			<input type="radio"/>
F1	<input type="radio"/>			<input type="radio"/>

: Setting enabled (indirect designation disabled)

: Setting enabled (indirect designation enabled)

4

Setting range

	Value	Remarks
F0	1 - 8: PLC number	
F1	0 - 255: PLC station number	-1: All station numbers designation
F1+1	0 - 255: PLC sub-station number	-1: All sub-station number designation

Supplemental remarks

- The macro command is used in the event of a communication fault.
- Reconnection with the specified station and the specified sub-station is performed only once.
- When reconnection is successful, the “interrupted” information in 8-way communication device memory (\$p[F0] : 10 to 25) in the PLC is cleared. For the PLC1, the “interrupted” information in system device memory (\$s114 to 129) is also cleared at the same time.
- The result of macro execution is stored in \$s1063. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

SAMPLE

All models	<input type="radio"/>
------------	-----------------------

SAMPLE F0 F1 F2**Function: Acquire logging/alarm data**

This macro command is used to store sampling data specified in [F2] of the block number specified in [F1] at the device memory address specified in [F0].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	<input checked="" type="radio"/>			
F1	<input type="radio"/>			
F2	<input type="radio"/>			

: Setting enabled (indirect designation disabled)

: Setting enabled (indirect designation enabled)

\$\$s1673

The macro command operation is specified by the value in \$\$s1673.

\$\$s1673	Contents
0	Applicable area: V8 compatible blocks (buffering area)
Other than 0	Applicable area: All blocks

Setting range

	Value		
F0	Storage target		
F1	0: Cursor specification 1: Block specification		
	(F1 = 0)		(F1 = 1)
F1+1	0: Base 1 - 10: Overlap ID 0 - 9	0 - 11: Block number	
F1+2	0 - 255: ID No. of the item displayed	Not used	
F2	0: Acquisition of sampling data * Only when a logging part or logging block is specified in [F1]. 1: Acquisition of average/maximum/minimum/total data * Only when a logging part or logging block is specified in [F1]. 2: Acquisition of alarm data * Only when an alarm part or alarm block is specified in [F1].		
	((F2) = 0)		((F2) = 1)
F2+1	0: With no time data 1: With time data	0 - : Word No.	Not used

- Acquiring sampling data (with no time data)
 - When [F1] = 0
When the specified logging viewer is selected (the cursor is displayed), the data at the cursor position is stored.
When the specified logging viewer is not selected (the cursor is not displayed), the most recent sampling data is stored.
 - When [F1] = 1
The most recent sampling data is stored.
 - Specify the sampling data to be acquired in [F1+1] and [F1+2].
 - Set "0" for [F2] and [F2+1].

- The following data is stored in the [F0] memory.

Device memory	Contents	Word count
F0	Sampling data (1)	1
F0+1	Sampling data (2)	1
F0+2	Sampling data (3)	1
:	:	:
F0 + (sampling word count - 1)	Sampling data (sampling word count)	1

* When [Real Time Display] is selected for [Display Mode] in the logging viewer, no operation takes place.

2. Acquiring sampling data (with time data)

- When [F1] = 0
When the specified logging viewer is selected (the cursor is displayed), the data at the cursor position is stored.
When the specified logging viewer is not selected (the cursor is not displayed), the most recent sampling data is stored.
- When [F1] = 1
The most recent sampling data is stored.
- Specify the sampling data to be acquired in [F1+1] and [F1+2].
- Set "0" for [F2] and "1" for [F2+1].
- The following data is stored in the [F0] device memory.

Device memory	Contents	Word count
F0	Sampling time (Greenwich data)	2
F0+2	Sampling time in msec (0 - 999)	1
F0+3	Sampling data (1)	1
F0+4	Sampling data (2)	1
:	:	:
F0 + (3 + sampling word count - 1)	Sampling data (sampling word count)	1

* When [Real Time Display] is selected for [Display Mode] in the logging viewer, no operation takes place.

3. Acquiring average / maximum / minimum / total data

- Specify the sampling data to be acquired in [F1+1] and [F1+2].
- Set "1" for [F2].
- Set the number of words for [F2+1].
- The following data is stored in the [F0] device memory.

Device memory	Contents	Word count
F0	Average	2
F0+2	Maximum	2
F0+4	Minimum	2
F0+6	Total	2
F0+8	Result of overflow 0: No overflow 1: Overflow occurred	1

* When [Real Time Display] is selected for [Display Mode] in the logging viewer, no operation takes place.

4. Acquiring alarm information

- Specify the sampling data to be acquired in [F1+1] and [F1+2].
- Set "2" for [F2].
- The following data is stored in the [F0] device memory.

Device memory	Contents	Word count
F0	Automatic operation time	2
F0+2	Automatic operation stop time	2
F0+4	Program stop time	2
F0+6	Number of stops	1
F0+7	Rate of operation	1

* This command can be used only for the alarm server.
 If [Alarm History] ([Alarm Block] → [Alarm Device]) is not checked, no operation takes place.

Supplemental remarks

- The result of macro execution is stored in \$s1063.
 When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

SEARCH_FILE

SEARCH_FILE F0 F1

All models	<input type="radio"/>
------------	-----------------------

Function: JPEG file search

This macro command is used to search for JPEG file numbers in the SNAP/JPEG folder stored in the storage based on the specified increments and store the result in the device memory [F0].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	⊙			
F1	⊙			


○ : Setting enabled (indirect designation disabled)
 ⊙ : Setting enabled (indirect designation enabled)

Setting range

	Value
F0	Search result (file number) storage target
F1	0: Searches the JPEG folder for JPxxxxx.jpg file 1: Searches the SNAP folder for VDxxxxx.jpg file
F1+1	0 - 32767: Search start file number
F1+2	-32767 - 32767: Increments

Example

- \$u200 = 0 (W) [JPEG folder search]
- \$u201 = 0 (W) [Search start file No. 0]
- \$u202 = 10 (W) [Increments 10]
- SEARCH_FILE \$u100 \$u200
- \$u201 = \$u100 (W)



Supplemental remarks

- The macro command is valid even if no JPEG display item exists on the screen.
- The result of macro execution is stored in \$s1063. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

ADJ_VOLUME

V9 Advanced	
V910xiW	<input type="radio"/>
V907xiW	
V9 Standard	
All models	<input type="radio"/>
V9 Lite	
All models	
TELLUS	
TELLUS4 HMI	

ADJ_VOLUME F0 F1 F2**Function: Volume adjustment**

This macro command is used to change the volume of the channel specified in [F0] to the value specified in [F1]/[F2].

	Volume adjustment value	Volume
High   Low	7	0dB
	6	-3dB
	5	-6dB
	4	-9dB
	3	-12dB
	2	-15dB
	1	-18dB
	0	-21dB

*The default is "5" (-6 dB).

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0	<input type="radio"/>			<input type="radio"/>
F1	<input type="radio"/>			<input type="radio"/>
F2	<input type="radio"/>			<input type="radio"/>

: Setting enabled (indirect designation disabled)

: Setting enabled (indirect designation enabled)

Setting range

	Value
F0	0: L channel 1: R channel 2: Both channels L and R
F1	0 - 7: Volume adjustment for L channel
F2	0 - 7: Volume adjustment for R channel

Supplemental remarks

- This command is valid only for V910xiW and V9 Standard.
- To save the ADJ_VOLUME setting to the V series, use SAVE_VOLUME. When the V series is turned off without executing the SAVE_VOLUME command following the ADJ_VOLUME command, the viewing angle is reset to the one that was valid before the execution of the ADJ_VOLUME command.
- The current volume adjustment value (0 - 7) for the L channel is stored in \$s1001. The current volume adjustment value (0 - 7) for the R channel is stored in \$s1002.
- The result of macro execution is stored in \$s1063. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

SAVE_VOLUME

V9 Advanced	
V910xiW	<input type="radio"/>
V907xiW	
V9 Standard	
All models	<input type="radio"/>
V9 Lite	
All models	
TELLUS	
TELLUS4 HMI	

SAVE_VOLUME**Function: Save volume adjustment value**

This macro command is used to save the volume adjustment value set by the "ADJ_VOLUME" command in FROM.

Example

- ADJ_VOLUME 2 6 6
SAVE_VOLUME

The above program sets the volume for both L and R channels to 6.

Supplemental remarks

- This command is valid only for V910xiW and V9 Standard.
- Do not turn off the power supply of the V series while executing the macro command.
- When the SAVE_VOLUME command is executed, the communication (serial, Ethernet) is temporarily interrupted. Do not execute the SAVE_VOLUME command frequently.
- The result of macro execution is stored in \$s1063. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

TREND REFRESH TREND REFRESH F0 F1

All models	<input type="radio"/>
------------	-----------------------

Function: Refresh trend data display

The macro command is used to refresh the logging viewer display specified in [F0] and [F1].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F0				<input type="radio"/>
F1				<input type="radio"/>

: Setting enabled (indirect designation disabled)

: Setting enabled (indirect designation enabled)

Setting range

	Value
F0	0: Base 1 - 10: Overlap ID 0 - 9
F1	0 - 255: ID

Supplemental remarks

- This command is valid only when [Display mode: Historical Display] and [Display method: Graph Display] are set for the logging viewer.
- If device memory addresses are specified in logging viewer settings for [Graph Min. Value] and [Graph Max. Value], and [Max. Scale Value] and [Min. Scale Value], the display must be refreshed each time data at any of these devices is changed.
- The result of macro execution is stored in \$s1063.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

SYS

SYS (SET_SCRN) F1

All models	<input type="radio"/>
------------	-----------------------

Function: Screen number designation

This macro command is used to display the screen specified in [F1].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F1	⊙			

○ : Setting enabled (indirect designation disabled)

⊙ : Setting enabled (indirect designation enabled)

Setting range

	Value
F0	SET_SCRN
F1	0 - 9999: Screen number

Example

- \$u100 = 55 (W) [Screen number]
SYS (SET_SCRN) \$u100

The above program displays screen No. 55.

Supplemental remarks

- If a screen number that does not exist is specified in [F1], the macro command is disabled.
- The macro command is invalid in screen OPEN, screen CLOSE, overlap library OPEN, overlap library CLOSE, and initial macros.
- The macro command is valid only once in a macro created on the macro edit sheet. Its execution timing is set at the end of the macro on the edit sheet.
- Do not execute the macro command in every cycle using a CYCLE macro or an event timer macro.
- Transition effect for the screen change-over is not available.
- The result of macro execution is stored in \$s72.

When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

SYS**SYS (SET_MOVL P) F1**

All models	<input type="radio"/>
------------	-----------------------

Function: Multi-overlap/global overlap setting

This macro command is used to display the overlap library specified in F1+1 on the overlap ID in [F1].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F1	<input checked="" type="radio"/>			

: Setting enabled (indirect designation disabled)

: Setting enabled (indirect designation enabled)

Setting range

	Value	
	Dot (unit: 4 × 1)	Line/column (unit 8 × 20)
F0	SET_MOVL P	
F1	0 - 9: Overlap ID	
F1+1	0 - 1023: Overlap library number	
F1+2	0 - 1023: X coordinate	0 - 127: X coordinate
F1+3	0 - 767: Y coordinate	0 - 38: Y coordinate

Example

- \$u100 = 2 (W) [Overlap ID]
- \$u101 = 12 (W) [Overlap library number]
- \$u102 = 50 (W) [X coordinate]
- \$u103 = 5 (W) [Y coordinate]
- SYS (SET_MOVL P) \$u100

Line/Column:

The above program displays overlap ID2 and overlap library No. 12 at the coordinates X: 400 and Y: 100.

Dot:

The above program displays overlap ID2 and overlap library No. 12 at the coordinates X: 48* and Y: 5.

* Since four dots are treated as one unit on the X axis, any value in the range of "48" to "51" on the axis is regarded as "48".

Supplemental remarks

- The macro command is valid when [Internal] is checked under [Designate] in the [Multi-Overlap] or [Global Overlap Setting] dialog.
- If [F1]>9, the macro command is disabled.
- If an overlap library number specified in [F1+1] does not exist, the macro command is disabled.
- If the specified X and Y coordinates are outside the permissible ranges, the display appears in the lower right corner of the screen.
- The macro command is invalid in a screen CLOSE macro and an initial macro.
- The macro command is valid only once in a macro created on the macro edit sheet for each overlap ID. Its execution timing is set at the end of the macro on the edit sheet.
- Use the OVL P_SHOW command to turn off the multi-overlap or global overlap.
- Do not execute the macro command in every cycle using a CYCLE macro or an event timer macro.

- Transition effect for overlap show/hide is not available.
- The result of macro execution is stored in \$s72.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

SYS

SYS (OVLP_SHOW) F1

All models	<input type="radio"/>
------------	-----------------------

Function: Overlap ON/OFF

This macro command is used to show/hide the overlap ID specified in [F1].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F1	⊙			

- : Setting enabled (indirect designation disabled)
- ⊙ : Setting enabled (indirect designation enabled)

Setting range

	Value
F0	OVLP_SHOW
F1	0 - 9: Overlap ID
F1+1	0: OFF (non-display) 1: ON (display)

Example

- \$u100 = 2 (W) [Overlap ID]
\$u101 = 0 (W) [OFF]
SYS (OVLP_SHOW) \$u100

The above program turns off overlap ID2.

- \$u100 = 2 (W) [Overlap ID]
\$u101 = 1 (W) [ON]
SYS (OVLP_SHOW) \$u100

The above program turns on overlap ID2.

Supplemental remarks

- If [F1]>9, the macro command is disabled.
- If F1+1 = 0, the macro command is valid for normal, call-, multi-, and global ([Designate]: [Internal]) overlaps.
- The macro command is invalid in screen CLOSE, overlap library CLOSE and initial macros.
- The macro command is valid only once in a macro created on the macro edit sheet for each overlap ID. Its execution timing is set at the end of the macro on the edit sheet.
- Do not execute the macro command in every cycle using a CYCLE macro or an event timer macro.
- Transition effect for overlap show/hide is not available.
- The result of macro execution is stored in \$s72.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

SYS

SYS (OVLPOS) F1

All models	<input type="radio"/>
------------	-----------------------

Function: Overlap relocation

This macro command is used to move the overlap ID specified in [F1] to the coordinates X in [F1+1] and Y in [F1+2].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F1	⊙			

○ : Setting enabled (indirect designation disabled)

⊙ : Setting enabled (indirect designation enabled)

Setting range

	Value	
	Dot (unit: 4 × 1)	Line/column (unit 8 × 20)
F0	OVLPOS	
F1	0 - 9: Overlap ID	
F1+1	0 - 1023: X coordinate	0 - 127: X coordinate
F1+2	0 - 767: Y coordinate	0 - 38: Y coordinate

Example

- \$u100 = 2 (W) [Overlap ID]
- \$u101 = 50 (W) [X coordinate]
- \$u102 = 5 (W) [Y coordinate]
- SYS (OVLPOS) \$u100

Line/Column:

The above program moves overlap ID2 to coordinates X: 400 and Y: 100.

Dot:

The above program moves overlap ID2 to coordinates X: 48* and Y: 5.

* Since four dots are treated as one unit on the X axis, any value in the range of "48" to "51" on the axis is regarded as "48".

Supplemental remarks

- If [F1]>9, the macro command is disabled.
- In the event of a normal or a call-overlap, the macro command is enabled also to display the overlap.
- The X and Y coordinates specified by the macro command take effect until the screen is switched. If OVLPOS_SHOW is executed after OVLPOS, the overlap appears at the coordinates specified by OVLPOS.
- The macro command is invalid in screen OPEN, screen CLOSE, overlap library CLOSE and initial macros.
- The macro command is valid only once in a macro created on the macro edit sheet for each overlap ID. Its execution timing is set at the end of the macro on the edit sheet.
- Do not execute the macro command in every cycle using a CYCLE macro or an event timer macro.
- The result of macro execution is stored in \$s72.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

SYS

SYS (GET_MSG) F1

All models	<input type="radio"/>
------------	-----------------------

Function: Message acquisition

This macro command is used to store the F1-specified message in memory at the \$u address in F1+1 using ASCII/shifted JIS codes.

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F1	⊙			

○ : Setting enabled (indirect designation disabled)
 ⊙ : Setting enabled (indirect designation enabled)


Setting range

	Value
F0	GET_MSG
F1	0 - 32767: Message number
F1+1	0 - 16383: Storage device number
\$u[F1+1]	Shifted JIS/ASCII 50 words maximum

: ← V series (Return data)

Example

- \$u50 = 256 (W) [Message number]
 \$u51 = 100 (W) [Storage target device memory No.]
 SYS (GET_MSG) \$u50



SYS (GET_MSG)

\$u100	8	A	9	4	HEX	ts
\$u101	8	E	A	E	HEX	ir
\$u102	8	9	E	F	HEX	gn
\$u103	8	E	D	0	HEX	Null code

The above program stores message No. 256 (= GNo. 1 and line No. 0) in memory at \$u100 and after using shifted JIS codes.

The above program shows the case when [MSB → LSB] is selected for [Text Process] under [Communication Setting] for the PLC1.

Supplemental remarks

- Swap between the higher-order byte and the lower-order byte can be set by selecting an option for [Text Process] under [Communication Setting].
- Regardless of the setting above, use a "GET_MSGBLK" command (page 4-247) for storing data by [LSB → MSB].
- A null code is added to the end. Even-number-byte text thereby uses one extra word.
- The result of macro execution is stored in \$s72.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error


SYS

SYS (GET_XY) F1

All models	<input type="radio"/>
------------	-----------------------

Function: Acquisition of X and Y coordinates on circumference

This macro command is used to calculate X and Y coordinates from a radius, an angle and, center coordinates.



Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F1	⊙			

○ : Setting enabled (indirect designation disabled)
 ⊙ : Setting enabled (indirect designation enabled)

Setting range


	Value
F0	GET_XY
F1	0 or above: Radius
F1+1	0 to 3600: Angle (0.1-degrees)
F1+2	0 or above: Center coordinate X
F1+3	0 or above: Center coordinate Y
F1+4	0 or above: X coordinate
F1+5	0 or above: Y coordinate

:← V series (Return data)

Example

- \$u100 = 100 (W) [Radius]
- \$u101 = 900 (W) [Angle]
- \$u102 = 200 (W) [X coordinate of the center]
- \$u103 = 200 (W) [Y coordinate of the center]
- SYS (GET_XY) \$u100

On the circumference of a circle 100 dots in radius with the center at coordinates X: 200 and Y: 200, the above program calculates the X and Y coordinates of the point at an angle of 90 degrees.
 X coordinate: \$u104 = 200
 Y coordinate: \$u105 = 100



Supplemental remarks

- If a value specified for the angle is 3,600 or above, the value is corrected to the remainder as the result of division by 3,600.

- The result of macro execution is stored in \$s72. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

SYS

All models	○
TELLUS4 HMI	△

SYS (SET_BZ) F1**Function: Buzzer control**

This macro command is used to control the buzzer of MONITOUCH.

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F1	◎			

○ : Setting enabled (indirect designation disabled)

◎ : Setting enabled (indirect designation enabled)

Setting range

	Value	Remarks
F0	SET_BZ	
F1	0: Normal 1: Error 2: Sound change	
F1+1	0: Standard 1: Short 2: None 3: Continuous*	Setting required if F1 = 2

* Incompatible with TELLUS version 4

Example

- \$u100 = 2 (W) [Sound change]
 - \$u101 = 2 (W) [None]
- SYS (SET_BZ) \$u100

The above program turns off the MONITOUCH buzzer.

Supplemental remarks

- The [Buzzer] tab window setting in the [Unit Setting] dialog ([System Setting] → [Unit Setting] → [Buzzer]) takes effect only at the time of initial connection of MONITOUCH.
- The result of macro execution is stored in \$s72.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

SYS

SYS (GET_TIME) F1

All models	<input type="radio"/>
------------	-----------------------

Function: System time acquisition

This macro command is used to acquire values from the timer that increments by one at 10-ms intervals after power-on.

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F1	⊙			

○ : Setting enabled (indirect designation disabled)

⊙ : Setting enabled (indirect designation enabled)

Setting range

	Value
F0	GET_TIME
F1	0 - 4294967295 (×10 msec)
F1+1	

← V series (Return data)

Example

- SYS(GET_TIME) \$u100
The above program acquires the time that has elapsed after power-on.

\$u100 = 27900 (W)

279000 msec = 279 sec = 4 minutes 39 seconds

Supplemental remarks

- The result of macro execution is stored in \$s72.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

SYS

All models	○
------------	---

SYS (STA_TIME) F1
SYS (CHK_TIME) F1

Function: Timer setting

STA_TIME starts the timer. CHK_TIME confirms a time-out.

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F1	⊙			

○ : Setting enabled (indirect designation disabled)
 ⊙ : Setting enabled (indirect designation enabled)

Setting range

- STA_TIME

	Value	Remarks
F0	STA_TIME	
F1	Time-out flag 0: Counting 1: Time-out	
F1+1	0: Timer type 0	F1 = 1: Stops the timer
	1: Timer type 1	F1 = 1: Updates the timer start time
F1+2	0 - 65535: Time-out time	×10 ms
F1+3	Timer start time	

:← V series (Return data)

- CHK_TIME
 For [F1], use the same device memory as for STA_TIME.

Example

<Timer type 0>


- OPEN macro
 \$u101 = 0 (W) [Timer type]
 \$u102 = 50 (W) [Time-up time]
 SYS (STA_TIME) \$u100

The above program starts the timer type 0, for which a 500-ms time-out period is set.

\$u103 =current time and \$u100=0 are set.

- CYCLE macro
 SYS (CHK_TIME) \$u100

\$u100 = 0
 ↓ Lapse of 500 ms
 \$u100 = 1 (W)
 (End)




<Timer type 1>

- OPEN macro
 $\$u101 = 1$ (W) Timer type
 $\$U102 = 50$ (W) Time-up time
 SYS (STA_TIME) $\$u100$

The above program starts the timer type 1, for which a 500-ms time-out period is set.

$\$u103$ =current time and $\$u100=0$ are set.

- CYCLE macro
 SYS (CHK_TIME) $\$u100$
 IF ($\$u100! = 0$) LB 0 (W)
 RET
 LB0:
 $\$u200 = \$u200+1$ (W)
 RET



$\$u100 = 0$
 ↓ Lapse of 500 ms
 $\$u100 = 1$ and $\$u200 = 1$ are set.
 ↓
 $\$u103$ =current time and $\$u100=0$ are set.
 ↓ Lapse of 500 ms
 $\$u100 = 1$ and $\$u200 = 2$ are set.
 ↓
 (Repetition)

Supplemental remarks

- The timer base is set to 10 ms.
- The result of macro execution is stored in $\$s72$.
 When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

SYS

SYS (GET_CLND) F1

All models	<input type="radio"/>
------------	-----------------------

Function: Calendar acquisition

This macro command is used to acquire the values of the system calendar.

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F1	⊙			

- : Setting enabled (indirect designation disabled)
- ⊙ : Setting enabled (indirect designation enabled)

Setting range

	Value
F0	GET_CLND
F1	0 or above: Year (4-digit)
F1+1	1 - 12: Month
F1+2	1 - 31: Day
F1+3	0 - 23: Hour
F1+4	0 - 59: Minute
F1+5	0 - 59: Second
F1+6	0: Sunday 1: Monday 2: Tuesday 3: Wednesday 4: Thursday 5: Friday 6: Saturday

 :← V series (Return data)

Example

- SYS (GET_CLND) \$u100

```

$u100 = 2005
$u101 = 7
$u102 = 15
$u103 = 15
$u104 = 25
$u105 = 41
$u106 = 5
    
```

] [July 15, 2005 Friday 15:25:41]

Supplemental remarks

- The calendar is acquired not from a PLC or other external device but from the V series unit.
- The result of macro execution is stored in \$s72. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

SYS

SYS (SET_CLND) F1

All models	○
TELLUS4 HMI	

Function: Calendar setting

This macro command is used to set the values of eight words starting from the address specified in [F1] to the system calendar. When MONTOUCH is connected with PLC1 including the calendar function, this macro command also sets the PLC1's calendar.

- * For TELLUS4, it reads out PC's calendar to write to a PLC1.
Other calendar options are not available.

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F1	⊙			

- : Setting enabled (indirect designation disabled)
- ⊙ : Setting enabled (indirect designation enabled)

4

Setting range

	Value	
F0	SET_CLND	
F1	0 or above: Year (4-digit/2-digit)	
F1+1	1 - 12: Month	
F1+2	1 - 31: Day	
F1+3	0 - 23: Hour	
F1+4	0 - 59: Minute	
F1+5	0 - 59: Second	
F1+6	Day of the week	Invalid; to be automatically calculated by MONTOUCH
F1+7	0 - 31: PLC station number	For 1:n connection only

Example

- \$u100 = 2005 (W)
 - \$u101 = 7 (W)
 - \$u102 = 15 (W)
 - \$u103 = 15 (W)
 - \$u104 = 0 (W)
 - \$u105 = 0 (W)
- } [July 15, 2005 Friday 15:00:00]
- SYS (SET_CLND) \$u100

The above program sets the calendars in the V series and the PLC1 to July 15, 2005 on Friday at 15:00:00.

Supplemental remarks

- When setting calendar data for PLC 2 to 8, use a macro command " PLC_CLND" (page 4-149).
- When setting calendar data only for the V series, use a macro command " SYS (SET_SYS_CLND) F1" (page 4-304).
- The result of macro execution is stored in \$s72.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

SYS

SYS (SET_BUFNO) F1

All models	<input type="radio"/>
------------	-----------------------

Function 1: Logging information

This macro command is used to store the average, maximum, minimum, and total of logging numbers 0 to 31 located in the block number specified in [F1] in system devices \$s180 to 435.

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F1	⊙			

○ : Setting enabled (indirect designation disabled)

⊙ : Setting enabled (indirect designation enabled)

\$s1671

The server designation (logging server, alarm server, V8 compatible operation) is changed according to the value in \$s1671.

\$s1671	Contents
0	V8 compatible operation (buffering area number designation)
1	Logging server designation
2	Alarm server designation

Setting range

	Value
F0	SET_BUFNO
F1	0 - 11: Logging block No.
\$s180 - 181	Logging No. 0 Average
\$s182 - 183	Logging No. 0 Maximum
\$s184 - 185	Logging No. 0 Minimum
\$s186 - 187	Logging No. 0 Total
\$s188 - 195	Logging No. 1 Average/maximum/minimum/total
\$s196 - 203	Logging No. 2 Average/maximum/minimum/total
\$s204 - 211	Logging No. 3 Average/maximum/minimum/total
\$s212 - 219	Logging No. 4 Average/maximum/minimum/total
\$s220 - 227	Logging No. 5 Average/maximum/minimum/total
\$s228 - 235	Logging No. 6 Average/maximum/minimum/total
\$s236 - 243	Logging No. 7 Average/maximum/minimum/total
\$s244 - 251	Logging No. 8 Average/maximum/minimum/total
\$s252 - 259	Logging No. 9 Average/maximum/minimum/total
\$s260 - 267	Logging No. 10 Average/maximum/minimum/total
\$s268 - 275	Logging No. 11 Average/maximum/minimum/total
\$s276 - 283	Logging No. 12 Average/maximum/minimum/total
\$s284 - 291	Logging No. 13 Average/maximum/minimum/total
\$s292 - 299	Logging No. 14 Average/maximum/minimum/total
\$s300 - 307	Logging No. 15 Average/maximum/minimum/total
\$s308 - 315	Logging No. 16 Average/maximum/minimum/total
\$s316 - 323	Logging No. 17 Average/maximum/minimum/total

	Value
\$s324 - 331	Logging No. 18 Average/maximum/minimum/total
\$s332 - 339	Logging No. 19 Average/maximum/minimum/total
\$s340 - 347	Logging No. 20 Average/maximum/minimum/total
\$s348 - 355	Logging No. 21 Average/maximum/minimum/total
\$s356 - 363	Logging No. 22 Average/maximum/minimum/total
\$s364 - 371	Logging No. 23 Average/maximum/minimum/total
\$s372 - 379	Logging No. 24 Average/maximum/minimum/total
\$s380 - 387	Logging No. 25 Average/maximum/minimum/total
\$s388 - 395	Logging No. 26 Average/maximum/minimum/total
\$s396 - 403	Logging No. 27 Average/maximum/minimum/total
\$s404 - 411	Logging No. 28 Average/maximum/minimum/total
\$s412 - 419	Logging No. 29 Average/maximum/minimum/total
\$s420 - 427	Logging No. 30 Average/maximum/minimum/total
\$s428 - 435	Logging No. 31 Average/maximum/minimum/total

← V series (Return data)

Example

```
$s01671 = 1 (W) [Logging server designation]
$u100 = 5 (W) [Block No.]
SYS (SET_BUFNO) $u100
```

The above program stores the average, maximum, minimum and total values of logging block No. 5 in \$s180 to 435.

Supplementary remarks

- Logging numbers 32 to 255 are not available with this macro command.
- The [Others] → [Use Calculation Operation] checkbox must be selected in the logging block settings.
- The logging block number specified by the macro is stored in \$s1705.
- The result of macro execution is stored in \$s72.

When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

Function 2: Alarm log information

This macro command is used to store alarm log information of block number specified in [F1] in \$\$s436 - 443.

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F1	⊙			

○ : Setting enabled (indirect designation disabled)

⊙ : Setting enabled (indirect designation enabled)

\$\$s1671

The server designation (logging server, alarm server, V8 compatible operation) is changed according to the value in \$\$s1671.

\$\$s1671	Contents
0	V8 compatible operation (buffering area number designation)
1	Logging server designation
2	Alarm server designation

Setting range

	Value
F0	SET_BUFNO
F1	0 - 11: Alarm block number
\$\$s436 - 437	Automatic operation time
\$\$s438 - 439	Automatic operation stop time
\$\$s440 - 441	Program stop time
\$\$s442	Number of stops
\$\$s443	Rate of operation XX.X

: ← V series (Return data)

Example

\$\$s01671 = 2 (W) [Alarm server designation]

\$\$u100 = 4 (W) [Block No.]

SYS(SET_BUFNO) \$\$u100

The above program stores the alarm log information of alarm block No. 4 in \$\$s436 to 443.

Supplementary remarks

- This command is valid only when [Alarm History] ([Alarm Block] → [Alarm Device]) is checked.
- The alarm block number specified by the macro is stored in \$\$s1706.
- The result of macro execution is stored in \$\$s72.

When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

SYS

SYS (GET_SMPL) F1

All models	<input type="radio"/>
------------	-----------------------

Function: Acquire logging/alarm data

This macro command is used to store the data of the specified block, logging, or alarm device memory in the device memory address \$u [F1+2].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F1	⊙			

○ : Setting enabled (indirect designation disabled)

⊙ : Setting enabled (indirect designation enabled)

\$\$s1671

The server designation (logging server, alarm server, V8 compatible operation) is changed according to the value in \$\$s1671.

\$\$s1671	Contents
0	V8 compatible operation (buffering area number designation)
1	Logging server designation
2	Alarm server designation

\$\$s1672

When "2" is stored in \$\$s1671 (alarm server designation), the data type to acquire (event history, real time, alarm history) is changed according to the value in \$\$s1672.

\$\$s1672	Contents
0	Event history data
1	Real time data
2	Alarm history data

Setting range

		Value																
F0		GET_SMPL																
F1		0 - 11: Block number																
F1+1		0 or above: Logging number / Alarm device memory number																
F1+2		0 - 32767: Storage target internal device memory No. "n"																
Trigger / Constant cycle / Device memory map	\$u n	Time data 0 <table border="1" style="width: 100%; text-align: center;"> <tr> <td>15</td><td>14</td><td>13</td><td>12</td><td>11</td><td>10</td><td>9</td><td>8</td><td>7</td><td>6</td><td>5</td><td>4</td><td>3</td><td>2</td><td>1</td><td>0</td> </tr> </table> Month: 1 - 12 Day: 1 - 31 Hour: 0 - 23	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
	\$u n+1	Time data 1 <table border="1" style="width: 100%; text-align: center;"> <tr> <td>15</td><td>14</td><td>13</td><td>12</td><td>11</td><td>10</td><td>9</td><td>8</td><td>7</td><td>6</td><td>5</td><td>4</td><td>3</td><td>2</td><td>1</td><td>0</td> </tr> </table> Minutes & seconds (unit: seconds) [Time data 1]/[60] = [A] remainder [B] [A]: minutes [B]: seconds	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
	\$u n+2	Logging data (maximum number of logging data: 128 words)																
\$u n+3																		
:																		
Alarm (Event history / Alarm logging)	\$u n	Time data 0 <table border="1" style="width: 100%; text-align: center;"> <tr> <td>15</td><td>14</td><td>13</td><td>12</td><td>11</td><td>10</td><td>9</td><td>8</td><td>7</td><td>6</td><td>5</td><td>4</td><td>3</td><td>2</td><td>1</td><td>0</td> </tr> </table> Month: 1 - 12 Day: 1 - 31 Hour: 0 - 23	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
	\$u n+1	Time data 1 <table border="1" style="width: 100%; text-align: center;"> <tr> <td>15</td><td>14</td><td>13</td><td>12</td><td>11</td><td>10</td><td>9</td><td>8</td><td>7</td><td>6</td><td>5</td><td>4</td><td>3</td><td>2</td><td>1</td><td>0</td> </tr> </table> Minutes & seconds (unit: seconds)	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0			
\$u n+2	Sampling bit number <table border="1" style="width: 100%; text-align: center;"> <tr> <td>15</td><td>14</td><td>13</td><td>12</td><td>11</td><td>10</td><td>9</td><td>8</td><td>7</td><td>6</td><td>5</td><td>4</td><td>3</td><td>2</td><td>1</td><td>0</td> </tr> </table> 0: OFF Bit number 1: ON	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0			
Alarm (Real time / Time order alarming)	\$u n	Time data 0 <table border="1" style="width: 100%; text-align: center;"> <tr> <td>15</td><td>14</td><td>13</td><td>12</td><td>11</td><td>10</td><td>9</td><td>8</td><td>7</td><td>6</td><td>5</td><td>4</td><td>3</td><td>2</td><td>1</td><td>0</td> </tr> </table> Month: 1 - 12 Day: 1 - 31 Hour: 0 - 23	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
	\$u n+1	Time data 1 <table border="1" style="width: 100%; text-align: center;"> <tr> <td>15</td><td>14</td><td>13</td><td>12</td><td>11</td><td>10</td><td>9</td><td>8</td><td>7</td><td>6</td><td>5</td><td>4</td><td>3</td><td>2</td><td>1</td><td>0</td> </tr> </table> Minutes & seconds (unit: seconds)	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0			
\$u n+2	Sampling relay number <table border="1" style="width: 100%; text-align: center;"> <tr> <td>15</td><td>14</td><td>13</td><td>12</td><td>11</td><td>10</td><td>9</td><td>8</td><td>7</td><td>6</td><td>5</td><td>4</td><td>3</td><td>2</td><td>1</td><td>0</td> </tr> </table> Relay number	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0			

		Value
Alarm (Alarm history / Alarm tracking)	\$u n	Time data 0
	\$u n+1	Time data 1 <div style="border: 1px solid black; padding: 2px; margin: 5px 0;"> <div style="display: flex; justify-content: space-between;"> Time data 1 Time data 0 </div> </div> GMT-based UNIX time from January 1, 1970
	\$u n+2	Alarm bit information <div style="border: 1px solid black; padding: 2px; margin: 5px 0;"> <div style="display: flex; justify-content: space-between;"> 1514131211109876543210 </div> </div> Bit number 1: Power-off after an alarm occurrence 1: Deleted by DEL key 1: First cause 0: Reset 1: Occurrence

: ← V series (return data)

Example

```

$s01671 = 2 (W) [Alarm server designation]
$s01672 = 1 (W) [Real time data designation]
$u100 = 3 (W) [Block No.]
$u101 = 0 (W) [Alarm No.]
$u102 = 200 (W) [Storage target device memory]
SYS (GET_SMPL) $u100
    
```

The above program stores the information of alarm No. 0 in alarm block No. 3 in \$s200.


For alarm (real time)

\$u200 = 1E8F HEX

\$u201 = 06B4 HEX

\$u202 = 0002 HEX

July 20, 15:28:36, bit No. 2 ON



Supplemental remarks

- The result of macro execution is stored in \$s72
 When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended..

Code (DEC)	Contents
-1	Execution error

SYS**SYS (GET_SCUR) F1**

All models	<input type="radio"/>
------------	-----------------------

Function: Cursor point acquisition

This macro command is used to store the sampling number and the cursor address associated with the of the logging or alarm viewer currently being displayed.

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F1	⊙			

○ : Setting enabled (indirect designation disabled)

⊙ : Setting enabled (indirect designation enabled)

Setting range

	Value	Remarks
F0	GET_SCUR	
F1	0: Base 1 - 10: Overlap ID 0 - 9	
F1+1	0 - 255 : ID	
F1+2	0: Cursor non-display	The most recent information to be stored in F1+3 and F1+4
	1: Cursor display	The cursor information to be stored in F1+3 and F1+4
F1+3	0 or above: Sample number	Used by GET_SMPL
F1+4	0 or above: Cursor address	Sampling number comparison*

⊙ : ← V series (Return data)

* Whether or not the acquired sampling number is the same as that previously acquired is checked.

Even if the sampling number remains the same, any change in the cursor address means that the data to be fetched has also changed.

Contrary, even if the sampling number has changed, no change in the cursor address means that the data to be accessed also remains the same.

Example

- \$u100 = 0 (W) [Base]
\$u101 = 1 (W) [ID]
SYS (GET_SCUR) \$u100

The above program acquires the cursor point of the logging or alarm data (ID 1) on the base screen.

```
$u102 = 1      [Cursor being displayed]
$u103 = 28    [Sample number]
$u104 = 39 (W) [Cursor address]
```

Supplemental remarks

- This command can be used only in the V8-compatible mode.
- The macro command is valid in the following cases:
 - [Historical Display] is selected for [Display mode] in the logging viewer.
 - [Event History] is selected for [Display mode] in the alarm viewer.
- If the sampling number is "5" at the time of the execution of GET_SCUR, the sampling count (numerical data display) on the screen shows "6".
This results from the fact that the cursor point starts from "0" and the sampling count (numerical data display) starts from "1".

- The result of macro execution is stored in \$s72. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

SYS**SYS (DSP_DATA) F1**

All models	<input type="radio"/>
------------	-----------------------

Function: Show/hide numerical data display

This macro command is used to show/hide numerical data displays placed in the specified location (ID).

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F1	<input checked="" type="radio"/>			

: Setting enabled (indirect designation disabled)

: Setting enabled (indirect designation enabled)

Setting range

	Value
F0	DSP_DATA
F1	0: Base 1 - 3: Overlap ID 0 - 2 4 - 7: Data block No. 0 - 3 8 - 14: Overlap ID 3 - 9
F1+1	0 - 255: ID
F1+2	0: Not display 1: Display

Example

- \$u100 = 0 (W) [Base]
- \$u101 = 1 (W) [ID]
- \$u102 = 0 (W) [Not display]
- SYS (DSP_DATA) \$u100

The above program hides all numerical data displays of ID 1 on the base screen.

Supplemental remarks

- The macro command is valid for numerical data displays only. It cannot be used for character and message displays.
- The result of macro execution is stored in \$s72. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

SYS

SYS (CHG_DATA) F1

All models	<input type="radio"/>
------------	-----------------------

Function: Change numerical data display property

This macro command is used to change the properties of the numerical data displays placed in the specified location (ID).

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F1	⊙			

○ : Setting enabled (indirect designation disabled)
 ⊙ : Setting enabled (indirect designation enabled)

Setting range

	Value																																																																						
F0	CHG_DATA																																																																						
F1	0: Base 1 - 3: Overlap ID 0 - 2 4 - 7: Data block No. 0 - 3 8 - 14: Overlap ID 3 - 9																																																																						
F1+1	0 - 255: ID																																																																						
F1+2	0: Without signs 1: With signs 2: With sign (+) 3: HEX 4: OCT 5: BIN																																																																						
F1+3	<p>Color</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="text-align: center; width: 50%;">Background color</td> <td style="text-align: center; width: 50%;">Foreground color</td> </tr> <tr> <td style="text-align: center;"> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 15px;">15</td><td style="width: 15px;">14</td><td style="width: 15px;">13</td><td style="width: 15px;">12</td><td style="width: 15px;">11</td><td style="width: 15px;">10</td><td style="width: 15px;">9</td><td style="width: 15px;">8</td> <td style="width: 15px;">7</td><td style="width: 15px;">6</td><td style="width: 15px;">5</td><td style="width: 15px;">4</td><td style="width: 15px;">3</td><td style="width: 15px;">2</td><td style="width: 15px;">1</td><td style="width: 15px;">0</td> </tr> <tr> <td colspan="8" style="text-align: center;">0 to 127 colors</td> <td colspan="8" style="text-align: center;">0 to 127 colors</td> </tr> <tr> <td colspan="8" style="text-align: center;">└ Blink</td> <td colspan="8" style="text-align: center;">└ Blink</td> </tr> </table> </td> <td style="text-align: center;"> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Color</th> <th>Code (HEX)</th> </tr> </thead> <tbody> <tr><td>Black</td><td>00</td></tr> <tr><td>Blue</td><td>01</td></tr> <tr><td>Red</td><td>02</td></tr> <tr><td>Magenta</td><td>03</td></tr> <tr><td>Green</td><td>04</td></tr> <tr><td>Cyan</td><td>05</td></tr> <tr><td>Yellow</td><td>06</td></tr> <tr><td>White</td><td>07</td></tr> </tbody> </table> </td> </tr> </table>	Background color	Foreground color	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 15px;">15</td><td style="width: 15px;">14</td><td style="width: 15px;">13</td><td style="width: 15px;">12</td><td style="width: 15px;">11</td><td style="width: 15px;">10</td><td style="width: 15px;">9</td><td style="width: 15px;">8</td> <td style="width: 15px;">7</td><td style="width: 15px;">6</td><td style="width: 15px;">5</td><td style="width: 15px;">4</td><td style="width: 15px;">3</td><td style="width: 15px;">2</td><td style="width: 15px;">1</td><td style="width: 15px;">0</td> </tr> <tr> <td colspan="8" style="text-align: center;">0 to 127 colors</td> <td colspan="8" style="text-align: center;">0 to 127 colors</td> </tr> <tr> <td colspan="8" style="text-align: center;">└ Blink</td> <td colspan="8" style="text-align: center;">└ Blink</td> </tr> </table>	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	0 to 127 colors								0 to 127 colors								└ Blink								└ Blink								<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Color</th> <th>Code (HEX)</th> </tr> </thead> <tbody> <tr><td>Black</td><td>00</td></tr> <tr><td>Blue</td><td>01</td></tr> <tr><td>Red</td><td>02</td></tr> <tr><td>Magenta</td><td>03</td></tr> <tr><td>Green</td><td>04</td></tr> <tr><td>Cyan</td><td>05</td></tr> <tr><td>Yellow</td><td>06</td></tr> <tr><td>White</td><td>07</td></tr> </tbody> </table>	Color	Code (HEX)	Black	00	Blue	01	Red	02	Magenta	03	Green	04	Cyan	05	Yellow	06	White	07
Background color	Foreground color																																																																						
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 15px;">15</td><td style="width: 15px;">14</td><td style="width: 15px;">13</td><td style="width: 15px;">12</td><td style="width: 15px;">11</td><td style="width: 15px;">10</td><td style="width: 15px;">9</td><td style="width: 15px;">8</td> <td style="width: 15px;">7</td><td style="width: 15px;">6</td><td style="width: 15px;">5</td><td style="width: 15px;">4</td><td style="width: 15px;">3</td><td style="width: 15px;">2</td><td style="width: 15px;">1</td><td style="width: 15px;">0</td> </tr> <tr> <td colspan="8" style="text-align: center;">0 to 127 colors</td> <td colspan="8" style="text-align: center;">0 to 127 colors</td> </tr> <tr> <td colspan="8" style="text-align: center;">└ Blink</td> <td colspan="8" style="text-align: center;">└ Blink</td> </tr> </table>	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	0 to 127 colors								0 to 127 colors								└ Blink								└ Blink								<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Color</th> <th>Code (HEX)</th> </tr> </thead> <tbody> <tr><td>Black</td><td>00</td></tr> <tr><td>Blue</td><td>01</td></tr> <tr><td>Red</td><td>02</td></tr> <tr><td>Magenta</td><td>03</td></tr> <tr><td>Green</td><td>04</td></tr> <tr><td>Cyan</td><td>05</td></tr> <tr><td>Yellow</td><td>06</td></tr> <tr><td>White</td><td>07</td></tr> </tbody> </table>	Color	Code (HEX)	Black	00	Blue	01	Red	02	Magenta	03	Green	04	Cyan	05	Yellow	06	White	07				
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0																																																								
0 to 127 colors								0 to 127 colors																																																															
└ Blink								└ Blink																																																															
Color	Code (HEX)																																																																						
Black	00																																																																						
Blue	01																																																																						
Red	02																																																																						
Magenta	03																																																																						
Green	04																																																																						
Cyan	05																																																																						
Yellow	06																																																																						
White	07																																																																						
F1+4	<p>Decimal point and number of digits</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 15px;">15</td><td style="width: 15px;">14</td><td style="width: 15px;">13</td><td style="width: 15px;">12</td><td style="width: 15px;">11</td><td style="width: 15px;">10</td><td style="width: 15px;">9</td><td style="width: 15px;">8</td> <td style="width: 15px;">7</td><td style="width: 15px;">6</td><td style="width: 15px;">5</td><td style="width: 15px;">4</td><td style="width: 15px;">3</td><td style="width: 15px;">2</td><td style="width: 15px;">1</td><td style="width: 15px;">0</td> </tr> <tr> <td colspan="8" style="text-align: center;">Decimal point 0 - 10</td> <td colspan="8" style="text-align: center;">Number of digits 1 - 31</td> </tr> </table>	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Decimal point 0 - 10								Number of digits 1 - 31																																													
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0																																																								
Decimal point 0 - 10								Number of digits 1 - 31																																																															

Example

The above program changes the properties of the numerical data display of ID1 placed on the base screen.

- Type: HEX
- Background color: Black
- Foreground color: Green
- Decimal Point: None
- Number of digits: 5


```
$u200 = 0 (W)      [Base]
$u201 = 1 (W)      [ID]
$u202 = 0 (W)      [Not display]
SYS (DSP_DATA) $u200
```

```
$u100 = 0 (W)      [Base]
$u101 = 1 (W)      [ID]
$u102 = 3 (W)      [Type]
$u103 = 0004H (W)  [Color]
$u104 = 0005H (W)  [Decimal point and number of digits]
SYS (CHG_DATA) $u100 macro execution
```

```
$u200 = 0 (W)      [Base]
$u201 = 1 (W)      [ID]
$u202 = 1 (W)      [Display]
SYS (DSP_DATA) $u200
```

Supplemental remarks

- The macro command is valid for numerical data displays only. It cannot be used for character and message displays.
- When using this macro command, be sure to execute the command DSP_DATA to redisplay the data. For more information on DSP_DATA, refer to page 4-282.
- Even on MONITOUCH with 32k- or 64k-color display, 128 colors + blink ([Custom Color] → [Palette 1]) are available with the macro command.
- 128-color codes
The boxes on the palette are provided with their individual codes.



- The result of macro execution is stored in \$s72. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

SYS

SYS (STA_LIST) F1

All models	<input type="radio"/>
------------	-----------------------

Function: Data sheet print

This macro command is used to print data sheets.

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F1	⊙			

○ : Setting enabled (indirect designation disabled)
 ⊙ : Setting enabled (indirect designation enabled)

Setting range


	Value
F0	STA_LIST
F1	0 - 1023: Print start number
F1+1	1 - 1023: Number of pages to be printed
F1+2	ASCII code: Output file name (64 one-byte alphanumeric characters maximum) *
:	
F1+33	

* Valid only when \$s1656 = 1 (output in PDF)

Example


- \$u100 = 3 (W) [Print start number]
- \$u101 = 1 (W) [Number of pages to be printed]
- SYS (STA_LIST) \$u100 macro execution

The above program prints data sheet No. 3.



- \$s1656 = 1(W) Output destination: PDF
- \$u100 = 3(W) Print start number
- \$u101 = 1(W) Number of pages to be printed
- \$u102 = TEST (STRING)1(W) File name
- STA_LIST \$u100


Datasheet No. 3 is output to the storage device in PDF format.



Supplemental remarks

- If nothing is registered on a data sheet, specifying the page of this sheet does not produce a printout of it.

[Data Sheet Edit]



\$u100 = 10 [Print start number] Data sheet No. 10 to 12 and 14 can be printed.
 \$u101 = 5 [Number of pages to be printed] The page that is not stored, No. 13, is ignored, and four pages are output.

SYS (STA_LIST) \$u100

- The result of macro execution is stored in \$s72. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

SYS

V9 Advanced	
V910xiW	○
V907xiW	
V9 Standard	
All models	○
V9 Lite	
All models	
TELLUS	
TELLUS4 HMI	

SYS (RGB_CHG) F1

Function: Change RGB input parameter

This macro command is used to change the RGB parameter set on the RGB input screen (on the [Main Menu] screen) between [Setting 1] and [Setting 2].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F1	⊙			

○ : Setting enabled (indirect designation disabled)

⊙ : Setting enabled (indirect designation enabled)

Setting range

	Value
F0	RGB_CHG
F1	0: Setting 1 1: Setting 2

Example

- \$u100 = 1 (W) [Setting 2]
SYS (RGB_CHG) \$u100

The above program changes the RGB parameter from [Setting 1] to [Setting 2].

Supplemental remarks

- If the frequency is different between [Setting 1] and [Setting 2]: MONITOUCH selects [Setting 1] or [Setting 2] automatically.
 - If the frequency is the same between [Setting 1] and [Setting 2]: At power-on, [Setting 1] always takes effect. Afterward, [Setting 1] or [Setting 2] can be selected by the macro command.
 - This macro command is valid when "GUR-01" or "GUR-10" unit is used.
 - The result of macro execution is stored in \$s72.
- When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

SYS

V9 Advanced	
V910xiW	<input type="radio"/>
V907xiW	
V9 Standard	
All models	<input type="radio"/>
V9 Lite	
All models	
TELLUS	
TELLUS4 HMI	

SYS (SET_RGB) F1

Function 1: Switch from/to RGB input screen

This macro command is used to switch between the RGB input screen and the RUN screen.

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F1	Ⓞ			

○ : Setting enabled (indirect designation disabled)
 ◎ : Setting enabled (indirect designation enabled)

Setting range

	Value
F0	SET_RGB
F1	0: OFF (RUN screen) 1: ON (RGB input screen)

Example

- \$u100 = 0 (W) [RUN screen display]
 SYS (SET_RGB) \$u100

The above program switches from the RGB input screen to the RUN screen.

Supplemental remarks

- In addition to the macro command, [System Setting] → [Hardware Setting] → [Video/RGB] → [RGB Input Control Device] is also available to switch from/to the RGB input screen.
- While the [RGB Input Control Device] is set (ON), the macro command is invalid.
- The result of macro execution is stored in \$s72.
 When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

Function 2: Snap/delete RGB input screen

This macro command is used to snap and delete the RGB screen.

V9 Advanced	
V910xiW	○
V907xiW	
V9 Standard	
All models	○
V9 Lite	
All models	
TELLUS	
TELLUS4 HMI	

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F1	⊙			

○ : Setting enabled (indirect designation disabled)
 ⊙ : Setting enabled (indirect designation enabled)

Setting range

	Value	
F0	SET_RGB	
F1	2: Snap (turn the RGB screen ON and snap it) 3: File delete (delete the JPEG file generated by snapping)	
F1+1	(F1 = 2)	(F1 = 3)
	File No.: (0 - 32767 / -1 [AUTO])	File No.: (0 - 32767)

JPEG file

Storage target: \\(access folder)\SNAP
 File name: \\VDxxxxx.jpg
└
 00000 - 32767: File No.


Example

- \$u100 = 2 (W) [Snap]
 \$u101 = 0 (W) [Specify file No. 0.]
 SYS (SET_RGB) \$u100

The above program saves the currently displayed RGB input screen as VD00000.jpg.

Supplemental remarks

- When the file number is set to [AUTO] for the snap operation, if no file exists the file number is generated by incrementing from [00000], while if files exist it is generated by incrementing from the number following the current maximum number.
 However, the number must be within the range determined by [Maximum Number of Snap Files in Auto] under [System Setting] → [Hardware Setting] → [Video/RGB].



- When the number set for [Maximum Number of Snap Files in Auto] has been reached, operation proceeds in accordance with the specification ([Stop] or [Overwrite]) for [When the Limitation is Exceeded] under [System Setting] → [Hardware Setting] → [Video/RGB]. When [Overwrite] is selected, the number is reset to "0000" and the operation proceeds.
- The result of macro execution is stored in \$s72.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

V9 Advanced	
V910xiW	○
V907xiW	
V9 Standard	
All models	○
V9 Lite	
All models	
TELLUS	
TELLUS4 HMI	

Function 3: RGB input channel selection

This macro command is used to select the display in the read area, or to select the channel when the RGB input signal is switched using the "SET_RGB" macro command. It also selects the applicable channel for the touch switch emulation function.

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F1	⊙			

○ : Setting enabled (indirect designation disabled)

⊙ : Setting enabled (indirect designation enabled)

Setting range

	Value
F0	SET_RGB
F1	8: CH selection (selects the RGB channel)
F1+1	5: RGB IN1 6: RGB IN2

Example

- \$u100 = 8 (W) [RGB input channel selection]
\$u101 = 6 (W) [Specify RGB IN2.]
SYS (SET_RGB) \$u100

The above program switches to RGB IN2.

Supplemental remarks

- This function can be used only when the "GUR-11" unit is used.
- The default is [RGB IN1].
- The setting is maintained until the power is turned OFF. When the power goes OFF the setting is cleared and the default is set.
- This macro command is invalid if [TouchSW(CH5)] and [TouchSW(CH6)] under [System Setting] → [Hardware Setting] are checked.
For more information on touch switch emulation, refer to the V9 Series Reference Manual [2].
- The result of macro execution is stored in \$s72.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

SYS

All models	○
TELLUS4 HMI	

SYS (SET_BKLT) F1**Function: Backlight control**

This macro command is used to control the backlight.

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F1	⊙			

○ : Setting enabled (indirect designation disabled)

⊙ : Setting enabled (indirect designation enabled)

Setting range

	Value	Remarks
F0	SET_BKLT	
F1	0: OFF 1: ON	
	2: OFF time change	Valid when [Auto 1/2/3] is selected
F1+1	0 - 65535: OFF time (sec)	Setting required if F1 = 2

Example

- \$u100 = 0 (W) [OFF]
SYS (SET_BKLT) \$u100

The above program turns off the backlight.

Supplemental remarks

- When [Always ON] is selected for [Action] on the [Backlight] tab window in the [Unit Setting] dialog ([System Setting] → [Unit Setting]), the backlight will not turn off.
- The backlight will not turn off while the control device memory is ON.
- Do not execute the macro command in macros to be executed constantly using a CYCLE macro, an interval timer, or an event timer macro.
- The use of a switch ON macro to execute a backlight turn-on command will not be possible.
- At power-on, the backlight is restored to the status as set in [Backlight] tab window (initial status) in the [Unit Setting] dialog ([System Setting] → [Unit Setting]). The internal memory \$L is available to retain the value set with this macro command. By using the initial macro at power-on, this macro command is executable according to the value you stored with \$L.
- The result of macro execution is stored in \$s72.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

SYS

SYS (RESTART) F1

All models	<input type="radio"/>
------------	-----------------------

Function: Restart

This macro command is used to restart the V series when the time (in seconds) specified in [F1] has elapsed.

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F1	⊙			

○ : Setting enabled (indirect designation disabled)

⊙ : Setting enabled (indirect designation enabled)

Setting range

	Value
F0	RESTART
F1	0 - 60: Time (sec)
F1+1	1: Restart from the OS Other than 1: Restart without rebooting the OS

* When F1+1=1:

RUN mode → "Restarting. Please wait..." → Local mode (elapsed time defined as F1) → Black screen → Data Loading... → Splash screen → RUN mode

When F1+1=Other than 1:

RUN mode → "Restarting. Please wait..." → Local mode (elapsed time defined as F1) → RUN mode

Example

- \$u100 = 10 (W) [sec]
\$u101 = 1 (W)
SYS (RESTART) \$u100

The above program switches the operation mode to Local mode and reboots the OS on the V9 after 10 seconds elapse in Local mode.

Supplemental remarks

- When the macro command has been executed, the data in the internal memory \$u becomes "0".
- The result of macro execution is stored in \$s72. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

SYS

SYS (CHG_LANG) F1

All models	○
------------	---

Function: Language change

This macro command is used to switch the language displayed on MONITOUCH to the language specified in [F1].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F1	◎			


○ : Setting enabled (indirect designation disabled)
 ◎ : Setting enabled (indirect designation enabled)

Setting range

	Value
F0	CHG_LANG
F1	0: Language 1 1: Language 2 2: Language 3 : 13: Language 14 14: Language 15 15: Language 16

Example

In the example below, the ON macros for the screen change switches are used to switch between two languages.



Supplemental remarks

- When the screen is switched, the language also switches.
 To change the language on the same screen, use the “SYS(RESET_SCRN)” command (page 4-296).
- At power-on, the language as displayed before power-off takes effect.

- The result of macro execution is stored in \$s72. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

SYS

SYS (RESET_SCRN) F1

All models	<input type="radio"/>
------------	-----------------------

Function: Redisplay screen

This macro command is used to reset the currently displayed screen. It is convenient for switching languages and for switching the display of screen libraries.

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F1	⊙			

○ : Setting enabled (indirect designation disabled)
 ⊙ : Setting enabled (indirect designation enabled)

Setting range

	Value
F0	RESET_SCRN
F1	Bit OFF (0) : Executed Bit ON (1) : Disabled <p style="text-align: center;"> 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0 Reserved for the system (fixed at 0) Screen OPEN macro — Screen CLOSE macro — \$T device memory initialization — Transmission of screen interrupt command (with universal serial selected) * Multiple bits can be specified at the same time. </p>

Example

- \$u100 = 0H (W)
 SYS (RESET_SCRN) \$u100
 Close macro, open macro, and internal device memory \$T are initialized and the screen currently displayed is reset.
- \$u100 = CH (W)
 SYS (RESET_SCRN) \$u100
 The screen currently displayed is reset without executing close macro and open macro.

Supplemental remarks

- The macro command is invalid in screen OPEN, screen CLOSE, overlap library OPEN, overlap library CLOSE, and initial macros. Executing these error results in failure.
- The macro command is valid only once in a macro created on the macro edit sheet. Its execution timing is set at the end of the macro on the edit sheet.
- When screen change using a switch is disabled (the 0th bit of control device under [Hardware Setting] → [Control Area] is ON), the macro is invalid.
- [Function: Return] for the switch is valid even after using this command.
- The result of macro execution is stored in \$s72.
 When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

SYS

SYS (GET_STATUS_FL) F1

All models	○
TELLUS4 HMI	

Function: FL-Net information acquisition

This macro command is used to acquire the FL-Net node information.

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F1	⊙			

○ : Setting enabled (indirect designation disabled)

⊙ : Setting enabled (indirect designation enabled)

Setting range

		Value
F0		GET_STATUS_FL
Local node information	F1	0: Local node information
	\$s627	Local node FA link status
	\$s628	Local node status
	\$s629	Local node FL-Net status
	\$s646	Current permissible time for refresh cycle
	\$s654	Current minimum permissible frame interval
Guest node information	F1	1 - 254: Guest node information
	\$s647	Guest node number
	\$s648	Host status
	\$s649	Guest node area 1 top address
	\$s650	Guest node area 1 data size
	\$s651	Guest node area 2 top address
	\$s652	Guest node area 2 data size
	\$s653	Guest node FA link status

☐ : ← V series (Return data)

Example

- \$u100 = 0 (W)
SYS (GET_STATUS_FL) \$u100
The above program acquires the local node information.
- \$u100 = 2 (W)
SYS (GET_STATUS_FL) \$u100
The above program acquires node No. 2 information.

Supplemental remarks

- The macro command is valid for FL-Net communication only.
- For more information, refer to the V9/TS2060 Communication Unit Specifications FL-Net.

- The result of macro execution is stored in \$s72.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

SYS

SYS (OUT_ENQ) F1

All models	<input type="radio"/>
------------	-----------------------

Function 1: Universal serial (interrupt)

This macro command is used to execute an interrupt.

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F1	Ⓞ			

Ⓞ : Setting enabled (indirect designation disabled)

Ⓢ : Setting enabled (indirect designation enabled)

Setting range

	Value	Remarks
F0	OUT_ENQ_EX	
F1	ENQ No. 10 - 2F _{HEX} : For PLC1 30 - 3F _{HEX} : For PLC2 40 - 4F _{HEX} : For PLC3 50 - 5F _{HEX} : For PLC4 60 - 6F _{HEX} : For PLC5 70 - 7F _{HEX} : For PLC6 80 - 8F _{HEX} : For PLC7 90 - 9F _{HEX} : For PLC8	
F1+1	Transfer format 0: Numerical 1: Characteristic	
F1+2	1 - 16384: Word count 2 - 32768: Number of bytes	If F1+1 = 1
F1+3	Top address number	
F1+4	0: Non-wait 1: Wait	Executes the next macro Executes the next macro after a transmission is complete

Example

The following programs transmit the specified data to the host connected to PLC1 when the character display (\$u200) shows "ABCD".

- Transfer data format: Numerical
 \$u100 = 10H (W) [ENQ No. to PLC1]
 \$u101 = 0 (W) [Numerical]
 \$u102 = 2 (W) [Word count]
 \$u103 = 200 (W) [Top address]
 \$u104 = 0 (W) [Non-wait]
 SYS (OUT_ENQ_EX) \$u100 Macro execution
 Data received at the host: 3431343234333434H
- Transfer data format: Characteristic
 \$u100 = 10H (W) [ENQ No. to PLC1]
 \$u101 = 1 (W) [Characteristic]
 \$u102 = 4 (W) [Number of bytes]
 \$u103 = 200 (W) [Top address number]
 \$u104 = 0 (W) [Non-wait]
 SYS (OUT_ENQ_EX) \$u100
 Data received at the host: 41424344H

Supplemental remarks

- The result of macro execution is stored in \$s72. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

All models	○
TELLUS4 HMI	

Function 2: A-link+Net10 (network designation)

This macro command is used to designate a target network, with which a connection will be established.

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F1	◎			

○ : Setting enabled (indirect designation disabled)

◎ : Setting enabled (indirect designation enabled)

Setting range

	Value	Remarks
F0	OUT_ENQ	
F1	0: Fixed	
F1+1	2: Fixed	
F1+2	System code 1: NET/10 2: NET II (/B)	
F1+3	0: Fixed	If F1+2 = 2
	1: Network number	If F1+2 = 2

Example

- \$u100 = 0 (W) [Fixed]
- \$u101 = 2 (W) [Fixed]
- \$u102 = 1 (W) [NET/10]
- \$u103 = 3 (W) [Network number]
- SYS (OUT_ENQ) \$u100

According to the above program, the PLC connected to the V series accesses the PLC NET 10 on network No. 3.

Supplemental remarks

- The macro command is valid when [A-link + Net10] is selected for [Select PLC1 Type].
- Be sure to use the macro command in an OPEN macro for the screen. If it is used in any other way, the network will change immediately after the command is executed and a communication error will result.
- For more information, refer to the V9 Series Connection Manual.
- The result of macro execution is stored in \$s72.

When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

SYS**SYS (OUT_ENQ_EX) F1**

All models	<input type="radio"/>
------------	-----------------------

Universal serial (interrupt)

This macro command is used to execute an interrupt.

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F1	⊙			

○: Setting enabled (indirect designation disabled)

⊙: Setting enabled (indirect designation enabled)

Setting range

	Value	Remarks
F0	OUT_ENQ_EX	
F1	1 - 8: PLC No.	
F1+1	10 - 2F _{HEX} : ENQ No.	
F1+2	Transfer format 0: Numerical 1: Characteristic	
F1+3	1 - 16384: Word count	When [F1+1] = 0
	2 - 32768: Number of bytes	When [F1+1] = 1
F1+4	Top address number	
F1+5	0: Non-wait	Executes the next macro
	1: Wait	Executes the next macro after a transmission is complete

Example

The following programs transmit the specified data to the host connected to PLC2 when the character display (\$u200) shows "ABCD".

- Transfer data format: Numerical
 - \$u100 = 2 (W) [PLC No.]
 - \$u101 = 10H (W) [ENQ No.]
 - \$u102 = 0 (W) [Numerical]
 - \$u103 = 2 (W) [Word count]
 - \$u104 = 200 (W) [Top address]
 - \$u105 = 0 (W) [Non-wait]

SYS (OUT_ENQ_EX) \$u100
Data received at the host:3431343234333434H

- Transfer data format: Characteristic
 - \$u100 = 2 (W) [PLC No.]
 - \$u101 = 10H (W) [ENQ No.]
 - \$u102 = 1 (W) [Characteristic]
 - \$u103 = 4 (W) [Number of bytes]
 - \$u104 = 200 (W) [Top address number]
 - \$u105 = 0 (W) [Non-wait]

SYS (OUT_ENQ_EX) \$u100
Data received at the host: 41424344H

Supplementary remarks

- The result of macro execution is stored in \$s72. When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

SYS**SYS (SET_SYS_CLND) F1**

All models	<input type="radio"/>
------------	-----------------------

Function: System calendar setting

This macro command is used to set the values of seven words starting from the address specified in [F1] to the system calendar.
The PLC calendar is not changed.

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F1	⊙			

○ : Setting enabled (indirect designation disabled)

⊙ : Setting enabled (indirect designation enabled)

Setting range

	Value	
F0	SET_SYS_CLND	
F1	0 - : Year (4-digit/2-digit)	
F1+1	1 - 12: Month	
F1+2	1 - 31: Day	
F1+3	0 - 23: Hour	
F1+4	0 - 59: Minute	
F1+5	0 - 59: Second	
F1+6	Day of the week	Invalid; to be automatically calculated by MONITOUCH

Example

- \$u100 = 2005 (W)
 - \$u101 = 7 (W)
 - \$u102 = 15 (W)
 - \$u103 = 15 (W)
 - \$u104 = 0 (W)
 - \$u105 = 0 (W)
 - SYS (SET_SYS_CLND) \$u00100
- } July 15, 2005 Friday 15:00:00

The above program sets the calendars in MONITOUCH to July 15, 2005 on Friday at 15:00:00.

Supplemental remarks

- When setting calendar data for PLC 1 to 8, use a macro command " PLC_CLND" (page 4-149).
- The result of macro execution is stored in \$s72.
When the execution of the macro is normally complete, the value at the address is not updated. Therefore, before macro execution, resetting the value at the address to zero is recommended.

Code (DEC)	Contents
-1	Execution error

HMI-FUNC

All models	
TELLUS4 HMI	○

HMI-USERFUNC (F1, " ")

Function: DLL function execution

This macro command is used to execute the function in the dll file loaded to the table specified in [F1].

Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F1				○

○ : Setting enabled (indirect designation disabled)
 ◎ : Setting enabled (indirect designation enabled)

Setting range

	Value
F0	HMI-USERFUNC
F1	0: Table number : : 255
Text	Function name

Example

- HMI-USERFUNC (0, "DspMsg")





Table No.	dll	Function defined in dll file
0	Test2.dll	DspMsg
1	Test1.dll	aa
⋮	⋮	⋮
255		



Supplemental remarks

- This macro command is valid, provided that either "TELLUS Ver. 4" is selected in the [Edit Model Selection] dialog.
- It is necessary to load the dll file by HMI-LoadDll in advance.


HMI-FUNC

All models	
TELLUS4 HMI	○

HMI-LOADDLL (F1 , " ")

Function: Load DLL file

This macro command is used to load a dll file prepared by users to the table specified in [F1].



Available device memory

	Internal device memory	PLC 1 - 8 device memory	Memory card	Constant
F1				○


○ : Setting enabled (indirect designation disabled)
 ◎ : Setting enabled (indirect designation enabled)

Setting range

	Value
F0	HMI-LOADDLL
F1	0: Table number ⋮ 255
Text	Location of dll file (pathname)

Example

- HMI-LOADDLL (0, "C:\Test2.dll")



Supplemental remarks

- This macro command is valid, provided that either "TELLUS Ver. 4" is selected in the [Edit Model Selection] dialog.
- When executing the function in the loaded dll file, use HMI-UserFunc.
- Once a dll file is loaded, the function in the file can be executed by HMI-UserFunc repeatedly as desired in, for example, an initial macro.

HMI-FUNC

All models	
TELLUS4 HMI	○


HMI-SHUTDOWN

Function: Computer shutdown

This macro command is used to shut down the computer.

Example

- HMI-SHUTDOWN



Supplemental remarks

- This macro command is valid, provided that either "TELLUS Ver. 4" is selected in the [Edit Model Selection] dialog.
- If the macro command is executed on a panel computer without the power-off function, the message indicating that the computer is ready to be turned off appears.

HMI-FUNC

All models	
TELLUS4 HMI	○

HMI-USEREXE (" ")

Function: Application file execution


This macro command is used to execute an exe file.

Setting range


	Value
F0	HMI-USEREXE
Text	exe file and the location of the file to be executed concurrently (pathname)

Example


- HMI-USEREXE ("notepad.exe "C:\MONITOUCH\HMI.txt")



- * Some applications may need to set a pathname. The pathname can be specified by putting it in quotation marks (" ").



Outcome



Supplemental remarks

- This macro command is valid, provided that either "TELLUS Ver. 4" is selected in the [Edit Model Selection] dialog.

HMI-FUNC

All models	
TELLUS4 HMI	<input type="radio"/>

HMI-CLOSE**Function: TELLUS termination**


This macro command is used to terminate the Tellus HMI mode.

Supplemental remarks

- This macro command is valid, provided that either "TELLUS Ver. 4" is selected in the [Edit Model Selection] dialog.

MEMO

Please use this page freely.



 **Hakko Electronics Co., Ltd.**
www.monitouch.com

Sales 890-1, Kamikashiwano-machi, Hakusan-shi, Ishikawa,
924-0035 Japan
TEL +81-76-274-2144 FAX +81-76-274-5136