

Firmware Update Procedure


This document describes on how to update the AP-500AC's firmware.

* In following instructions, Windows 10 is used as an example, however, the procedure will be the same even if you are using an OS other than Windows 10. Also, the unified management software "AMC Manager" is used to update the firmware. The free version of AMC Manager can be downloaded from our website (<https://www.silextechnology.com/>).


TIP

- * To update the firmware, both AP-500AC and your PC need to be connected to a wired network.
- * When AP-500AC is Ver.1.0.1, update it to Ver.1.0.2 first and then to a newer version. If AP-500AC is mistakenly updated from Ver.1.0.1 to a version newer than Ver.1.0.2, please initialize AP-500AC and start it over.

1 Start AMC Manager, select AP-500AC from the list and click the Web configuration icon .



* When two or more AP-500AC units are displayed on AMC Manager, identify the target one by checking it with IP address and MAC address.
 * If you know IP address of AP-500AC, the Web configuration interface can be accessed by entering IP address to the address bar of your Web browser (Internet Explorer, Google Chrome, etc).




2 When the login screen is displayed, enter the password of AP-500AC and click **Login**. (By defaults, no password is set to AP-500AC.)




3 Click **Maintenance - Firmware Update** from the left menu on the Web page.



4 In the **Firmware Update** page, click **Browse**, select the firmware file to be loaded to AP-500AC (AP-500AC.bin) and click **Update**.



* When the firmware update is finished, AP-500AC is automatically restarted. Do not turn off AP-500AC or close your Web browser while the firmware update is in progress.



5 When the login menu is displayed, the firmware update is complete. Check that the version information is changed in the bottom left of Web page.

