
MAZDA MOTORSPORTS

By: PENSKE

SPEC MX5 REAR SHOCK, P/N: 0000-04-5292-SA REQUIRED REAR UPPER MOUNT KIT, P/N: 0000-04-5358



SHAFT SPACER & BUMP RUBBER:

- Black plastic spacer provides uniform surface for bump rubber contact - .875" thick
- Black Penske bump rubberdirection as shown with wide base toward spacer


Provides a plush cushion near the end of stroke Prevents abrupt damper bottoming


- 2.5" long used to access adjuster
- 8 total clicks of adjustment counted from the full-stiff position
- Adjustment affects both compression and rebound damping

TOP MOUNT

MAZDA MOTORSPORTS







MAZDA MOTORSPORTS

By:

PENSIFE

RACING SHOCKS

REAR SHOCK SPACING

This picture shows improper spacing of the lower shock mount. The proper spacing procedure requires the user to install the rear dampers without springs and take the suspension through its full travel to confirm that the shock is centered within the mount. This procedure must be completed after the racecar has been properly aligned to achieve race settings (Camber). Improper spacing will likely cause binding of the suspension, and a loss of performance.





PROPER SPACING

This picture shows the proper spacing of the lower shock mount.



150 FRANKLIN ST • P.O. BOX 1056 READING, PA 19602 (610) 375-6180 • (610) 375-6190 FAX